

[Manuals.plus](#) /

› [Brewista](#) /

› Brewista Artisan Electric Gooseneck Kettle BA10VKETL Instruction Manual

Brewista BA10VKETL

Brewista Artisan Electric Gooseneck Kettle Instruction Manual

Brand: Brewista | **Model:** BA10VKETL

1. INTRODUCTION

Thank you for choosing the Brewista Artisan Electric Gooseneck Kettle. This kettle is designed for coffee and tea enthusiasts who demand precision and style. With its precise temperature control, fast boiling capabilities, and elegant design, it enhances your brewing experience. Please read this manual thoroughly before use to ensure safe and optimal operation.



Image: The Brewista Artisan Electric Gooseneck Kettle in Mirror Polished finish, showcasing its sleek design and gooseneck spout, accompanied by various coffee brewing tools.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or heating base in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
12. Do not use appliance for other than intended use.
13. Extreme caution must be used when moving an appliance containing hot water.

3. PACKAGE CONTENTS

Your Brewista Artisan Electric Gooseneck Kettle package includes:

- Kettle Body
- Lid
- Heating Base
- Power Cord

4. PRODUCT FEATURES

The Brewista Artisan Electric Gooseneck Kettle is engineered with several key features to optimize your brewing experience:

- **Elegant Design & Quality Construction:** This gooseneck kettle combines a sleek aesthetic with durable stainless steel construction, ideal for coffee enthusiasts who value both appearance and performance.
- **Precision Gooseneck Spout:** Designed for controlled and even water flow, the gooseneck spout ensures steady, accurate pouring, crucial for achieving perfect extraction in pour-over methods.
- **Accurate Temperature Control:** Achieve pinpoint accuracy with 1-degree adjustments. The intuitive LCD console allows you to set the exact water temperature, unlocking the full potential of various roasts, grinds, and steeped teas.
- **Fast Boiling Setting:** Reduce waiting time with the kettle's rapid boiling capability, streamlining your coffee routine.
- **Keep Warm Function:** The keep-warm setting maintains your desired water temperature for an extended period, ensuring your coffee or tea remains perfectly warm without reheating.
- **Integrated Timer:** A built-in timer assists in mastering the perfect brewing rhythm, specifically designed for pour-over coffee to precisely control every second for the ultimate flavor experience.




Image: A collage of Brewista Artisan Electric Gooseneck Kettles in different finishes, emphasizing the product's stylish design.

GOOSENECK SPOUT DESIGN

Gooseneck spout for accurate pour control



Image: A visual representation of the gooseneck spout's precision, showing how it allows for controlled pouring techniques like drip, trickle, and turbulent flow.

5. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the heating base on a dry, flat, and stable surface. Ensure it is away from the edge of the counter and out of reach of children.
3. **Initial Cleaning:** Before first use, fill the kettle with water to the MAX line, boil, and then discard the water. Repeat this process 2-3 times to remove any manufacturing residues.
4. **Connect Power:** Plug the power cord into a standard electrical outlet.

6. OPERATING INSTRUCTIONS


Operating your Brewista Artisan Electric Gooseneck Kettle is straightforward:


1. **Fill the Kettle:** Remove the lid and fill the kettle with fresh, cold water. Do not fill below the MIN line or above the MAX line (1 Liter capacity). Replace the lid securely.
2. **Place on Base:** Place the kettle body onto the heating base.
3. **Power On:** Press the power button (**Power Button icon**) on the LCD panel to turn on the kettle.
4. **Set Temperature:** Use the plus (+) and minus (-) buttons to adjust the desired temperature in 1-degree increments. The LCD will display the set temperature. You can also switch between Fahrenheit and Celsius using the F/C button.
5. **Start Heating:** The kettle will automatically begin heating to the set temperature. The LCD will show the current water temperature as it rises.
6. **Fast Boil:** For rapid boiling, select the highest temperature setting or use the dedicated fast boil function if available on your model.
7. **Keep Warm:** To activate the keep warm function, press the keep warm button (**Keep Warm icon**) after setting your desired temperature. The kettle will maintain this temperature for up to 1 hour.
8. **Integrated Timer:** The built-in timer can be activated to assist with pour-over brewing. Consult the specific instructions for timer usage on your model's LCD panel.
9. **Pouring:** Once the desired temperature is reached, carefully lift the kettle from the base and use the gooseneck spout for precise pouring.


10. **Power Off:** The kettle will automatically shut off after reaching the set temperature or after the keep warm cycle. You can manually turn it off by pressing the power button.




Image: The LCD control panel of the kettle, detailing the various buttons for temperature adjustment, fast boil, keep warm, and timer functions.


TEMPERATURE SETTING
With pinpoint heat accuracy, release the complete flavor profile of your favorite roasts and truly elevate your coffee-drinking experience.


KEEP WARM SETTING
Relive that first cup feeling without restarting your water. Maintain your desired water temperature and hold it there with the Keep Warm setting.


FLASH BOIL SETTING
With boiling speeds that even coffee aficionados can enjoy, Brewista's high-powered boil means less time waiting, and more time enjoying a perfect cup of coffee.


COUNT-UP TIMER SETTING
Master the perfect brewing rhythm every time. The timing feature is designed specifically for pour-over coffee, precisely controlling every second for the ultimate flavor experience.

Images: Visual representations of the Temperature Setting, Keep Warm Setting, Flash Boil Setting, and Count-Up Timer Setting.

Official Product Videos

Video: An official product video from Brewista demonstrating the Electric Gooseneck Kettle in use, highlighting its features and design.

Video: An official product video from Amber&Stone (a seller of Brewista products) showcasing the Brewista Artisan Gooseneck Kettle, its aesthetics, and functionality.

7. CLEANING AND MAINTENANCE

Proper cleaning and maintenance ensure the longevity and performance of your kettle:

- **Daily Cleaning:** After each use, unplug the kettle and allow it to cool. Wipe the exterior with a soft, damp cloth.
- **Interior Cleaning:** The interior of the kettle can be hand washed. Do not use abrasive cleaners or scouring pads, as these can damage the stainless steel finish.
- **Descaling:** Over time, mineral deposits (limescale) may build up inside the kettle. To descale, fill the kettle

with a mixture of equal parts water and white vinegar. Bring to a boil and let it sit for 30 minutes to an hour. Empty and rinse thoroughly. Repeat if necessary.

- **Storage:** Store the kettle in a dry place when not in use.

8. TROUBLESHOOTING

If you encounter any issues with your kettle, please refer to the following common problems and solutions:

- **Kettle not heating:**
 - Ensure the power cord is securely plugged into both the base and the wall outlet.
 - Check if the kettle is properly seated on the heating base.
 - Verify that the power button has been pressed and a temperature is set.
- **Water not reaching desired temperature:**
 - Confirm the temperature setting on the LCD panel.
 - Ensure the lid is securely closed to prevent heat loss.
 - Descale the kettle if there is significant mineral buildup.
- **Kettle leaks:**
 - Do not overfill the kettle beyond the MAX line.
 - Ensure the lid is properly seated and sealed.
- **LCD display not working:**
 - Unplug the kettle from the power outlet for a few minutes, then plug it back in.
 - Ensure the kettle is receiving power.

If the problem persists, please contact Brewista customer support.

9. SPECIFICATIONS

Feature	Detail
Brand	Brewista
Model Name	BA10VKETL
Color	Mirror Polished
Capacity	1 Liter
Material	Stainless Steel
Special Feature	Temperature Control
Finish Type	Mirrored
Product Dimensions	12.2"L x 9.06"W x 8.27"H
Item Weight	4.39 pounds
Included Components	Kettle Body, Lid, Heating Base, Power Cord

Product Care Instructions	Wipe Clean, Hand Wash
UPC	810060501320

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Brewista website. Keep your purchase receipt as proof of purchase for any warranty claims. Visit the Brewista Store for more information:[Brewista Store](#)