

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [EGGKING](#) /

› [EGGKING C200 Electric Bicycle User Manual - 20" Fat Tires, Dual Suspension, 7-Speed](#)

## EGGKING C200

# EGGKING C200 Electric Bicycle User Manual

Model: C200

<a href="#">Introduction</a>	<a href="#">Safety Information</a>	<a href="#">Package Contents</a>	<a href="#">Setup &amp; Assembly</a>	<a href="#">Operating Instructions</a>
<a href="#">Features</a>	<a href="#">Maintenance</a>	<a href="#">Troubleshooting</a>	<a href="#">Specifications</a>	<a href="#">Warranty &amp; Support</a>

## 1. INTRODUCTION

Welcome to the EGGKING C200 Electric Bicycle user manual. This manual provides essential information for the safe operation, assembly, maintenance, and troubleshooting of your new electric bicycle. Please read this manual thoroughly before your first ride to ensure optimal performance and safety.

The EGGKING C200 is designed for adults, featuring 20-inch fat tires, dual suspension, and a 7-speed gear system, powered by a removable 48V battery. It is compliant with EU Regulation 168/2013 for EPAC vehicles.

## 2. SAFETY INFORMATION

Your safety is paramount. Always wear a helmet and appropriate safety gear when riding. Familiarize yourself with local traffic laws and regulations regarding electric bicycles. This e-bike is intended for adult use only.

- **Pre-Ride Check:** Before each ride, check tire pressure, brake function, battery level, and ensure all bolts and quick releases are securely fastened.
- **Braking:** The dual mechanical disc brakes provide reliable stopping power. Practice braking in a safe area to understand their response.
- **Battery Safety:** Do not expose the battery to extreme temperatures or water. Use only the provided charger. Do not attempt to open or modify the battery pack.
- **Weather Conditions:** Exercise caution when riding in wet or slippery conditions. The fat tires provide enhanced traction, but reduced grip is still possible.
- **Visibility:** Ensure the front and rear lights are functional, especially when riding in low light conditions.

## 3. PACKAGE CONTENTS

Upon unpacking, please verify that all items listed below are present:

- 1 x EGGKING C200 Electric Bicycle (pre-assembled)

- 1 x Removable 48V Lithium Battery
- 1 x Battery Charger
- 1 x Air Pump
- 1 x Mobile Phone Holder
- 1 x User Manual (this document)
- Assembly Tools

## 4. SETUP AND ASSEMBLY

---

Your EGGKING C200 electric bicycle comes largely pre-assembled. Follow these steps to complete the assembly:

### 4.1 General Assembly Overview

Watch this video for a quick overview of the assembly process, including handlebar, front wheel, mudguard, headlight, brake handle, pedal, and rear stirrup installation.

Your browser does not support the video tag.

*Video: EGGKING C200 Electric Bicycle Assembly Tutorial.*


### 4.2 Handlebar Installation

Remove the fixing screws from the handlebar stem. Carefully install the handlebar, ensuring proper alignment. Tighten the screws securely, adjusting the angle for comfortable riding before final tightening.

# VIAGGI BREVI SENZA PAURA



# 840WH



*Image: Handlebar installation process.*

## 4.3 Front Wheel Installation

Align the front wheel with the fork, ensuring the brake pads are correctly positioned around the disc. Securely tighten all screws on both sides of the axle.

# 1500W POWERFUL HUB-MOTOR

Alto coppia e valore di picco ti permettono di perseguire velocità più elevate.



**48V**



**17.5Ah**



**32 MPH**  
MAX SPEED



**7-SPEED**  
SHIMANO GEARS



*Image: Front wheel installation, focusing on brake disc and axle nuts.*

## 4.4 Front Mudguard Installation

Remove the existing fixing screws on the front fork. Position the front mudguard and re-install the screws to secure it in place.

# BATTERIA HIGH-CAPACITY, SCAMBIABILE



**60-100 Mi**  
Max Range



**3 Riding**  
Modes



**Lockable**



**45° Up**  
Slop



*Image: Installation of the front mudguard.*

## 4.5 Headlight Installation

Install the headlight onto its bracket. Pay close attention to the direction of the cable interface when connecting it. Ensure the connection is secure.

# LUCI PIÙ GRANDI E PIÙ LUMINOSE



*Image: Headlight assembly and cable connection.*

## 4.6 Brake Handle Adjustment

Adjust the brake handles to a comfortable position and securely fix their screws.

# 20"X4.0" FAT TIRE EBIKE

Adattarsi a vari terreni



Image: Brake handle adjustment.

## 4.7 Pedal Installation

When installing the foot pedals, note that they are marked 'L' for left and 'R' for right. Ensure you install them on the correct side and tighten them firmly.



**400 LBS**  
Carico massimo



**5.5"-6.5"**  
Consigliato carico di altezza



**83 LBS**  
Peso dell'ebike

**A** Lunghezza totale: 68"

**B** Altezza manubrio: 44"

**C** Passo: 43.5"

**D** Diametro della ruota: 24"

**E** Altezza del sedile: 21,5"

**F** Cadenza: 18"

**G** Lunghezza del tubo superiore: 17"

*Image: Pedal installation with L/R distinction.*

#### 4.8 Rear Stirrups Installation

For the left side rear stirrup, you will need to remove the screws of the foot support first. For the right side, the stirrup can be installed directly. Securely fasten all screws.



Image: Rear stirrups installation.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Powering On/Off and Display

The LCD panel displays essential information such as speed, battery level, and riding mode. Consult the display for current operational status.

## Control mediante APP

The image displays the app interface for the YouFs-B9 motorcycle. The app features a central motorcycle icon and a 'Connected' status indicator. Below the icon, there are three data points: Single Mileage (0.0 km), Est. Range (0.0 km), and Total Mileage (0.0 km). A 'Funcs' section at the bottom includes three toggle switches for Cruise, Headlight, and Start mode. The Start mode toggle is currently turned on. To the left of the smartphone, a grid of six blue circular icons represents app features: Cruise Control (target icon), Speed Mode (speedometer icon), Start Mode (power button icon), Remaining Battery (battery icon), Lock & Unlock Bike (lock icon), and Ride Mileage (cyclist icon).

Image: LCD display and app control features.

### 5.2 Riding Modes and Gear Shifting

The EGGKING C200 offers 3 riding modes: electric, assisted, and pedal. Use the 7-speed gear system to adapt to various terrains and preferences.



*Image: 7-speed gear system for varied terrain.*

### 5.3 Unlocking the Throttle

To unlock the throttle function, hold the brake lever and press the 'M' button on the display three times consecutively. This will enable the full electric mode.

Your browser does not support the video tag.

*Video: Demonstration of unlocking the throttle.*

### 5.4 Unlocking Maximum Speed

To unlock the maximum speed setting, hold the brake lever and press the 'M' button on the display two times consecutively. This will adjust the speed limit.

Your browser does not support the video tag.

*Video: Demonstration of unlocking the maximum speed.*

## 6. KEY FEATURES

- **EU Homologation:** EPAC compliant with EU Regulation 168/2013, featuring a nominal 250W motor (750W peak) and a speed limiter at 25 km/h.
- **Long-Range Removable Battery:** Powerful 48V 17.5Ah detachable lithium battery offering a range of 50-80 km per charge.
- **Dual Mechanical Disc Brakes:** Provides immediate and reliable braking response in various terrains and weather conditions.
- **20" x 4.0" Fat Tires & Dual Suspension:** Wide tires combined with a dual suspension system absorb impacts and provide excellent traction for comfortable riding on both city streets and uneven paths.
- **LCD Display & 7 Speeds:** Clear LCD panel shows speed, battery level, and other essential data. The 7-speed shifter with 3 riding modes (electric/assisted/pedal) adapts to your needs.



# E-bike de llantas anchas

## The Perfect Electric Dirt Bike



750 Motor



Doble disco delantero + trasero



Batería de litio 48V 17.5Ah



Alcance máximo 80 km



Image: Fat tires and their versatility across different terrains.

# Brushless Motor



**80 N.m**  
Max. Torque



**750**  
Peak Power



**30°**  
Climbing Angle




Image: Brushless motor specifications.



Image: Battery specifications and features.

## 7. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your EGGKING C200 electric bicycle.

- **Cleaning:** Clean your e-bike regularly with a damp cloth. Avoid high-pressure washing directly on electrical components.
- **Tires:** Check tire pressure before each ride. Maintain recommended pressure for optimal performance and safety. Inspect tires for wear and damage.
- **Brakes:** Regularly check brake pads for wear and ensure brake levers respond correctly. Adjust or replace as needed.
- **Chain:** Keep the chain clean and lubricated to ensure smooth gear changes and prevent wear.
- **Battery Care:** Charge the battery regularly, even if not in use, to maintain its health. Store the battery in a cool, dry place.
- **Fasteners:** Periodically check all bolts, nuts, and quick releases for tightness.

## 8. TROUBLESHOOTING

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Bike does not power on.	Battery not charged, battery not properly seated, power cable loose.	Charge battery, ensure battery is fully inserted, check all cable connections.
Motor not assisting.	Low battery, incorrect riding mode, throttle locked.	Check battery level, select appropriate riding mode, unlock throttle (refer to section 5.3).

Problem	Possible Cause	Solution
Brakes feel weak.	Worn brake pads, loose brake cable, air in brake line (less likely for mechanical).	Inspect and replace brake pads, adjust brake cable tension. If issue persists, consult a professional.
Unusual noises during ride.	Loose components, dry chain, brake rub.	Check all fasteners, lubricate chain, inspect brake alignment.

If you encounter issues not listed here or if the suggested solutions do not resolve the problem, please contact customer support.

## 9. SPECIFICATIONS

Feature	Detail
Brand	EGGKING
Model Number	C200
Type	Electric Bicycle (EPAC)
Wheel Size	20 Inches (Fat Tires)
Motor Power	250W Nominal (750W Peak)
Max Speed	25 km/h (EU compliant)
Battery	48V 17.5Ah Lithium (Removable)
Range	50-80 km (depending on conditions)
Brakes	Dual Mechanical Disc Brakes
Suspension	Doble
Gears	7-Speed
Frame Material	High-Carbon Steel
Weight	38 kg
Max Load	400 LBS (approx. 181 kg)
Special Features	Front Light, Rear Light, Digital Display, Mobile Phone Holder

## 10. WARRANTY AND SUPPORT

EGGKING products come with a standard manufacturer's warranty. For specific warranty details, registration, or to contact customer support, please refer to the warranty card included in your package or visit the official EGGKING website. Keep your proof of purchase for warranty claims.

For technical assistance or spare parts, please contact our specialized customer service team.

