

ProtoArc EM15

ProtoArc EM15 Bluetooth Wireless Mouse Instruction Manual

Model: EM15

- Introduction
- Package Contents
- Product Overview
- Setup
- Operating
- Maintenance
- Troubleshooting
- Specifications

1. INTRODUCTION

Thank you for choosing the ProtoArc EM15 Bluetooth Wireless Mouse. This compact and versatile mouse is designed to enhance your productivity across multiple devices with its seamless connectivity options and ergonomic design. Please read this manual carefully to ensure proper use and optimal performance.

2. PACKAGE CONTENTS

- ProtoArc EM15 Wireless Mouse
- USB-C Receiver (stored in mouse)
- USB-A Receiver (stored in mouse)
- USB-C Charging Cable
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the various buttons and ports on your ProtoArc EM15 mouse:



Image 1: Top and Bottom View of ProtoArc EM15 Mouse with labeled components. The top view shows the Left Button, Right Button, Scroll Wheel, DPI Switch, Forward Button, Backward Button, and Type C Charging Port. The bottom view shows the Power Switch, Mode Switch Button, USB Receiver, and Type C Receiver storage slots.

- **Left/Right Buttons:** Standard mouse click functions.
- **Scroll Wheel:** For vertical scrolling.
- **DPI Switch:** Adjusts cursor sensitivity (1000/1600/2400 DPI).
- **Forward/Backward Buttons:** Navigate web pages or documents. *(Note: Not compatible with Mac OS systems for*

navigation.)

- **Type C Charging Port:** Located at the front of the mouse for recharging.
- **Power Switch:** Turns the mouse ON/OFF.
- **Mode Switch Button:** Cycles between USB, Type-C, and Bluetooth connection modes. LED indicators show the active mode.
- **Receiver Storage:** Dedicated compartment on the bottom for USB-A and USB-C receivers.

4. SETUP

4.1 Charging the Mouse

The ProtoArc EM15 mouse features a built-in Lithium Ion battery. To charge:

1. Connect the provided USB-C charging cable to the Type C Charging Port on the front of the mouse.
2. Connect the other end of the cable to a USB power source (e.g., computer USB port, wall adapter).
3. A full charge typically takes 1-2 hours and provides approximately 15 days of use or 200 days of standby time.



Image 2: The ProtoArc EM15 mouse connected to a USB-C charging cable, illustrating the charging process. Text indicates 1-2 hours charging time and 200 days standby time.

4.2 Connecting to Devices

The EM15 mouse supports simultaneous connection to three different devices via Bluetooth, USB-A, and USB-C receivers. You can switch between connected devices with a single button.

Using USB-A or USB-C Receiver:

1. Locate the receiver compartment on the bottom of the mouse.
2. Gently slide open the cover and remove the desired receiver (USB-A or USB-C).
3. Plug the receiver into an available USB-A or USB-C port on your computer or device.
4. Turn on the mouse using the Power Switch on the bottom.
5. Press the Mode Switch Button on the bottom until the corresponding LED indicator for the receiver (e.g., blue for USB-C, red for USB-A) lights up. The mouse should connect automatically.



Image 3: The bottom of the ProtoArc EM15 mouse, highlighting the storage compartment for the USB-A and USB-C receivers.

Using Bluetooth:

1. Turn on the mouse using the Power Switch on the bottom.
2. Press the Mode Switch Button on the bottom until the Bluetooth LED indicator (e.g., flashing blue) lights up, indicating it's in pairing mode.
3. On your device (laptop, tablet, PC), go to Bluetooth settings and search for new devices.
4. Select "ProtoArc EM15" from the list of available devices to pair.
5. Once paired, the LED indicator on the mouse will become solid.



Image 4: The ProtoArc EM15 mouse shown in a multi-device setup, illustrating its connectivity options with a laptop, tablet, and smartphone.

4.3 Official Product Video: Multi-Device Connectivity

Your browser does not support the video tag.

Video 1: This video demonstrates the ProtoArc EM15 mouse's multi-device connectivity, showing how to switch between Bluetooth and 2.4G wireless modes using the dual receivers. It highlights the ease of connecting to various devices like laptops and tablets.

5. OPERATING THE MOUSE

5.1 Adjustable DPI for Smooth Movement

The EM15 mouse offers adjustable DPI (Dots Per Inch) levels to customize cursor sensitivity and tracking speed. This allows for precise control across various surfaces and tasks.

1. Press the **DPI Switch** button (located below the scroll wheel) to cycle through the available DPI settings: 1000, 1600, and 2400.
2. Each press will change the sensitivity, allowing you to find the optimal speed for your work or gaming needs.



Image 5: A visual representation of the adjustable DPI settings (1000, 1600, 2400) for the ProtoArc EM15 mouse, indicating cursor sensitivity options.

5.2 Quiet Click and Ergonomic Design

The EM15 mouse features silent click buttons (left and right click) to minimize noise, making it ideal for quiet environments. Its slim and ergonomic design provides maximum support and comfort for extended use.



Image 6: The ProtoArc EM15 mouse with visual indicators for its quiet click feature, emphasizing silent operation.



Image 7: The ProtoArc EM15 mouse showcasing its ergonomic design, providing a comfortable grip for users.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the mouse in a cool, dry place. Ensure receivers are securely stored in their compartment to prevent loss.
- **Battery Care:** To prolong battery life, avoid fully discharging the mouse frequently. Charge it when the battery indicator is low.

7. TROUBLESHOOTING

7.1 Connection Issues

- **Mouse not responding:** Ensure the mouse is turned ON and fully charged. Check that the correct connection mode (USB, Type-C, or Bluetooth) is selected via the Mode Switch Button.
- **Receiver not detected:** Ensure the USB-A or USB-C receiver is firmly plugged into your device's port. Try a different USB port.
- **Bluetooth pairing failure:** Make sure your device's Bluetooth is enabled and the mouse is in pairing mode (flashing LED). Remove any previous pairings of the mouse from your device's Bluetooth list and try pairing again.

7.2 Performance Issues

- **Cursor erratic or slow:** Adjust the DPI setting using the DPI Switch button. Ensure the mouse is used on a clean, suitable surface.
- **Forward/Backward buttons not working:** These buttons may not be compatible with all operating systems or applications. Specifically, they are not compatible with Mac OS for navigation.

8. SPECIFICATIONS

Feature	Detail
Model	EM15
Brand	ProtoArc
Connectivity Technology	2.4G Wireless, Bluetooth, Type C Wireless
Movement Detection Technology	Optical
DPI Levels	1000/1600/2400
Special Features	Ergonomic Design, Lightweight, Portable, Rechargeable, Soundless (Quiet Click)
Battery Type	Built-in Lithium Ion
Charging Time	Approx. 1-2 hours
Usage Time	Approx. 15 days (active use)
Standby Time	Approx. 200 days
Compatibility	Windows 7/8/10/XP, Vista, Mac OS X 10.10 or later, Type-C devices, tablets, cellphones, Macbook, Macbook Pro, iMac, iMac Pro, Chromebook
Item Weight	7 ounces
Package Dimensions	5.28 x 4.49 x 2.72 inches

9. WARRANTY & SUPPORT

For warranty information or technical support, please refer to the contact details provided in your product packaging or visit the official ProtoArc website. Keep your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F7R9D9ZS>

More documents and user manuals: <https://manuals.plus/>