

Greesum GS-T-SCLB23-0413A-WT-0507

Greesum Litter Robot Professional Self-Cleaning Cat Litter Box User Manual

Model: GS-T-SCLB23-0413A-WT-0507

INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation, setup, and maintenance of your Greesum Litter Robot Professional Self-Cleaning Cat Litter Box. Please read this manual thoroughly before using the product to ensure proper function and longevity.

SAFETY INFORMATION

- Always place the unit on a firm, level surface.
- Do not immerse the unit in water or spray directly with water.
- Keep children and pets away from the unit during cleaning cycles.
- Use only clumping cat litter with this device. Non-clumping litter may interfere with operation.
- Unplug the unit from the power outlet before performing any maintenance or cleaning.
- Ensure the power cord is not damaged or pinched.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Greesum Litter Robot Professional Unit
- Power Adapter
- 2 Roll Garbage Bags
- Litter Mat
- User Manual (this document)

PRODUCT OVERVIEW

The Greesum Litter Robot Professional is an automated self-cleaning litter box designed to simplify cat waste management. It features a rotating globe that sifts waste into a concealed drawer, maintaining a clean litter bed for your cat.



Image: The Greesum Litter Robot Professional in white, shown with a grey cat sitting on a matching litter mat. A smartphone displays the companion app interface, indicating Wi-Fi connectivity status (2.4GHz connected, 5GHz not connected).

SETUP

1. **Placement:** Place the Litter Robot on a firm, level surface indoors, away from direct sunlight or heat sources. Ensure there is enough space around the unit for proper ventilation and access.
2. **Power Connection:** Connect the power adapter to the unit and then plug it into a standard electrical outlet. The unit will perform an initial calibration cycle.
3. **Add Litter:** Fill the globe with clumping cat litter, ensuring the litter level is between the MIN and MAX fill lines indicated inside the globe. Do not overfill.
4. **Install Waste Bag:** Open the waste drawer and insert one of the provided garbage bags. Ensure the bag is properly secured to prevent leaks.
5. **App Connection (Optional):**
 - Download the "Auto Self-Cleaning Cat Litter..." app from your device's app store.
 - Follow the in-app instructions to connect your Litter Robot to your home Wi-Fi network. The unit

supports 2.4GHz Wi-Fi.

- Verify successful connection by checking the Wi-Fi indicator lights on the unit and within the app.

OPERATING INSTRUCTIONS

Automatic Cleaning Cycle

The Litter Robot is designed to automatically clean itself after your cat uses it. A sensor detects when your cat enters and exits the globe. After a preset delay (Wait Time), the globe will rotate, sifting waste into the waste drawer.

- **Wait Time:** The delay before a cleaning cycle begins. This allows clumps to form properly. Adjust this setting via the app (e.g., 6 minutes).
- **Usage Tracking:** The app displays usage statistics such as cat weight, duration of use, and number of uses.

Manual Operation via App

The companion app provides additional control over the unit:

- **CLEAN:** Initiates a cleaning cycle immediately.
- **CLEAR:** Resets certain settings or clears error notifications.
- **Child Lock:** Activates or deactivates a safety lock feature to prevent unintended operation.

MAINTENANCE

Emptying the Waste Drawer

1. When the waste drawer is full, the app will notify you, or you may observe a full indicator on the unit.
2. Unplug the unit from the power outlet.
3. Pull out the waste drawer.
4. Carefully remove the full garbage bag, tie it securely, and dispose of it.
5. Insert a new garbage bag into the drawer and push the drawer back into the unit until it clicks into place.
6. Plug the unit back in.

Cleaning the Unit

Regular cleaning is essential for hygiene and optimal performance.

- **Exterior:** Wipe the exterior surfaces with a damp cloth and mild detergent. Avoid abrasive cleaners.
- **Globe:** For thorough cleaning, the globe can be removed. Unplug the unit, remove the globe, and wash it with mild soap and water. Ensure it is completely dry before reassembling.
- **Base:** Clean the base with a damp cloth. Do not submerge the base in water as it contains electronic components.
- **Litter Mat:** The included litter mat can be easily cleaned by shaking off loose litter and washing with water.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit not cycling or spinning	Obstruction, motor issue, sensor error, or improper assembly.	<ul style="list-style-type: none">• Check for foreign objects or excessive litter clumps blocking the globe's rotation.• Ensure the globe is correctly seated on the base.• Unplug the unit, wait 30 seconds, then plug it back in to reset.• Verify the litter level is not too high.
Unpleasant odor	Full waste drawer, unit requires cleaning, or inadequate ventilation.	<ul style="list-style-type: none">• Empty the waste drawer regularly.• Perform a thorough cleaning of the globe and base.• Ensure the unit is in a well-ventilated area.
Litter or waste leakage	Improper waste bag installation, damaged seal, or excessive moisture.	<ul style="list-style-type: none">• Ensure the waste bag is properly secured in the drawer.• Check for any cracks or damage to the globe or waste drawer.• Ensure the litter is clumping effectively and not too wet.
App connectivity issues	Incorrect Wi-Fi password, out of range, or 5GHz network.	<ul style="list-style-type: none">• Ensure your router is broadcasting a 2.4GHz Wi-Fi signal.• Move the unit closer to your Wi-Fi router.• Re-enter Wi-Fi credentials in the app.• Restart your router and the Litter Robot.

SPECIFICATIONS

Feature	Detail
Brand	Greesum
Model Name	Self Cleaning Automatic Cat Litter Box
Item Model Number	GS-T-SCLB23-0413A-WT-0507
UPC	760606835580




Feature	Detail
Product Dimensions (LxWxH)	21 x 20 x 20 inches
Item Weight	24.7 pounds
Material	Plastic
Color	White
Size	Extra-large
Litter Box Type	Automated Self-Cleaning Litter Box
Included Components	2 Roll Garbage Bags, Mat




WARRANTY AND SUPPORT

For warranty information, technical support, or to inquire about replacement parts, please contact Greesum customer service. Refer to your purchase documentation for specific warranty terms and contact details. You may also visit the official Greesum website for further assistance.

© 2025 Greesum. All rights reserved.

Related Documents - GS-T-SCLB23-0413A-WT-0507

	<p>Greesum Brown 4-Piece Wicker Outdoor Patio Furniture Set Assembly and Care</p> <p>Comprehensive guide for the Greesum 4-Piece Wicker Outdoor Patio Furniture Set, covering assembly instructions, parts list, usage, care, and warranty information for outdoor living spaces.</p>
	<p>Greesum Patio Furniture Set: Parts List and Assembly Instructions</p> <p>Comprehensive guide for assembling your Greesum patio furniture set. Includes a detailed parts list for the chair and coffee table, along with step-by-step assembly instructions.</p>
	<p>Nobleza Automatic Cat Litter Box Instruction Manual</p> <p>Comprehensive instruction manual for the Nobleza Automatic Cat Litter Box (Model T-MSP1). Learn how to set up, operate, clean, and troubleshoot this smart, self-cleaning pet device for optimal hygiene and convenience.</p>

	<p>NOTTY Automatic Cat Litter Box User Manual</p> <p>User manual for the NOTTY Automatic Cat Litter Box (Model T-MSP1), detailing setup, operation, cleaning, app control, and product specifications. Includes warranty information and FCC compliance.</p>
	<p>Pettadore Air Insight User Manual: Setup, Operation, and Specifications</p> <p>Comprehensive user manual for the Pettadore Air Insight, covering setup, operation, LED status, specifications, precautions, and warranty terms. Learn how to install and use your pet odor eliminator.</p>
	<p>Danfoss FH-WC Connection Box 230V Installation Guide</p> <p>Comprehensive installation guide for the Danfoss FH-WC Connection Box 230V, detailing wiring diagrams, setup steps, and compatibility with Danfoss Icon and BasicPlus2 systems.</p>