

FLEXISPOT One-Piece Standing Desk with Rattan Drawers

FLEXISPOT One-Piece Standing Desk with Rattan Drawers (48x24" Black)

User Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your FLEXISPOT One-Piece Standing Desk with Rattan Drawers. Please read this manual thoroughly before installation and use to ensure proper function and safety. Keep this manual for future reference.



Image: The FLEXISPOT One-Piece Standing Desk in black with rattan drawers, featuring a monitor shelf and an integrated control panel.

IMPORTANT SAFETY INFORMATION

To prevent injury or damage to the product, observe the following safety guidelines:

- Always follow the assembly instructions carefully.
- Keep children and pets away from the assembly area.
- Use appropriate tools and safety gear during assembly.
- Ensure all connections are secure before operating the desk.
- Do not overload the desk. The maximum weight capacity is 110 lbs.
- Keep hands and objects clear of moving parts during height adjustment.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. The desk ships in two separate packages.

- Desktop with integrated monitor shelf and rattan drawers
- Desk frame and legs

- Control panel
- Power adapter and cables
- Assembly hardware (screws, bolts, tools)
- User Manual



Image: A diagram illustrating the dimensions of the desk components and indicating that the product ships in two separate packages.

ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately one hour. Refer to the separate detailed assembly guide included in your package for step-by-step instructions and diagrams. Ensure all fasteners are correctly identified and used in their designated locations.

1. Unpack all components and verify against the package contents list.
2. Attach the desk legs to the desktop frame using the provided hardware.
3. Connect the control panel and motor cables as instructed.
4. Secure any cable management components.
5. Place the desk in its desired location.

SETUP

After assembly, connect the desk to a power source.

- Plug the power adapter into the desk's control box.
- Plug the power cord into a standard electrical outlet.
- The desk is now ready for initial use.

OPERATING INSTRUCTIONS

Height Adjustment

The desk features an electric motor system for smooth height transitions.

- Press the **Up arrow** button to raise the desk.
- Press the **Down arrow** button to lower the desk.
- The desk can adjust between 28.9 inches (minimum) and 46.5 inches (maximum).
- The motor operates quietly, typically below 50dB.



Image: The desk shown at its minimum (28.9") and maximum (46.5") adjustable heights.

Memory Presets

Program up to three preferred height settings for quick adjustments.

- Adjust the desk to your desired height.
- Press the **M** button, then press one of the numbered preset buttons **1**, **2**, or **3** within 3 seconds to save the current height.
- To recall a saved height, simply press the corresponding numbered preset button.



Image: A close-up view of the desk's control panel, highlighting the up/down arrows and memory preset buttons.

Monitor Shelf

The integrated monitor shelf is designed to elevate screens to an ergonomic eye level.

- Place your monitor(s) on the shelf to reduce neck and back strain.
- This helps maintain proper posture during extended work sessions.

ADAPTABLE WORK POSITION REDUCED STRAIN



Image: Visual comparison of poor posture versus ergonomic sitting and standing postures facilitated by the adjustable desk.

Rattan Drawers

The desk includes both sliding-door desktop compartments and an under-desk drawer for organized storage.

- Use the desktop compartments (47.2"x8.7"x5.5") for easy access to frequently used items.
- The under-desk drawer (23.6"x11.8"x3.9") provides discreet storage for documents or books.

OPTIMIZE SPACE UTILIZATION



Image: An illustration demonstrating the various storage options, including the monitor stand, storage cabinet, and drawers, for optimal space utilization.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your desk.

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Cable Management:** Ensure cables are neatly organized and not interfering with the desk's movement.

TROUBLESHOOTING

If you encounter issues with your desk, refer to the following common solutions:

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem | Possible Cause | Solution |
|---|--|--|
| Desk does not move or respond to controls. | Power connection issue, cable disconnected, motor error. | Check power cord connection to outlet and desk. Ensure all motor cables are securely connected. Unplug and replug the power for 10 seconds to reset. |
| Desk moves unevenly or makes unusual noise. | Uneven load, loose connections, obstruction. | Ensure weight is evenly distributed. Check for any obstructions under the desk. Verify all assembly screws are tight. |
| Memory presets are not working. | Presets not saved correctly. | Re-save the desired height settings by pressing 'M' then the preset number within 3 seconds. |

SPECIFICATIONS

| Feature | Detail |
|--------------------------------|---|
| Brand | FLEXISPOT |
| Product Dimensions (D x W x H) | 23.6"D x 47.2"W x 29"H (at lowest point) |
| Color | Black |
| Base Material | Alloy Steel |
| Top Material Type | Wood |
| Minimum Height | 28.9 Inches |
| Maximum Height | 46.5 Inches |
| Number of Drawers | 1 (under-desk) |
| Enclosed Shelves | 2 (sliding-door desktop compartments) |
| Special Feature | Corded electric height adjustment, Memory Presets |
| Required Assembly | Yes |







WARRANTY AND SUPPORT

FLEXISPOT provides comprehensive warranty coverage for your standing desk:

- **Frame and Motor:** 5-year coverage.
- **Electronics:** 2-year coverage.

This warranty ensures lasting security for your workspace investment. For customer support, technical assistance, or warranty claims, please refer to the contact information provided in your product packaging or visit the official FLEXISPOT website.

Related Documents - One-Piece Standing Desk with Rattan Drawers

| | |
|---|--|
|  | <p>Flexispot E7 Operation Instructions</p> <p>User manual for the Flexispot E7 height adjustable desk controller, detailing its functions, buttons, memory presets, child lock, USB charging, collision prevention, and troubleshooting.</p> |
|  | <p>FlexiSpot Q8B/Q8W Height Adjustable Standing Desk Installation Guide and Warranty</p> <p>Comprehensive installation guide and warranty information for the FlexiSpot Q8B/Q8W height adjustable standing desk, including setup instructions, usage tips, troubleshooting, and warranty details.</p> |
|  | <p>FlexiSpot E7B/E7W/E7S-Plus Height Adjustable Desk User Manual & Installation Guide</p> <p>Detailed user manual for FlexiSpot E7B-Plus, E7W-Plus, and E7S-Plus height adjustable desks. Includes technical specifications, step-by-step installation instructions, handset operation, troubleshooting guide, and warranty information.</p> |
|  | <p>FlexiSpot E2LB-V2/E2LW-V2 Electric Height-Adjustable Desk User Manual</p> <p>User manual for the FlexiSpot E2LB-V2 and E2LW-V2 electric height-adjustable desks, covering assembly, operation, technical specifications, and troubleshooting.</p> |
|  | <p>FlexiSpot E5-UKV2 Standing Desk Frame User Manual and Installation Guide</p> <p>Comprehensive user manual and installation guide for the FlexiSpot E5-UKV2 electric height-adjustable desk frame. It includes detailed specifications, component identification, step-by-step assembly guidance, keypad functions, troubleshooting tips, and safety precautions. Learn how to set up your ergonomic workspace with FlexiSpot.</p> |
|  | <p>FlexiSpot Height Adjustable Desk EG1B/EG1W/EG1S Series Installation Guide and Limited Warranty</p> <p>Comprehensive guide for installing FlexiSpot height adjustable desks (EG1B/EG1W/EG1S series), including detailed steps, specifications, warranty information, and troubleshooting tips.</p> |