Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lancer Tactical GR1000W

Lancer Tactical x SnowPeak GR1000W Nitro Break Barrel 5.5mm .22 Caliber Air Gun User Manual

Model: GR1000W

1. Important Safety Information

WARNING: This air gun is not a toy. Misuse or careless use may cause serious injury or death. Read all instructions before using. Always wear eye protection. Always keep the muzzle pointed in a safe direction. Be sure of your target and what is beyond it. Never point at anything you do not intend to shoot. Always treat every gun as if it were loaded. Keep out of reach of children.

- Always assume the air gun is loaded.
- Never point the air gun at a person or anything you do not intend to shoot.
- Always wear appropriate eye protection when handling or shooting the air gun.
- Ensure the safety mechanism is engaged until you are ready to fire.
- Store the air gun unloaded and separate from ammunition, in a secure location inaccessible to children.
- Do not modify the air gun. Any modifications may void the warranty and compromise safety.
- Use only the correct caliber projectiles (5.5mm / .22 Caliber) as specified for this model.

2. Product Overview

The Lancer Tactical x SnowPeak GR1000W is a high-performance nitro break barrel air gun designed for target practice and small game hunting. It features a durable beech wood stock and is powered by a nitrogen piston for consistent shooting.



Figure 2.1: Overall view of the Lancer Tactical x SnowPeak GR1000W Nitro Break Barrel Air Gun. This image shows the full length of the air gun, highlighting its classic wood stock and barrel.



Figure 2.2: A detailed view of the trigger assembly and the Monte Carlo-style gunstock. This angle emphasizes the ergonomic design for enhanced cheek weld and aiming comfort.




Figure 2.3: A close-up of the front end of the air gun, showing the barrel and front sight. This view highlights the robust construction of the barrel.



Figure 2.4: The air gun displayed with its overall length of 50.78 inches and weight of 7.93 lbs, providing a clear understanding of its physical dimensions.

3. Setup

3.1 Unpacking

Carefully remove all components from the packaging. Verify that all included components are present:

- 1x Lancer Tactical x SnowPeak GR1000W Air Gun
- 1x Fill Probe (if applicable, though this is a break barrel)
- 1x Ring Set (for scope mounting)
- 1x Tooling Set
- 1x Manual (this document)

Inspect the air gun for any visible damage. If any components are missing or damaged, contact customer support immediately.

3.2 Mounting a Scope (Optional)

The GR1000W features an integrated 11mm mounting rail for easy scope or accessory installation. To mount a scope:

1. Ensure the air gun is unloaded and the safety is engaged.
2. Place the scope rings onto the 11mm rail, ensuring proper alignment.
3. Tighten the base screws of the rings securely to the rail.
4. Place the scope into the lower half of the rings.
5. Attach the upper half of the rings and tighten the screws evenly, ensuring the scope is level and at the correct eye relief.
6. Do not overtighten, as this can damage the scope tube.

4. Operating Instructions

4.1 Loading the Air Gun

1. **Engage Safety:** Always ensure the safety mechanism is engaged before handling or loading the air gun.
2. **Break the Barrel:** Firmly grasp the barrel and strike it downwards near the muzzle to break the barrel open. Continue to pull the barrel down until the spring/piston mechanism is cocked and locked into place. You will hear a click.
3. **Insert Pellet:** With the barrel broken open, insert a single 5.5mm (.22 Caliber) pellet into the breech. Ensure the pellet is seated correctly.
4. **Close the Barrel:** Return the barrel to its original position by pushing it upwards until it locks securely. Ensure it is fully closed before proceeding.

4.2 Firing the Air Gun

1. **Aim:** Point the air gun at a safe and appropriate target. Ensure there are no obstructions or unintended targets beyond your primary target.
2. **Disengage Safety:** When ready to fire, disengage the safety mechanism.
3. **Fire:** Gently squeeze the trigger to fire the air gun.
4. **Re-engage Safety:** After firing, immediately re-engage the safety mechanism.

Note: The nitrogen piston provides smooth and consistent shooting performance. Recoil may be present, so maintain a firm grip.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your Lancer Tactical x SnowPeak GR1000W air gun.

- **Cleaning the Barrel:** Periodically clean the barrel using a suitable cleaning rod and patches. Avoid using harsh solvents that could damage the barrel's rifling.
- **Lubrication:** Apply a small amount of silicone-based lubricant to moving parts, such as the pivot points of the break barrel mechanism, to ensure smooth operation. Do not over-lubricate.
- **Stock Care:** The beech wood stock can be cleaned with a soft, damp cloth. For long-term care, wood polish or oil can be applied as needed.
- **Storage:** Store the air gun in a cool, dry place, unloaded and with the safety engaged. Keep it in a gun case or cabinet to protect it from dust and damage, and to prevent unauthorized access.

Important: Do not attempt to disassemble the nitrogen piston system or internal mechanisms beyond routine cleaning. Unauthorized disassembly or modification will void the warranty and can be dangerous.

6. Troubleshooting

Problem	Possible Cause	Solution
Air gun does not cock.	Barrel not fully broken/pulled down.	Ensure the barrel is pulled down firmly until a distinct click is heard, indicating the piston is cocked.
Pellet does not fire.	Safety engaged; Barrel not fully closed; No pellet loaded.	Disengage safety; Ensure barrel is securely locked in place; Load a pellet.
Inaccurate shots.	Incorrect pellet type/weight; Dirty barrel; Loose scope/sights.	Use recommended 5.5mm (.22 Caliber) pellets; Clean the barrel; Check and tighten scope/sights.
Difficulty breaking barrel.	Lack of lubrication; New air gun (stiff mechanism).	Apply a small amount of silicone lubricant to the pivot points; Mechanism will loosen with use.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact customer support.

7. Specifications

Feature	Detail
Brand	Lancer Tactical
Model Name	GR1000W
Caliber	5.5mm (.22 Caliber)
Power Type	Nitrogen Piston
Barrel Material	Alloy Steel
Frame Material	Polymer
Stock Material	Beech Wood
Color	Wood
Overall Length	1290 mm (approx. 50.78 inches)
Weight	3600 g (approx. 7.93 lbs)
Energy Output	Up to 25 Joules
Mounting Rail	Integrated 11mm
UPC	193939069436

8. Warranty and Support

8.1 Warranty Information

The Lancer Tactical x SnowPeak GR1000W Air Gun comes with a **60 Days Warranty**. This warranty covers defects in manufacturing, materials, or workmanship.
To obtain warranty coverage, the warranty holder must:

1. Provide proof of original purchase.
2. Ensure the defective device is safely and securely packaged and shipped to the seller in accordance with instructions provided with the Return Merchandise Authorization (RMA) before the expiration of the warranty period.

The seller retains the sole authority to determine if a claim is covered by this limited warranty.
Exclusions: This warranty excludes batteries, chargers, and accessories. It does not cover damages caused by the user, including but not limited to: opening up the gearbox, normal wear and tear, disassembling the rifle or modifications, dropping or damage caused during play, and any attempted repairs made to the item. **Removing the orange tip WILL VOID your warranty.**

8.2 Customer Support

For technical assistance, warranty claims, or general inquiries, please contact the seller:

Seller: AirsoftMegaStore

For support, please refer to your purchase documentation or visit the seller's page on Amazon:AirsoftMegaStore on Amazon

© 2025 Lancer Tactical. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F7WV7SQ7

More documents and user manuals: **https://manuals.plus/**