

## TOSHIBA ER-S17ZB

# TOSHIBA Microwave Oven 17L ER-S17ZB Instruction Manual

MODEL: ER-S17ZB

Brand: TOSHIBA

### Introduction

This manual provides essential information for the safe and efficient operation of your TOSHIBA ER-S17ZB 17L single-function microwave oven. Please read it thoroughly before use and keep it for future reference.

This TOSHIBA microwave oven features a 1.5m power cord and a total capacity of 17L. Its annual power consumption for microwave functions is 59.9kWh/year, with 0.0kWh/year for standby. The timer limits are 3 minutes for 900W, 15 minutes for 600W/500W, and 30 minutes for 200W defrost. The 900W high-power output is a short-time function (maximum 1 minute 30 seconds); continuous rated high-frequency output is 600W, to which it automatically switches. Actual power consumption varies based on usage frequency, duration, food quantity, and ambient temperature.

### Key Features

- **900W High Power & Quick Reheat:** Equipped with inverter technology, this microwave offers 900W high power for rapid and even heating. It features 4 adjustable power levels: 900W, 600W, 500W, and 200W (defrost).
- **Flat Interior & Vertical Opening Design:** The spacious 17L flat interior (effective width 29.3cm) easily accommodates various dishes and lunch boxes. The flat design simplifies cleaning. The vertical opening door allows for convenient one-handed operation.
- **Stylish Design & Intuitive Buttons:** Features a minimalist button layout for straightforward operation. The refined white design seamlessly blends with any kitchen decor, offering a clean and modern aesthetic.
- **Easy-to-Read Backlit LCD & Interior Light:** The backlit LCD panel ensures clear visibility of settings, even in dimly lit environments. An LED interior light allows you to monitor food status during cooking.
- **Compact Design & Flexible Placement:** With dimensions of 45.8 cm (W) x 34.9 cm (D) x 28.1 cm (H) and a weight of approximately 10kg, its slim body fits well in smaller kitchens. The 1.5m long power cord provides greater flexibility for placement.



# 小さくてもパワフル出力

フラット庫内の縦開きモデル



簡単  
操作



17L  
大容量



ホワイトバ  
ックライト  
液晶



ホワイトLEDで  
明るく見やすい  
庫内



インバー  
ター技術



900Wの  
ハイパワー

Figure 1: Overview of the TOSHIBA ER-S17ZB microwave's key features.

# スムーズ開閉の縦開きデザイン

出し入れが便利で、調理がより快適に



Figure 2: The vertical opening door design for smooth and convenient access.

## Setup

1. **Unpacking:** Carefully remove the microwave oven from its packaging. Retain all packaging materials for potential future transport or service.
2. **Placement:** Place the microwave oven on a stable, flat, heat-resistant surface. Ensure adequate ventilation around the unit. Maintain a minimum clearance of 10 cm on the sides and back, and 30 cm above the oven. Do not block any ventilation openings.
3. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of the appliance.
4. **Initial Cleaning:** Before first use, wipe the interior and exterior surfaces with a soft, damp cloth.



Figure 3: Compact dimensions of the microwave for easy placement.

## Operating Instructions

### Basic Heating

1. Place food in a microwave-safe container inside the oven.
2. Close the door securely.
3. Select the desired power level (900W, 600W, 500W, or 200W).
4. Set the cooking time using the time buttons.
5. Press the 'Start' button to begin heating.

# 最大900W<sup>※1</sup>で、素早くあたため!

食材や料理に応じて、出力を4段階で切り替え可能



※1 定格高周波出力900Wは短時間高出力機能（最大1分30秒）であり、定格連続高周波出力は600Wです。600Wへは自動的に切り換わります。

Figure 4: The microwave in operation, showcasing its 900W high power for quick heating.

# 900W※のハイパワーで、すばやく加熱

調理に合わせた4段階出力



※定格高周波出力900Wは短時間高出力機能（最大1分30秒）であり、定格連続高周波出力は600Wです。600Wへは自動的に切り換わります。

Figure 5: Four power levels for various cooking needs.

# シンプル操作で、誰でも簡単

わかりやすいボタンで、使いやすい



Figure 6: Simple and intuitive control panel for easy operation.

## Defrosting

For defrosting, place the frozen food in the oven. Select the 200W power level and set the appropriate time. Monitor the food during defrosting to ensure even thawing and prevent cooking.

Video 1: Product demonstration showing basic operation and heating functions.

## Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your microwave oven.

- **Interior Cleaning:** The flat interior design makes cleaning easy. Wipe spills and food splatters immediately with a soft, damp cloth and mild detergent. Do not use abrasive cleaners or scouring pads.
- **Exterior Cleaning:** Clean the exterior surface with a soft, damp cloth. Avoid using harsh chemicals that may damage the finish.
- **Door Seal:** Regularly inspect and clean the door seal to ensure it is free from food debris, which could affect the seal and oven efficiency.

# 広々としたフラット庫内

お手入れ簡単で、大きなお弁当もラクラク



Figure 7: The flat interior design allows for easy cleaning.

## Troubleshooting

If you encounter any issues, please refer to the following common problems and solutions before contacting customer service.

- **Oven does not start:** Ensure the door is closed completely. If the door is not fully latched, the start button will not respond. Check if the power cord is securely plugged into the outlet.
- **Food is not heating:** Verify that the power level and cooking time are set correctly. Ensure the food is placed in a microwave-safe container.
- **Uneven heating:** Stir or rotate food halfway through cooking, especially for larger quantities, to ensure more even heating.
- **Unusual noise during operation:** This may be normal during microwave operation. If the noise is excessive or accompanied by other issues, discontinue use and consult the warranty information.

## Specifications

| Feature                        | Specification                                            |
|--------------------------------|----------------------------------------------------------|
| Brand                          | TOSHIBA                                                  |
| Model Number                   | ER-S17ZB(W)                                              |
| Product Dimensions (W x D x H) | 45.8 cm x 34.9 cm x 28.1 cm                              |
| Color                          | White                                                    |
| Capacity                       | 17 Liters                                                |
| Special Features               | Inverter Technology                                      |
| Wattage                        | 1350 W                                                   |
| Controller Type                | Button                                                   |
| Voltage                        | 100 V (AC)                                               |
| Number of Power Levels         | 4                                                        |
| Defrost System Type            | Defrost                                                  |
| Cooking Programs               | Defrost/Reheat, 900W Short-time Reheat, 900W, 600W, 500W |
| Frequency                      | 60 Hz                                                    |
| Material                       | Glass (door)                                             |
| Recommended Setting            | Home Use                                                 |
| Installation Method            | Countertop                                               |
| Included Components            | Instruction Manual                                       |

### Warranty and Support

Your TOSHIBA ER-S17ZB microwave oven comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or service inquiries, please refer to the contact information provided in the included instruction manual or visit the official TOSHIBA website.

Please retain your proof of purchase for warranty validation.