

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [luckystyle](#) /

> [luckystyle 100FT LED Outdoor String Lights S11 with Remote Control User Manual](#)

luckystyle S11

luckystyle 100FT LED Outdoor String Lights S11 User Manual

Model: S11 | Brand: luckystyle

1. INTRODUCTION

Thank you for choosing the luckystyle 100FT LED Outdoor String Lights. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new string lights. Designed for outdoor use, these lights feature shatterproof S11 LED bulbs, remote control dimming, and a waterproof construction, providing warm white 2700K illumination for various settings.

2. SAFETY INFORMATION

- **Power Source:** Ensure the power adapter is connected to a compatible power outlet. This product is corded electric and not solar-powered.
- **Low Voltage:** The lights operate at a safe 24V low voltage. The adapter includes overload and short-circuit protection.
- **Water Resistance:** The lights are IP65 waterproof. Ensure all connections are secure to maintain water resistance.
- **Bulb Handling:** While bulbs are shatterproof, avoid excessive force or intentional damage.
- **Installation:** Install lights securely to prevent falling or swaying in wind. Do not hang on power lines.
- **Temperature Range:** Suitable for temperatures between 14°F and 113°F (-10°C to 45°C).

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x 100FT LED Outdoor String Lights (with 35 S11 LED bulbs installed)
- 1 x Spare S11 LED Bulb
- 1 x Remote Control (requires 2 AAA batteries, included)
- 1 x Power Adapter (24V)



Image 1: Overview of the luckystyle 100FT LED Outdoor String Lights, including the string, remote, a spare bulb, and the power adapter.

4. SETUP AND INSTALLATION

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Plan Layout:** Determine the desired path for your string lights. Ensure the power adapter can reach a suitable outdoor power outlet. The string has a lead length of approximately 11 feet from the adapter to the first bulb.
3. **Mounting:** Use appropriate hooks, zip ties, or guide wires (not included) to securely hang the string lights. Each bulb socket has a small loop for easy hanging. Ensure the lights are not under excessive tension.
4. **Bulb Installation (if necessary):** The lights come with bulbs pre-installed. If a bulb needs replacement, gently screw in the S11 LED bulb into the E12 base until snug. Do not overtighten.
5. **Connect Power:** Plug the power adapter into a grounded outdoor electrical outlet.
6. **Remote Pairing (First-time Use):** For initial use, press and hold the remote's power button for 3-5 seconds within 30 seconds of connecting the power supply. This pairs the remote with the lights.

Detailed Parameters




Image 2: Diagram illustrating the string light dimensions, including the 11ft lead wire and 2.6ft spacing between bulbs, along with the power adapter.

5. OPERATING INSTRUCTIONS

The luckystyle string lights are controlled via the included remote. Ensure the remote has fresh AAA batteries installed.

Remote Control Functions:

- **ON/OFF:** Press the power button to turn the lights on or off.
- **Dimming:**
 - **Preset Levels:** Select 25%, 50%, 75%, or 100% brightness.
 - **Stepless Dimming:** Use the "+" and "-" buttons for fine-tuned brightness adjustment.
- **Lighting Modes:**
 - **Lighting:** Standard constant illumination.
 - **Breath:** Lights gently fade in and out.
 - **Flash:** Lights flash on and off.
- **Timer Function:**
 - **3H:** Lights will stay on for 3 hours and then automatically turn off.
 - **6H:** Lights will stay on for 6 hours and then automatically turn off.

Multi-Function Remote

Adjust lighting styles with ease.

Timing



Remote activation

Hold ON/OFF 3-5s within 30s of power-on to activate

Dimming



3 Modes



Image 3: The multi-function remote control, detailing buttons for timing (3H, 6H), dimming presets (25%, 50%, 75%, 100%), stepless dimming (+/-), and lighting modes (Lighting, Breath, Flash).



Image 4: Visual representation of the four preset brightness levels: 25%, 50%, 75%, and 100%.



Image 5: Examples of the three available lighting modes: Constant, Breathe, and Flicker, demonstrating their visual effects.

6. MAINTENANCE

- **Cleaning:** Disconnect power before cleaning. Wipe bulbs and wires with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Bulb Replacement:** If a bulb fails, replace it with an S11 LED bulb (E12 base). luckystyle offers a Lifetime Bulb Replacement Service. Contact customer support for assistance.
- **Storage:** If storing the lights for an extended period, clean them thoroughly, coil them neatly, and store in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically inspect the string for any damage to the wire, sockets, or bulbs. Discontinue use if damage is found and contact support.

IP65 Waterproof String Lights

Temp resistance: (14°F-113°F)

IP65 waterproof

Snowproof



Windproof



Sunproof



Shatterproof



Image 6: Illustration highlighting the IP65 waterproof rating and durability features, including snowproof, windproof, sunproof, and shatterproof design.

Problem	Possible Cause	Solution
Lights do not turn on.	No power to outlet. Adapter not properly connected. Remote not paired. Remote batteries depleted.	Check power outlet with another device. Ensure adapter is fully plugged in. Perform remote pairing procedure (hold power button 3-5s within 30s of power-on). Replace remote batteries (2 AAA).
Lights flicker or dim unexpectedly.	Loose bulb connection. Faulty bulb. Interference with remote signal.	Gently tighten all bulbs. Replace faulty bulb with the spare or contact support. Ensure clear line of sight between remote and receiver.
Remote control is unresponsive.	Depleted batteries. Remote not paired. Obstruction between remote and receiver.	Replace remote batteries (2 AAA). Perform remote pairing procedure. Remove any obstructions.

8. SPECIFICATIONS

Feature	Detail
Model Number	S11
Length	100 FT
Bulb Type	S11 LED (Shatterproof)
Number of Bulbs	35 + 1 Spare
Bulb Base	E12
Light Color	Warm White (2700K)
Voltage	24V Low Voltage
Power Source	Corded Electric
Control Method	Remote Control
Dimming Options	25%, 50%, 75%, 100% & Stepless
Lighting Modes	Constant, Breath, Flash
Timer Functions	3H, 6H
Water Resistance Level	IP65 Waterproof
Operating Temperature	14°F - 113°F (-10°C - 45°C)
Remote Batteries	2 AAA (included)

9. WARRANTY AND SUPPORT

luckystyle is committed to providing high-quality products and customer satisfaction. We offer:


- **Lifetime Support:** For any questions or issues regarding your product.
- **Lifetime Bulb Replacement Service:** Contact our customer service team for replacement bulbs if needed.

For assistance, please contact luckystyle customer service through the platform where you purchased the product or visit the official luckystyle store online.

© 2025 luckystyle. All rights reserved.



Related Documents - S11

 <p>USER'S GUIDE</p> <p>16" 16"</p> <p>Notes: 1. Please use the USB-C data cables provided in the device package. 2. The device supports up to 4K resolution and 60Hz refresh rate. 3. The device is not compatible with some third-party USB-C cables. 4. Compatible with Windows and Mac OS laptops.</p>	<p>S11 Portable Dual-Screen Laptop Monitor User Guide</p> <p>User guide for the S11 Portable Dual-Screen Laptop Monitor, detailing product introduction, connection methods, display settings, OSD settings, and FAQs. Compatible with Windows and macOS laptops.</p>
	<p>Tacx Boost Trainer Bundle: Getting Started and Assembly Guide</p> <p>A comprehensive guide for setting up and using the Tacx Boost Trainer Bundle, covering initial setup, assembly instructions, an explanation of virtual power, training options, and warranty information.</p>
	<p>S11 Bluetooth In-Car Speakerphone User Manual</p> <p>User manual for the S11 Bluetooth in-car speakerphone, covering features, setup, operation, specifications, and FCC warnings.</p>
	<p>Folding Drone with Obstacle Avoidance - Operating Manual & Features</p> <p>Comprehensive operating manual for the Folding Drone with Obstacle Avoidance. Learn about remote control functions, assembly, charging, flight preparation, and FCC compliance.</p>
	<p>Apple Find My Compatible Locator Manual</p> <p>A comprehensive manual for operating and setting up a locator device compatible with Apple Find My, covering setup, functions, notifications, and safety information.</p>



[S11 Wireless Car Charging Mount Instruction Manual](#)

User guide for the S11 Wireless Car Charging Mount by Shenzhen Nengxinda Technology Co., Ltd, detailing its features, construction, and usage instructions for Qi-compatible devices.