

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Okin](#) /

› [Okin 6 Button Adjustable Bed Wireless Remote and Control Box User Manual](#)

Okin RC.10.20.02

Okin 6 Button Adjustable Bed Wireless Remote and Control Box User Manual

Model: RC.10.20.02



INTRODUCTION

This manual provides instructions for the Okin 6 Button Adjustable Bed Wireless Remote (RF.23.06.02) and Control Box (CB.10.20.01) replacement parts. It covers setup, operation, maintenance, and troubleshooting to ensure proper functionality and compatibility with your adjustable bed system.

INCLUDED COMPONENTS

- Okin 6 Button Wireless Remote (RF.23.06.02)
- Okin Control Box (CB.10.20.01)



Image: The Okin 6-button wireless remote control and the associated control box with its power cable. The remote features buttons for head up, head down, foot up, foot down, and a flat position. The control box has the Okin logo visible.

SETUP AND PAIRING

Follow these steps to pair your Okin wireless remote with the control box:

1. **Step 1:** Double-click the pairing button on the control box. The control box indicator green light will turn on, indicating it has entered pairing mode.
2. **Step 2:** On the remote, press and hold both the **HEAD UP** and **HEAD DOWN** buttons simultaneously. Continue holding until the control box indicator light goes out. This signifies that the pairing process is complete.

Important Compatibility Note: Ensure your bed does not have a massage function if using this remote, as it is not designed for massage functions. Also, verify that the control box's 5-pin lift motor connector matches your motor's connector type.

OPERATING INSTRUCTIONS

The Okin 6-button wireless remote provides intuitive control over your adjustable bed's positions.

- **Head Up/Down:** Use the arrow buttons with the head icon to raise or lower the head section of the bed.
- **Foot Up/Down:** Use the arrow buttons with the foot icon to raise or lower the foot section of the bed.
- **Flat:** Press the "FLAT" button to return the bed to a completely flat position.

Dual-Bed Synchronization: For controlling two adjustable beds simultaneously, use the master pairing function to connect to the first control box. Subsequently, use the slave function for the second control box. After both pairings are established, you can control both beds with a single remote.

Version and Button Matching: It is crucial to verify that the remote buttons match the product specifications. Mismatched buttons can lead to incompatibility, as different remote versions may have varying functions.

MAINTENANCE

Battery Replacement

The adjustable bed wireless remote requires **2 x AAA batteries** for operation. Batteries are sold separately and are not included with the remote. Replace batteries when the remote's performance diminishes or it stops responding.

1. Locate the battery compartment on the back of the remote.
2. Slide open the battery cover.
3. Remove the old batteries.
4. Insert two new AAA batteries, ensuring correct polarity (+/-).
5. Close the battery cover securely.

TROUBLESHOOTING

If you encounter issues with your Okin wireless remote and control box, consider the following:

- **Remote Not Responding:**
 - Check if the batteries are correctly inserted and have sufficient charge. Replace them if necessary.
 - Ensure the remote is properly paired with the control box. Refer to the "Setup and Pairing" section for re-pairing instructions.
- **Incompatibility Issues:**
 - Verify that the remote buttons and functions match your bed's original remote or specifications. Mismatched

versions can cause functionality problems.

- Confirm that the control box's 5-pin lift motor connector is compatible with your bed's motor.
- If your bed has a massage function, this remote and control box may not be compatible as they do not support massage features.

- **Bundle Advantage:** Purchasing the remote and receiver/control box together is recommended to avoid chip incompatibility issues that can arise from separately produced units.
- **Pre-Purchase Checks:** Before purchasing, always confirm part numbers, motor connectors, and whether your bed includes a massage function to ensure compatibility.

SPECIFICATIONS

Feature	Detail
Brand	Okin
Model Name	RC.10.20.02
Item Model Number	RF.23.06.02 (Remote), CB.10.20.01 (Control Box)
Color	Black
Item Weight	1.21 pounds (approx.)
Package Dimensions	12.99 x 12 x 7.09 inches
Battery Requirement	2 x AAA batteries (sold separately)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the original product packaging or contact the manufacturer directly. Keep your purchase receipt for warranty claims.

You can visit the official Okin store on Amazon for more products and support:[Okin Store](#)