

[Manuals.plus](#) /

› [Dinsoo](#) /

› Dinsoo RGB Wireless Controller (Model 08-03-461) User Manual

Dinsoo 08-03-461

Dinsoo RGB Wireless Controller User Manual


Model: 08-03-461

INTRODUCTION

This manual provides instructions for setting up, operating, and maintaining your Dinsoo RGB Wireless Controller. This controller is compatible with PlayStation 5, PlayStation 4, PC, iOS, and Android devices, offering a versatile gaming experience.

Controller connection to PS5 step by step, slide to the end to see the video tutorial!

1. Any problems encountered can be resolved by re-inserting the USB adapter and pairing it with the controller.
2. The controller uses cable to connect to the PS5 for charging or to connect to the PS5, it is necessary to re-pair the USB adapter with the controller after re-inserting it into the PS5 host for the controller to work properly.



Front view of the Dinosoo RGB Wireless Controller, showcasing its design and illuminated buttons.

SETUP AND CONNECTION

Connecting to PlayStation 5 (PS5)

For proper functionality with PS5, specific system settings are required. A wired connection is necessary for the initial setup.

1. Navigate to your PS5 system settings.
2. Select **Accessories**.
3. Choose **Controller (General)**.
4. Select **Communication Method**.
5. Change the setting to **Use USB Cable**.

Important Note for PS5 Users:

- If you encounter connection issues, re-insert the USB adapter and re-pair it with the controller.
- If using the console to charge the controller, the controller needs to be re-paired with the receiver after charging.
- This controller may primarily support PS4 games when played on a PS5 console. For PS5-specific games, an official PS5 controller may be required.



Visual guide for connecting the controller to a PS5, showing adapter insertion and pairing steps.

Your browser does not support the video tag.

Video tutorial demonstrating the steps to connect the Dinosoo controller to a PS5 console using the 2.4G adapter.

Connecting to Other Platforms

- **PlayStation 4 (PS4):** Connect wirelessly via Bluetooth or using the provided USB cable.
- **PC (Windows):** Connect via the 2.4G adapter for wireless play or directly via USB cable for wired connection.
- **iOS/Android:** Connect wirelessly via Bluetooth. Refer to your device's Bluetooth pairing instructions.

OPERATING FEATURES

Controller Layout



Detailed diagram illustrating the various buttons, sticks, touchpad, and ports on the Dinosoo controller.

Adjustable RGB Lighting

The controller features seven adjustable RGB lighting modes. These can be changed to suit user preference.

Customized Lighting

Different colors LED for better playing experience



The controller displaying its customizable RGB lighting feature.

Multi-Function Capabilities

- **Dual Vibration Motors:** Provides tactile feedback for immersive gameplay.
- **Touchpad:** Integrated touchpad for additional control options.
- **Integrated Light Bar:** Visual indicator for various in-game actions or controller status.
- **Speakers:** Built-in speaker for enhanced audio cues.
- **3.5mm Stereo Headphone Jack:** Allows connection of headphones for private audio.
- **Share Button:** Enables quick sharing of gameplay moments.

6-Axis Gyro Sensor



Dual Motor



3.5mm Headphone Jack



Visual representation of the 6-Axis Gyro Sensor, Dual Motors, and 3.5mm Headphone Jack.

Six-Axis Sensors and Turbo Function

- **Six-Axis Sensors:** Provides motion sensing for stability and directional input, aiding in quick reactions during gameplay.
- **Turbo Function:** Activates rapid fire for designated buttons, useful in certain game genres.

TURBO

Switch to turbo mode
for faster rapid fire



Illustration of the Turbo function and its activation method.

On-the-Fly Mapping

The controller supports on-the-fly button mapping without requiring additional software, allowing for quick customization of controls.



Diagram explaining the on-the-fly mapping feature for controller buttons.

Hall Linear Triggers

The trigger buttons incorporate Hall Linear technology, providing precise and responsive input. They also include vibration motors for enhanced tactile feedback during gameplay.

Hall Linear Trigger

Trigger buttons add vibration motors to make weapons, impacts and vibrations a realistic experience



Close-up view highlighting the Hall Linear Trigger mechanism.

MAINTENANCE

Charging the Controller

The controller is powered by a built-in battery. Connect the controller to a power source using the provided USB Type-C charging cable. The integrated light bar may indicate charging status.

Cleaning

Use a soft, dry cloth to clean the controller's surface. Avoid using harsh chemicals or abrasive materials, as these can damage the finish and internal components.

TROUBLESHOOTING

- **Controller not connecting to PS5:** Ensure the PS5 communication method is set to "Use USB Cable" in system settings (Accessories > Controller (General) > Communication Method). Re-insert the 2.4G adapter and re-pair the controller if issues persist.
- **Controller not working with PS5 games:** This controller may function primarily with PS4 games when played on a PS5 console. For full compatibility with PS5-specific titles, an official PS5 controller might be necessary.
- **Connection drops frequently:** Ensure the 2.4G adapter is securely plugged into the console. Try moving closer to the console to minimize interference. Re-pair the controller if necessary.
- **Buttons unresponsive:** Ensure the controller is fully charged. If the issue persists, try resetting the controller (refer to the controller layout for a potential reset button location, usually a small pinhole).
- **RGB lights not working:** Check if the controller is powered on and charged. Refer to the operating instructions for how to cycle through RGB light modes.

SPECIFICATIONS

Brand	Dinosoo
Model Number	08-03-461

Compatible Devices	PlayStation 5, PlayStation 4, PC, iOS, Android
Controller Type	Wireless
Connectivity Technology	Wireless (2.4G adapter, Bluetooth), Wired (USB)
Button Quantity	21
Power Source	Battery Powered
Color	Black

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Dinosoo customer service through their official channels. Keep your purchase receipt for warranty claims.

© 2024 Dinosoo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F7XQW416>

More documents and user manuals: <https://manuals.plus/>