

AlfaBot N3

AlfaBot Soy Milk Maker N3 Instruction Manual

Model: N3

1. INTRODUCTION

Thank you for purchasing the AlfaBot Soy Milk Maker N3. This versatile appliance is designed to simplify your healthy lifestyle by allowing you to prepare fresh soy milk, soups, juices, porridges, and fermented foods with ease. Featuring an 800ml capacity, a 12-hour reservation function, and automatic cleaning, this machine offers convenience and efficiency. Please read this manual thoroughly before use to ensure safe and optimal operation.

2. SAFETY PRECAUTIONS

- Always connect the appliance to a grounded 3-pin power outlet. Ensure your home's electrical outlets are compatible with a 3-pin plug before first use.
- Do not immerse the main unit, power cord, or plug in water or other liquids.
- Keep the appliance away from children and pets.
- Do not operate the appliance if the power cord or plug is damaged.
- The appliance is equipped with safety features such as overheat protection and an automatic stop function when the lid is opened. Do not attempt to bypass these safety mechanisms.
- Ensure the lid is securely closed before operating.
- Use only the accessories provided or recommended by AlfaBot.
- Unplug the appliance from the power outlet when not in use, before cleaning, and before assembling or disassembling parts.
- The operating noise level is approximately 65 decibels, which is quieter than traditional soy milk makers. However, avoid operating it in quiet environments during late hours if noise is a concern.

3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- Soy Milk Maker Main Unit (x1)
- Power Plug (x1)

- Dedicated Cleaning Brush (x1)
- Measuring Spoon (30ml) (x1)
- Filter Jug (x1)
- Filter Bags (x2)
- Instruction Manual (x1)
- Recipe Collection (x1)

パッケージ内容



- ① 豆乳メーカー 本体 x1
- ② プラグ x1
- ③ 専用クリーニングブラシ x1
- ④ 計量スプーン (30ml) x1
- ⑤ フィルター付きじょうご x1
- ⑥ フィルターバッグ x2
- ⑦ 取扱説明書 x1
- ⑧ レシピ集 x1

Image: All components included in the AlfaBot Soy Milk Maker N3 package, including the main unit, power cord, cleaning brush, measuring spoon, filter jug, filter bags, instruction manual, and recipe book.

4. PRODUCT OVERVIEW

The AlfaBot Soy Milk Maker N3 features a compact design with an integrated heating element and powerful blending blades. The main unit houses the motor and control panel, while the transparent pitcher allows you to monitor the process. The 8-blade stainless steel cross-blade ensures efficient and smooth blending.

8枚ステンレス刃

超強力撹拌でなめらか実現



四面防はねコラム

カットのムラ低減・
きめ細かく

Image: Close-up view of the AlfaBot Soy Milk Maker N3's 8-blade stainless steel cross-blade, designed for powerful and smooth blending.

簡単3ステップ操作



STEP 1 大豆と水を入れる



STEP 2 本体蓋と防音カバーを閉める



STEP 3 お好みのメニューを選択

Image: Diagram highlighting key features of the AlfaBot Soy Milk Maker N3, including food-grade stainless steel, mirror-finish for easy cleaning, and sound insulation enclosure.

5. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, clean the pitcher and lid with warm soapy water. Rinse thoroughly and dry. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the soy milk maker on a stable, flat, and dry surface, away from heat sources and direct sunlight.
4. **Power Connection:** Ensure the appliance is unplugged. Place the pitcher onto the main unit, then securely attach the lid. Plug the 3-pin power cord into a compatible grounded electrical outlet.



Image: A visual guide demonstrating the three simple steps for operating the AlfaBot Soy Milk Maker N3: 1. Add ingredients and water, 2. Secure the lid and soundproof cover, 3. Select your desired menu.

6. OPERATING INSTRUCTIONS

6.1 Basic Operation

1. Add your desired ingredients and water into the pitcher. Ensure the water level is between the MIN and MAX marks.
2. Securely close the lid.
3. Plug in the appliance. The control panel will illuminate.
4. Select your desired function by pressing the corresponding button on the control panel.
5. The appliance will begin processing. Once complete, it will usually beep and enter a keep-warm or standby mode.

6.2 Available Modes

The AlfaBot Soy Milk Maker N3 offers multiple automatic cooking modes:

- **Soy Milk:** For preparing fresh, creamy soy milk from dried soybeans. The unique mode ensures a rich flavor without the need for straining.
- **Porridge:** Ideal for making various types of porridge, including grain porridge.
- **Juice:** Blends fruits and vegetables into smooth juices.
- **Soup:** Prepares hot soups with blended ingredients.
- **Tea:** For brewing various types of tea.

- **Fermentation:** Suitable for making fermented foods.
- **Baby Food:** Creates smooth and nutritious baby food.



Image: The AlfaBot Soy Milk Maker N3 displaying its multi-functional capabilities, including modes for soy milk, porridge, juice, pumpkin paste, yogurt, and tea.

6.3 12-Hour Reservation Function

The reservation function allows you to set a delayed start time for up to 12 hours. This is convenient for preparing ingredients the night before and waking up to a freshly made beverage or meal.

1. Add ingredients and water to the pitcher.
2. Close the lid and plug in the appliance.
3. Press the 'Reservation' button and use the adjustment buttons to set the desired delay time.
4. Select your desired cooking mode. The appliance will start automatically after the set delay time.

予約機能 最大12時間

朝の一杯をお楽しみください



20:00

寝る前に材料を入れて



08:00

起きたら美味しい飲み物の
できあがり



Image: A split image illustrating the 12-hour reservation function of the AlfaBot Soy Milk Maker N3. Ingredients are added at 8:00 PM for a fresh drink ready by 8:00 AM.

7. CLEANING AND MAINTENANCE

Regular cleaning ensures hygiene and extends the lifespan of your appliance.

7.1 Automatic Cleaning

The AlfaBot Soy Milk Maker N3 features an automatic high-temperature cleaning mode:

1. After use, remove any large food residues.
2. Add a small amount of water (up to the MIN line) and a drop of dish soap to the pitcher.
3. Close the lid and select the 'Cleaning' mode on the control panel.
4. The appliance will perform a high-temperature wash cycle to break down residue and odors.
5. Once the cycle is complete, unplug the appliance, discard the water, and rinse the pitcher thoroughly.

ワンタッチ 自動洗浄

内蔵洗浄機能
手ぶらでOK



Image: The AlfaBot Soy Milk Maker N3 demonstrating its one-touch automatic cleaning function, with water swirling inside the pitcher.

7.2 Manual Cleaning

- Always unplug the appliance before cleaning.
- The pitcher and lid are hand-washable. Use the provided cleaning brush to reach all areas, especially around the blades.
- The interior of the pitcher has a mirror finish, making it easy to wipe clean.
- Do not use abrasive cleaners or scouring pads, as they may damage the surface.
- Wipe the exterior of the main unit with a soft, damp cloth. Never immerse the main unit in water.
- The appliance is not dishwasher safe.

8. TROUBLESHOOTING

If you encounter any issues with your AlfaBot Soy Milk Maker N3, please refer to the following common troubleshooting steps. For more detailed information, consult the comprehensive troubleshooting section in the included instruction manual.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly; power outage; lid not properly closed.	Ensure the 3-pin plug is fully inserted into a working, grounded outlet. Check your home's power supply. Ensure the lid is securely fastened.
Unusual noise during operation.	Too many ingredients; appliance not on a stable surface; foreign object inside.	Do not exceed the MAX fill line. Place the appliance on a flat, stable surface. Unplug and check for any foreign objects.
Ingredients not blended smoothly.	Insufficient water; too many hard ingredients; blades are dull.	Ensure adequate water level. Reduce the amount of hard ingredients. If blades are dull, contact customer support.
Overflow during operation.	Overfilling the pitcher.	Do not fill above the MAX line. Ensure the lid is properly sealed.

9. SPECIFICATIONS

Feature	Specification
Brand	AlfaBot
Model Number	N3
Color	White
Product Dimensions (D x W x H)	8 x 8 x 22.6 cm
Wattage	500 W
Power Source	Corded Electric
Material	Stainless Steel
Blade Material	Stainless Steel
Special Features	Built-in grinder, Safety lock, Automatic shut-off
Recommended Uses	Chopping, Liquefying, Mixing, Fine grinding
Care Instructions	Hand Wash
Dishwasher Safe	No
Country of Origin	China

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included in your package or contact AlfaBot customer service directly. Details for contacting support can typically be found on the manufacturer's official website or in the full instruction manual provided with the product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question