

VirtuFit Kayak 335

VirtuFit Kayak 335 Inflatable Instruction Manual

Model: Kayak 335 (VF06139-SET1)

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use, setup, operation, and maintenance of your VirtuFit Kayak 335 Inflatable. This versatile kayak is designed for recreational use on various water bodies, including lakes, rivers, and coastal seas. It accommodates two people with an option for a third seat, offering flexibility for solo, tandem, or small group adventures.

2. SAFETY INFORMATION

- Always wear a U.S. Coast Guard approved personal flotation device (PFD) when using the kayak.
- Do not exceed the maximum weight capacity of the kayak. Refer to the Specifications section for details.
- Never use the kayak under the influence of alcohol or drugs.
- Be aware of weather conditions and water currents. Avoid kayaking in adverse weather or strong currents.
- Inform someone of your float plan, including your destination and estimated return time.
- Inspect the kayak and all accessories for damage before each use. Do not use if damaged.
- Ensure all air chambers are properly inflated to the recommended pressure.
- Keep sharp objects away from the kayak's surface.
- Children should always be supervised by an adult.

3. PACKAGE CONTENTS

The VirtuFit Kayak 335 package includes the following items:

- 1 x VirtuFit Kayak 335 Inflatable Kayak

- 2 x Kayak Seats (adjustable)
- 2 x Aluminum Paddles (4-piece, adjustable from 175-220 cm)
- 2 x Slide-in Fins
- 1 x Carry Bag
- 1 x Repair Kit



Image: Top-down view of the VirtuFit Kayak 335, showing its overall shape and seat positions.

4. SETUP INSTRUCTIONS

4.1 Unpacking and Preparation

1. Unpack the kayak and all accessories from the carry bag.
2. Lay the kayak flat on a clean, smooth surface to avoid punctures.

4.2 Inflation

The kayak features three Boston valves for quick inflation and deflation.

1. Locate the three Boston valves on the kayak.
2. Open the outer cap of each valve.
3. Attach a suitable air pump (not included) to the valve. Ensure the one-way inflation diaphragm is in place to prevent air loss.
4. Inflate each air chamber until it is firm to the touch, but not over-inflated. Refer to the recommended pressure in the Specifications section.
5. Once inflated, quickly close the inner cap, then the outer cap, ensuring a tight seal.



Image: Close-up of the kayak's bow, showing the VirtuFit logo and an inflation valve.

4.3 Seat Installation

The kayak is designed for two people, with an option for a third seat in the middle.

1. Position the seats inside the kayak. The kayak has attachment points (D-rings or straps) for securing the seats.
2. Attach the seat straps to the corresponding attachment points on the kayak.
3. Adjust the straps to achieve a comfortable and secure seating position.



Image: Close-up of an installed kayak seat, showing its design and attachment points.



Image: Detailed view of a single kayak seat, highlighting its ergonomic design.

4.4 Fin Installation

The two slide-in fins enhance tracking and stability.

1. Turn the kayak upside down.
2. Slide each fin into its designated slot on the bottom of the kayak until it clicks securely into place.

4.5 Paddle Assembly

The paddles are 4-piece and adjustable.

1. Connect the four sections of each paddle. Ensure the push-button connectors snap securely.
2. Adjust the paddle length by twisting and locking the adjustable sections. The length can be set between 175 cm and 220 cm.
3. Paddles can also be assembled as a single-blade paddle for alternative use.

5. OPERATING INSTRUCTIONS

5.1 Launching the Kayak

1. Carry the inflated kayak to the water's edge. The kayak weighs approximately 19 kg, making it manageable for two people.
2. Gently place the kayak into the water, ensuring it floats freely.
3. Carefully board the kayak, maintaining balance.



Image: Two individuals carrying the VirtuFit Kayak 335 on a sandy beach towards the water.

5.2 Paddling Techniques

- Hold the paddle with both hands, slightly wider than shoulder-width apart.
- For forward motion, immerse the paddle blade fully into the water near your feet and pull it towards your hip. Alternate sides.
- To turn, paddle on one side only, or use a sweep stroke (a wide arc from front to back) on the desired turning side.
- The kayak's double-layer construction and reinforced bottom provide stability and protection against minor

abrasions.



Image: An aerial view showing two people paddling the VirtuFit Kayak 335 in calm, clear blue water.



Image: A perspective from inside the kayak, showing two individuals paddling on open water.



Image: An aerial shot of a person relaxing comfortably in the VirtuFit Kayak 335 on calm water.

5.3 Landing the Kayak

1. Approach the shore slowly.
2. Once in shallow water, carefully exit the kayak.
3. Lift the kayak out of the water and place it on a clean, dry surface.

6. MAINTENANCE

6.1 Cleaning

- After each use, rinse the kayak thoroughly with fresh water to remove salt, sand, and dirt.
- Use a mild soap and soft brush if necessary.
- Ensure the kayak is completely dry before deflating and storing to prevent mold and mildew.

6.2 Storage

- Deflate the kayak by opening both caps of the Boston valves.
- Fold the kayak neatly and place it in the provided carry bag.
- Store the kayak in a cool, dry place, away from direct sunlight and extreme temperatures.
- Avoid storing heavy objects on top of the folded kayak.

6.3 Repairs

- The included repair kit can be used for minor punctures.
- For larger damage or if unsure, consult a professional repair service.
- Always ensure the repair area is clean and dry before applying patches.

7. TROUBLESHOOTING

- **Kayak losing air:** Check all valve caps are securely closed. Inspect the kayak surface for punctures or leaks. Use soapy water to identify small leaks.
- **Difficulty tracking straight:** Ensure both slide-in fins are properly installed and securely in place. Check that the kayak is evenly inflated.
- **Seats uncomfortable or unstable:** Adjust the seat straps to find a more secure and comfortable position. Ensure the seats are properly attached to the D-rings.

8. SPECIFICATIONS

Feature	Detail
Brand	VirtuFit
Model Name	Kayak 335
Model Number	VF06139-SET1

Material	Plastic and Polyester (Double-layer construction with reinforced bottom)
Color	Black / Blue
Item Weight	19 Kilograms
Dimensions (L x W x H)	3.65L x 1.01W x 0.17H meters
Seating Capacity	2 (with option for 3rd seat)
Paddle Length Adjustment	175 cm - 220 cm
Valve Type	Boston Valves (3)
Recommended Water Types	Lakes, Rivers, Coastal Seas (Freshwater and Saltwater)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the VirtuFit official website or contact your retailer. Keep your proof of purchase for any warranty claims.

© 2024 VirtuFit. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

