

[Manuals.plus](#) /

> [Northpoint](#) /

> Northpoint LED Rechargeable Lounge Lights (NP-ALL-Lounge-Parent) - Instruction Manual

## Northpoint NP-ALL-Lounge-Parent

# Northpoint LED Rechargeable Lounge Lights - Instruction Manual

## INTRODUCTION

---

The Northpoint LED rechargeable lounge lights are designed to provide versatile accent and mood lighting for both indoor and outdoor environments. This set includes four individual lights with touch sensor controls, offering warm white, color-changing, and candle flicker functions. They are powered by an integrated rechargeable battery and come with a convenient charging station, allowing for flexible placement and extended use.



This image shows the four Northpoint LED lounge lights illuminated, creating a warm ambiance on a wooden table, suitable for outdoor settings.

## PACKAGE CONTENTS

---

Please check the package contents carefully to ensure all items are present:

- 4 x Northpoint LED Rechargeable Lounge Lights
- 1 x Charging Station
- 1 x USB Cable
- 1 x USB Power Adapter



A detailed graphic outlining the dimensions of the lounge lights (approx. 5cm x 7cm) and the charging station (approx. 25.2cm length, 2.2cm height), along with the included 50 cm USB-C cable.

## IMPORTANT SAFETY INSTRUCTIONS

---

To ensure safe operation and prevent damage, please read and follow these safety guidelines:

- Read all instructions thoroughly before using the product.

- Keep the lights and charging station away from direct water exposure. While suitable for outdoor use (IP44 splash-proof), do not immerse them in water.
- Do not attempt to open, modify, or repair the lights or charging station. Refer all servicing to qualified personnel.
- Use only the provided charging station, USB cable, and USB power adapter. Using unauthorized accessories may cause damage or safety hazards.
- Ensure the charging station is placed on a stable, dry, and level surface during charging.
- Keep the product out of reach of children and pets.
- Do not expose the lights to extreme temperatures, direct sunlight for prolonged periods, or open flames.

## SETUP

---

### Initial Charging

Before first use, fully charge all lounge lights:

1. Unpack all components from the packaging.
2. Connect the USB cable to the charging station, then plug the USB power adapter into a standard wall outlet.
3. Place each lounge light onto the charging station. Ensure they are correctly seated in their respective slots. Indicator lights on the charging station will illuminate to show the charging status.
4. Allow approximately 5-7 hours for a full charge.



The image displays the four lounge lights placed on their white charging station. Some lights are illuminated, while others show charging indicator lights, demonstrating the simultaneous charging capability.

### Placement

The lounge lights are wireless and can be placed freely. Choose a stable, flat surface for optimal performance and stability, whether indoors or outdoors.

## OPERATING INSTRUCTIONS

---

### Power On/Off and Mode Selection

Each lounge light features a built-in touch sensor at its base for control:



This close-up image highlights the touch sensor located at the base of the lounge light, which is used to control the lighting modes.

1. **To Turn On:** Gently tap the touch sensor at the base of the light.
2. **To Change Mode:** Tap the touch sensor repeatedly to cycle through the available lighting modes:
  - Warm White Light
  - Color Changing Mode (RGBW)
  - Candle Flicker Effect
  - Color Fix Mode (tap during color changing to hold a specific color)
3. **To Turn Off:** Continue tapping through the modes until the light switches off, or press and hold the touch sensor for a few seconds.

### **Battery Life**

A fully charged light provides up to 22 hours of operation in flicker mode. Operating time may vary depending on the selected lighting mode and brightness.



This image illustrates the compact dimensions of the lounge lights, measuring 5 cm in width and 7 cm in height. It also demonstrates the color-changing capabilities, showing blue, purple, and warm white light options.

## MAINTENANCE

Proper care and maintenance will extend the lifespan of your lounge lights:

- **Cleaning:** Wipe the lights and charging station with a soft, slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Storage:** When not in use for extended periods, store the lights and charging station in a cool, dry place. Ensure the lights are fully charged before storage to help maintain battery health.
- **Battery Care:** To prolong battery life, recharge the lights regularly, even if they have not been used frequently. Avoid completely draining the battery before recharging.

## TROUBLESHOOTING

If you encounter any issues with your Northpoint LED lounge lights, please refer to the following table:

Problem	Possible Cause	Solution
Light does not turn on	Battery is depleted	Place the light on the charging station and allow it to fully charge (approx. 5-7 hours).

Problem	Possible Cause	Solution
Light does not charge	Improper connection or faulty power source	Ensure the USB cable is securely connected to both the charging station and the USB power adapter. Verify the power adapter is plugged into a working wall outlet. Ensure the light is correctly seated on the charging station.
Light modes do not change	Touch sensor issue or light is off	Ensure the touch sensor area at the base of the light is clean and dry. Try tapping firmly. If the light is off, tap once to turn it on before cycling modes.
Short operating time	Battery not fully charged or aging battery	Ensure a full 5-7 hour charge. Battery capacity naturally decreases over time with repeated charge cycles.

## SPECIFICATIONS

Feature	Detail
Model Number	NP-ALL-Lounge-Parent
Dimensions (each light)	5 cm (Diameter) x 7 cm (Height)
Charging Station Dimensions	Approx. 25.2 cm (Length) x 2.2 cm (Height)
Material	Plastic (Base), Plastic or Acrylic (Lampshade)
Light Source	LED (54SMD)
Power Source	Rechargeable Battery
Charging Time	Approx. 5-7 hours
Operating Time (Flicker Mode)	Up to 22 hours
Functions	Warm White, RGBW Color Changing, Candle Flicker Effect, Color Fix
Control	Touch Sensor
Usage	Indoor and Outdoor
Water Resistance	IP44 (Splash-proof)
Number of Lights	4

## WARRANTY AND SUPPORT

For warranty information, technical support, or any questions regarding your Northpoint LED Rechargeable Lounge Lights, please refer to your purchase documentation or contact Northpoint customer service directly. Keep your proof of purchase for warranty claims.