

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Ceybo](#) /

› [Ceybo Original Solar Voice Remote Control \(Model BN59-01480A\) User Manual](#)

Ceybo BN59-01480A

Ceybo Original Solar Voice Remote Control User Manual

MODEL: BN59-01480A

Introduction

Thank you for choosing the Ceybo Original Solar Voice Remote Control. This remote is designed to provide seamless control over your compatible Samsung Smart TV, featuring convenient solar charging, voice command capabilities, and dedicated shortcut buttons for popular streaming services. This manual will guide you through the setup, operation, and maintenance of your new remote control.



Image: Front and back view of the Ceybo Solar Voice Remote Control, showcasing its sleek design and solar charging panel on the rear.

Setup

1. Charging the Remote

Your Ceybo remote control features an eco-friendly solar charging panel and a USB-C port for convenient

power options.

- **Solar Charging:** Place the remote control with its solar panel facing a light source (natural sunlight or indoor lighting) to charge the internal battery. For optimal charging, ensure the panel is exposed to light regularly.
- **USB-C Charging:** For faster charging or when light is insufficient, connect a USB-C cable (not included) to the remote's USB-C port and a power adapter.



Image: The Ceybo remote control positioned to receive sunlight, illustrating its solar charging capability.

2. Pairing with Your Samsung Smart TV

The Ceybo remote uses Bluetooth for connection. Follow these steps to pair it with your TV:

1. Ensure your TV is powered on.
2. Point the remote towards your TV.
3. Simultaneously press and hold the **Return** button (curved arrow) and the **Play/Pause** button for 3 seconds or more.
4. A red light on the remote will start blinking, indicating it is in pairing mode.
5. A prompt will appear on your TV screen confirming that the remote is paired.

Easy to pair

Simply hold the back button and play pause for a few seconds



Image: The Ceybo remote control with a visual guide indicating the Return and Play/Pause buttons for pairing, and a text overlay explaining the pairing process.

Operating the Remote

Basic Functions

- **Power Button:** Located at the top right, press to turn the TV on or off.
- **Volume Buttons (+/-):** Adjust the TV's volume.
- **Channel Buttons (Up/Down):** Change TV channels.
- **Directional Pad (Circular):** Navigate menus and select items.
- **Home Button:** Return to the TV's home screen.
- **Return Button:** Go back to the previous screen or menu.
- **Play/Pause Button:** Control media playback.

Voice Control

Utilize the built-in voice assistant for hands-free control:

1. Press the **Microphone** button (located near the top, with a microphone icon).

2. Speak your command clearly, such as "Open Netflix," "Change to Channel 5," or "Increase volume."
3. The TV will respond to your voice command.

Accessibility through Voice Commands

Press the Microphone button and simply say
"Open Netflix"



Image: The Ceybo remote control with a magnified view of the microphone button, illustrating its use for voice commands.

Shortcut Buttons

Access your favorite streaming services instantly with dedicated shortcut buttons:

- Press the **Netflix** button to launch Netflix.
- Press the **Prime Video** button to launch Amazon Prime Video.
- Press the **YouTube** button to launch YouTube.
- Press the **Samsung TV Plus** button to access Samsung's free streaming service.

Your favorite apps at the push of a button



Quick access to apps you love like Netflix, Prime Video, and More!

Image: The Ceybo remote control with a magnified view of the dedicated shortcut buttons for Netflix, Prime Video, YouTube, and Samsung TV Plus.

AI Button

Some Samsung Smart TVs feature AI capabilities. If your TV supports it, press the **AI button** (often depicted with a sparkle or star icon) to access AI features such as live translation or intelligent recommendations.

The Power of AI at your finger tips

by pressing the AI button, you can access all AI features like live translation.



Image: The Ceybo remote control with a magnified view of the AI button, indicating its function for accessing artificial intelligence features.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials.
- **Solar Panel Care:** Keep the solar panel clean and free from obstructions to ensure efficient charging. Regularly expose the remote to light.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight for prolonged periods if not in use, but ensure it receives light periodically to maintain charge.

Troubleshooting

- **Remote not responding:**
 - Ensure the remote is charged. Try charging via USB-C or exposing it to bright light.
 - Re-pair the remote with your TV by holding the Return and Play/Pause buttons simultaneously for 3 seconds.

- Check for any obstructions between the remote and the TV.
- **Voice control not working:**
 - Ensure the remote is properly paired.
 - Speak clearly and directly into the microphone.
 - Check your TV's settings to ensure voice control is enabled.

- **Shortcut buttons not launching apps:**

- Ensure your TV is connected to the internet.
- Verify that the respective apps are installed and updated on your TV.

Specifications

Feature	Detail
Model Number	BN59-01480A
Power Source	Solar Charging, USB-C
Connectivity	Bluetooth
Special Features	Voice Search, Dedicated Shortcut Buttons (Netflix, Prime Video, YouTube, Samsung TV Plus), AI Button
Compatible Devices	Samsung Smart Televisions
Color	Black
Item Weight	3.2 ounces
Package Dimensions	5.55 x 1.97 x 0.55 inches


Compatibility

This Ceybo Solar Voice Remote Control (Model BN59-01480A) is compatible with a wide range of Samsung Smart TVs, including:

- Neo QLED 8K Series
- QLED Series
- Specific models include: QN42S90FAFXZA, QN43Q7FAAFXZA, QN43QN90FAFXZA, QN48S90FAFXZA, QN50Q7FAAFXZA, QN50QN90FAFXZA, QN55Q7FAAFXZA, QN55QN70FAFXZA, QN55QN80FAFXZA, QN55QN90FAFXZA, QN55S85FAFXZA, QN55S90FAFXZA, QN55S95FAFXZA, QN65Q7FAAFXZA, QN65QN70FAFXZA, QN65QN80FAFXZA, QN65QN900FFXZA, QN65QN90FAFXZA, QN65QN990FFXZA, QN65S85FAFXZA, QN65S90FAFXZA, QN65S95FAFXZA, QN75QN70FAFXZA, QN75QN80FAFXZA, QN75QN900FFXZA, QN75QN90FAFXZA, QN75QN990FFXZA, QN77S85FAFXZA, QN77S90FAFXZA, QN77S95FAFXZA, QN83S85FAFXZA, QN83S90FAFXZA, QN85Q7FAAFXZA, QN85QN70FAFXZA, QN85QN80FAFXZA, QN85QN900FFXZA, QN85QN90FAFXZA, QN85QN990FFXZA.



Compatible with:
Neo QLED, OLED 8K
Samsung QLED 4K



And More!

Image: The Ceybo remote control displayed alongside various Samsung Neo QLED and QLED televisions, illustrating its broad compatibility.

Compatible with the following models

QN42S90FAFXZA QN43Q7FAAFXZA
QN43QN90FAFXZA QN48S90FAFXZA
QN50Q7FAAFXZA QN50QN90FAFXZA
QN55Q7FAAFXZA QN55QN70FAFXZA
QN55QN80FAFXZA QN55QN90FAFXZA

And more!


Image: A visual representation of the Ceybo remote control with a comprehensive list of compatible Samsung TV model numbers.

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

Related Documents - BN59-01480A

	<p>Samsung Smart-TV Remote Control Comparison: Original vs. Replacement Functions</p> <p>Detailed comparison of original Samsung Smart-TV remote control buttons and functions against a replacement remote. Covers navigation, playback, smart hub access, and shortcut keys for models like TM1850A.</p>
	<p>Samsung Remote Control User Guide and Compatibility</p> <p>Comprehensive guide to Samsung remote control functions, installation steps, and compatibility with various Samsung TV models. Includes model numbers for easy reference.</p>
	<p>Samsung BN59-00516A Replacement Remote Control Guide</p> <p>This guide provides button mapping details for the Samsung BN59-00516A replacement remote control, covering TV, DVD, STB, and CABLE-VCR functions. Compare original remote buttons to their replacements.</p>

	<p>Samsung Smart TV Remote Control Guide</p> <p>A comprehensive guide to using the Samsung Smart TV Remote Control, including pairing instructions, button functions, and voice command usage.</p>
	<p>Samsung Smart-TV Remote Control Function Guide: TM1850A BN59-01259B & Replacement Models</p> <p>Detailed comparison of original and replacement remote control buttons for Samsung Smart TVs, including models TM1850A BN59-01259B, BN59-01301A, and BN59-01350B. Find button function mapping from Mandis shop.</p>
	<p>Samsung BN59-01180A Remote Control Guide</p> <p>A comprehensive guide detailing the original and replacement functions of the Samsung BN59-01180A remote control, including button mappings and features.</p>