

Vente-unique TYRA

Vente-unique TYRA Hydromassage Shower Column User Manual

Model: TYRA

1. INTRODUCTION

Thank you for choosing the Vente-unique TYRA Hydromassage Shower Column. This manual provides essential information for the safe installation, operation, and maintenance of your new shower system. Please read these instructions carefully before installation and retain them for future reference.

2. SAFETY INFORMATION

- Ensure all plumbing connections are secure to prevent leaks.
- Verify water pressure is within recommended limits for optimal performance and to avoid damage.
- Always test water temperature before use to prevent scalding.
- Installation should be performed by a qualified professional if you are unsure about any steps.
- Do not use abrasive cleaners or harsh chemicals on the shower column's surface.

3. PACKAGE CONTENTS

Please check that all components are present before beginning installation:

- TYRA Hydromassage Shower Column
- Hand shower with hose
- Mounting brackets and hardware
- Installation manual (this document)
- Sealing washers and gaskets

4. SPECIFICATIONS

Feature	Detail
Brand	Vente-unique
Model	TYRA
Dimensions (L x W x H)	20 x 44 x 150 cm
Weight	6.5 Kilograms
Color	Black
Features	Hydromassage jets, Rain shower, Hand shower

Note: All dimensions are approximate and subject to minor manufacturing variations.

5. SETUP AND INSTALLATION

Before installation, ensure you have the necessary tools (drill, level, wrench, sealant) and that your water supply lines are accessible and compatible.

- 1. Prepare the Wall:** Mark the desired mounting height for the shower column. Ensure the wall is structurally sound and capable of supporting the unit's weight.
- 2. Mounting Brackets:** Using the provided template or measurements, drill holes for the mounting brackets. Secure the brackets firmly to the wall with appropriate fasteners.
- 3. Connect Water Lines:** Connect the hot and cold water supply lines to the corresponding inlets on the back of the shower column. Use sealing washers and ensure all connections are watertight.
- 4. Hang the Column:** Carefully hang the shower column onto the mounted brackets. Ensure it is level and securely seated.
- 5. Final Connections:** Connect the hand shower hose to its outlet on the column.
- 6. Test for Leaks:** Turn on the water supply and check all connections for leaks. Operate each function of the shower column to ensure proper water flow and temperature.




Figure 1: Technical drawing showing the dimensions and layout of the TYRA shower column. This diagram is crucial for planning installation and ensuring proper fit within your shower space.



Figure 2: An example of the TYRA shower column installed in a contemporary bathroom setting, demonstrating its aesthetic integration.

6. OPERATING INSTRUCTIONS

The TYRA shower column offers multiple functions for a personalized showering experience.

- **Water Flow Control:** Use the main knob/lever to turn the water on/off and adjust the flow intensity.
- **Temperature Control:** The temperature knob allows you to set your desired water temperature. Always check the temperature before stepping into the shower.
- **Function Selector:** Rotate the selector knob to switch between the different shower functions:
 - **Rain Shower:** Water flows from the overhead showerhead for a wide, gentle spray.
 - **Hydromassage Jets:** Water sprays from the body jets for a targeted massage.
 - **Hand Shower:** Detach the hand shower for flexible, directed rinsing.



Figure 3: Close-up view of the TYRA shower column's controls, including the main water flow/temperature mixer and the function selector knob.

7. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your shower column.

- **Cleaning the Surface:** Wipe the column regularly with a soft cloth and mild soap or a non-abrasive bathroom cleaner. Rinse thoroughly and dry to prevent water spots.
- **Cleaning Nozzles:** The silicone nozzles on the showerhead and body jets are designed for easy cleaning. Gently rub them with your finger or a soft brush to dislodge any mineral deposits.
- **Descaling:** In areas with hard water, descaling may be necessary. Use a descaling solution specifically designed for bathroom fixtures, following the product's instructions. Avoid strong acids or abrasive materials.
- **Hose Maintenance:** Periodically check the hand shower hose for kinks or damage. Clean the hose with a soft cloth.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Low water pressure	Clogged nozzles, low household water pressure, partially closed shut-off valve	Clean nozzles, check household water pressure, ensure shut-off valves are fully open.
Leaks from connections	Loose connections, worn washers	Tighten connections, replace washers if necessary. Apply plumber's tape if needed.
Water not hot enough	Water heater setting too low, insufficient hot water supply, faulty thermostatic cartridge	Adjust water heater temperature, ensure adequate hot water supply, contact a professional if cartridge is suspected.
Dripping after use	Residual water in showerhead, worn cartridge	Normal for a short period due to residual water. If persistent, a cartridge replacement might be needed by a professional.

If you encounter problems not listed here or if solutions do not resolve the issue, please contact Vente-unique customer support.

9. WARRANTY AND SUPPORT

Your Vente-unique TYRA Hydromassage Shower Column is covered by legal guarantees and a 30-day return policy, as provided by VENTE-UNIQUE. For any questions, technical assistance, or warranty claims, please contact Vente-unique Specialized Customer Support.

For more information, please visit the [Vente-unique Brand Store](#).