

Hombasing W2-1500W.8

Hombasing 2200W Handheld Steam Cleaner Instruction Manual

Model: W2-1500W.8

1. PRODUCT OVERVIEW

Thank you for choosing the Hombasing 2200W Handheld Steam Cleaner. This powerful and versatile steam cleaner is designed for efficient and chemical-free cleaning across various surfaces in your home and car. With its fast heat-up time and large water tank, it provides continuous steam for effective removal of dirt and grime.

Important Safety Information: Always exercise caution when operating the steam cleaner. Steam is extremely hot and can cause burns. Keep the steam nozzle away from people, pets, and delicate surfaces. Ensure proper ventilation during use.



Image 1.1: The Hombasing 2200W Handheld Steam Cleaner main unit.

2. PRODUCT COMPONENTS

The Hombasing 2200W Handheld Steam Cleaner comes with the following components:

- 1 x Handheld Steam Cleaner Unit
- 1 x High Pressure Extension Rod
- 3 x Brush Heads (various types for different cleaning tasks)
- 1 x Large Capacity Water Tank (integrated)
- 1 x Power Cord
- Additional accessories may include: nozzle washer, cleaning cloth, gloves.

POWERFUL HOT-PRESS STEAM

Please check and install the black rubber gasket before use to prevent water leakage.

The steam function can only be used after installing the yellow nozzle.

Image 2.1: All included components of the steam cleaner.

3. SETUP INSTRUCTIONS

1. **Install the Gasket:** Before attaching any nozzles or the extension rod, ensure the black rubber gasket is properly installed into the connection point on the handheld steam gun. This prevents water leakage during operation.
2. **Attach Nozzle/Extension Rod:** Select the appropriate nozzle or the high-pressure extension rod for your cleaning task. Screw it firmly onto the handheld steam gun.
3. **Fill the Water Tank:** Open the water tank cap on the main unit. Fill the 1.2L water tank with clean tap water. Do not overfill. Close the cap securely.
4. **Connect Power:** Plug the power cord into a suitable electrical outlet.
5. **Power On:** Press the power button on the main unit. The indicator light will illuminate, signifying that the unit is heating up. The device heats up in approximately 10-15 seconds.

1200ML Large Capacity Design to Meet the Needs of Deep Cleaning

Continuous Cleaning Without Interruption, No More Trouble of Frequent Water Addition



Image 3.1: Filling the 1.2L water tank.

Video: How to Install the Nozzle Washer

Video 3.2: This video demonstrates the correct procedure for installing the nozzle washer to prevent leaks.

4. OPERATING INSTRUCTIONS

Once the unit has heated up (indicator light may change or steam will be ready), you can begin cleaning. The steam cleaner generates 105°C/229°F high-temperature steam with a pressure of up to 3 BAR, effectively penetrating and removing stubborn stains.

1. **Select Attachment:** Choose from the 7 included accessories based on the surface you are cleaning. For example, brush heads for grout or tough stains, and the extension rod for hard-to-reach areas.
2. **Apply Steam:** Direct the steam nozzle towards the surface to be cleaned. Press the steam trigger on the handheld gun to release steam. Move the nozzle slowly over the area.
3. **Wipe Clean:** For best results, wipe the steamed area with a clean cloth immediately after steaming to remove loosened dirt and moisture.
4. **Continuous Use:** The 1.2L water tank allows for continuous operation for 10 (wettest) to 30 (driest)

minutes without frequent refilling.

Video: Usage Steps and Precautions

Video 4.1: This video provides a general overview of the usage steps and important precautions for operating the steam cleaner.

Cleaning Applications



Image 4.2: Cleaning kitchen stovetops.

Multifunctional High-Pressure Steam Machine

Continuous Cleaning Without Interruption, No More Trouble of Frequent Water Addition



Image 4.3: Cleaning windows and glass surfaces.

221°F HIGH TEMPERATURE STEAM CLEANER ONE BUTTON START, FAST HEATING WITHIN 10-20S 221°F



Image 4.4: Refreshing upholstery and fabrics.



MULTIPLE USE

Carpet/Kitchen/Car/Wall/Bathroom/Doll



Image 4.5: Deep cleaning tile grout.



Image 4.6: Cleaning car interiors.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your steam cleaner.

- **Empty Water Tank:** After each use, unplug the unit and allow it to cool completely. Carefully empty any remaining water from the tank.
- **Clean Accessories:** Clean all used nozzles and brush heads with water and mild soap. Ensure they are dry before storing.
- **Descale (Periodically):** Depending on water hardness, mineral deposits may build up. Consult the manufacturer's website or contact support for descaling instructions if needed.
- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your Hombasing steam cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Water leakage from nozzle connection	Missing or improperly installed gasket.	Ensure the black rubber gasket is correctly installed before attaching the nozzle or extension rod. Tighten the connection firmly. Refer to Video 3.2.
Steam cleaner only discharges water, no spray	Continuous use has caused the pump to overheat and automatically shut down.	Unplug the unit and allow it to cool down for 10-15 minutes. The pump will reset, and normal steam function will resume.
No steam or power	Unit not plugged in, power switch off, or water tank empty.	Check power connection, ensure power switch is on, and refill the water tank if empty. Allow adequate time for heating.

7. SPECIFICATIONS

Feature	Detail
Brand	Hombasing
Model Name	W2-1500W.8
Wattage	2200 watts
Tank Volume	1.2 Liters (1200 Milliliters)
Heat Time	10-15 Seconds
Maximum Temperature	229 Degrees Fahrenheit (105°C)
Item Weight	1.58 Kilograms (3.47 pounds)
Power Source	Corded Electric
Form Factor	Handheld
Included Components	3 Brush Heads, Handheld Steam Cleaner, High Pressure Extension Rod, Large capacity water tank, Power Cord
UPC	752674637692

8. WARRANTY INFORMATION

Specific warranty details for the Hombasing 2200W Handheld Steam Cleaner are not provided in this manual. Please refer to the product packaging, the seller's website, or contact customer support for information regarding warranty coverage and terms.

9. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Hombasing 2200W Handheld Steam Cleaner, please contact the seller directly through the platform where you purchased the product. You may also visit the official Hombasing store on Amazon for additional product information and support resources.

Amazon Store Link: [Hombasing Store](#)