

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [NURATIT](#) /

> [NURATIT Automatic Billiard Ball Cleaner and Polisher \(16-Ball Capacity\) - Instruction Manual](#)

NURATIT Automatic Billiard Ball Cleaner and Polisher

NURATIT Automatic Billiard Ball Cleaner and Polisher (16-Ball Capacity)

Instruction Manual

INTRODUCTION

The NURATIT Automatic Billiard Ball Cleaner and Polisher is designed to efficiently clean and polish up to 16 billiard or snooker balls, ensuring optimal playing conditions. This device utilizes a powerful motor and specialized cleaning solution to remove chalk, dirt, and grime, restoring the balls to a like-new, shiny finish. Its quiet operation and stable design make it a convenient addition to any billiard setup.

IMPORTANT SAFETY INFORMATION

- Ensure the device is placed on a stable, level surface before operation.
- Operate the unit using a 110V power supply.
- Keep the device dry and away from water or other liquids to prevent electrical hazards.
- This product is intended for adult use. Keep out of reach of children.
- Always unplug the device before cleaning or performing maintenance.
- Use only the provided cleaning solution or a recommended alternative for billiard balls.

PACKAGE CONTENTS

Verify that all items are present in the package:

- NURATIT Billiard Ball Cleaner and Polisher Unit
- Ball wash liquid (polishing spray)
- Power cord
- 2 spare fuses
- Wrench
- Shock absorbing cushion (1 piece)

- Spacer + Wool Ring (pre-installed or separate)
- Cleaning brush



The image displays the NURATIT Automatic Billiard Ball Cleaner and Polisher, a white circular device with a clear lid, surrounded by its accessories: a spray bottle, two fuses, a small wrench, a cleaning brush, and a set of billiard balls.

SETUP INSTRUCTIONS

1. Unpack all components from the packaging.
2. Place the billiard ball cleaner on a firm, level, and stable surface. The shock-absorbing underpads will help maintain stability during operation.
3. Ensure the red power switch is in the 'OFF' position.
4. Connect the power cord to the unit and then to a standard 110V electrical outlet.

OPERATING INSTRUCTIONS

1. **Load Balls:** Open the clear lid of the cleaner. Remove the top tray and carefully place up to 16 billiard balls into the designated slots on the main cleaning disc.
2. **Apply Solution:** Using the provided polishing spray, apply a small amount (twice per ball) onto each billiard ball. **Friendly reminder:** Avoid excessive use of cleaning solution, as this may saturate the

woolen loop, causing the cue ball to become tightly wrapped and reducing cleaning efficiency.

3. **Close Unit:** Replace the top tray and close the clear lid securely.
4. **Power On:** Press the red power switch on the right side of the unit to turn it on.
5. **Start Cleaning Cycle:** Press the green start button on the left side. The balls will begin to spin clockwise for approximately one minute, then pause for 26 seconds, and finally spin counter-clockwise for another minute. The entire cleaning and polishing cycle takes about 3 minutes.
6. **Remove Balls:** Once the cycle is complete and the unit stops, lift the clear lid and remove the top tray. Carefully take out the now clean and polished billiard balls.

Usage Steps

Original patented technology



- 1 Open the lid of the billiard ball cleaner and place the billiard balls to be cleaned



- 2 Spray the billiard ball cleaner that comes with the product onto the billiard ball and close the lid



- 3 Press the red power switch on the right side of the billiard ball cleaner, then press the green start button on the left side



- 4 The billiard balls in the billiard ball cleaner start spinning in the forward direction for about a minute, the balls stop for 30 seconds and start spinning in the reverse direction for about a minute



- 5 After waiting for the billiard balls to finish cleaning, open the top cover, remove the tray, and take out the billiard balls

This image provides a visual sequence of the usage steps: opening the lid and placing balls, spraying cleaning solution, closing the lid and pressing start, the balls spinning, and finally removing the cleaned balls.

Product Demonstration Video

Your browser does not support the video tag.

Official product video demonstrating the operation of the NURATIT Billiard Ball Cleaner and Polisher, including loading, solution application, and the automatic cleaning cycle.

Quiet Operation Demonstration

Your browser does not support the video tag.

A brief video clip showcasing the NURATIT Billiard Ball Cleaner in operation, highlighting its quiet performance while cleaning billiard balls.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your billiard ball cleaner.

- **Cleaning Wool Rings and Polishing Disks:** The high-quality wool rings and polishing disks may accumulate dirt with long-term use. They are designed to be removable for cleaning or replacement. Gently remove them and clean with mild soap and water, or replace if heavily soiled or worn.
- **Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Motor Cooling System:** The motor features a professional cooling system with an oval air outlet. Ensure these vents remain clear of obstructions to allow for effective heat dissipation and prolong motor life.



An image showing the removable wool rings and a spacer, which are key components for the cleaning and polishing process and require periodic cleaning or replacement.

TROUBLESHOOTING

If you encounter issues with your NURATIT Billiard Ball Cleaner, refer to the following common problems and solutions:

- **Unit Not Turning On:**
 - Check if the power cord is securely plugged into both the unit and the electrical outlet.
 - Ensure the red power switch is in the 'ON' position.
 - Verify that the electrical outlet is functional.
 - Check the fuses. The unit comes with spare fuses for replacement if needed.
- **Balls Not Spinning or Spinning Slowly:**
 - Ensure the lid is properly closed and the top tray is correctly seated.
 - Excessive cleaning solution can saturate the wool rings, causing resistance. Reduce the amount of solution used.
 - Clean or replace the wool rings and polishing disks if they are dirty or worn.
 - Ensure the motor cooling vents are not obstructed.
- **Poor Cleaning/Polishing Results:**
 - Ensure sufficient cleaning solution is applied (twice per ball).
 - For heavily soiled balls, pre-clean manually with a brush and solution before using the machine.
 - Clean or replace the wool rings and polishing disks.

PRODUCT SPECIFICATIONS

Specification	Detail
Brand	NURATIT
Model Name	Pool Ball Cleaner, Billiard Ball Cleaner, Billiard Ball Cleaner and Polisher, Automatic Pool Ball Cleaner, Automatic Billiard Ball Cleaning Machine
Material	Plastic, Nylon
Color	White
Capacity	16 Balls
Item Weight	10.34 Kilograms
Item Diameter	18 Inches
Package Dimensions (L x W x H)	18.5 x 18.4 x 11.7 inches
Sport	Billiards
Power Supply	110V (British and American Dual Use)

WARRANTY AND SUPPORT

This NURATIT Billiard Ball Cleaner and Polisher comes with a **2 Year Manufacturer Warranty**. For any product inquiries, technical support, or warranty claims, please contact NURATIT customer service through your original point of purchase or refer to the contact information provided in your product packaging.