

## **HOMCOM IT83B-327V90GY0631**

# **HOMCOM Electric Recliner Chair with Memory Function, Grey (Model IT83B-327V90GY0631) - User Manual**

This manual provides detailed instructions for the assembly, operation, and maintenance of your HOMCOM Electric Recliner Chair.

## **1. INTRODUCTION**

Thank you for choosing the HOMCOM Electric Recliner Chair. This chair is designed to provide comfort and relaxation with its silent electric reclining mechanism, adjustable footrest, and memory function. Please read this manual carefully before assembly and use to ensure safe and correct operation.



*Image: The HOMCOM Electric Recliner Chair in grey fabric, featuring a modern design suitable for various living spaces.*

## 2. IMPORTANT SAFETY INFORMATION

### **Warning:**

- Do not exceed the maximum weight capacity of 135 kg (297 lbs).
- Assemble the chair correctly by strictly following all instructions provided in this manual.
- Use the remote control with caution.
- Ensure all electrical cables are securely connected and free from damage before and during use.
- Keep children and pets away from moving parts during operation.
- Avoid placing the chair near heat sources or in direct sunlight to prevent material degradation.

### 3. PACKAGE CONTENTS

---

Please check that all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer service.

- Recliner Chair Components (Backrest, Seat, Armrests, Footrest)
- Power Adapter
- Remote Control
- Assembly Hardware (Screws, Allen Key)

Your browser does not support the video tag.

*Video: An overview of all components included in the package for the HOMCOM Electric Recliner Chair.*

### 4. ASSEMBLY INSTRUCTIONS

---

Assembly is required for this product. Please follow the steps below carefully. It is recommended to have two people for assembly.

#### 4.1. Visual Assembly Guide

Your browser does not support the video tag.

*Video: A step-by-step guide demonstrating the assembly process of the HOMCOM Electric Recliner Chair.*

#### 4.2. Step-by-Step Assembly

1. **Attach the Feet:** Locate the four feet and screw them into the designated holes on the bottom of the chair base. Ensure they are tightened securely.



*Image: Dimensions of the chair, also showing the base where feet are attached.*

2. **Connect the Backrest:** Align the backrest with the seat base. Slide the metal brackets on the backrest into the corresponding slots on the seat base until they click into place.
3. **Secure the Armrests:** Attach the armrests to the sides of the chair using the provided screws and Allen key. Do not fully tighten the screws until all components are aligned.
4. **Install the Electric Motor:** Carefully place the electric motor into its designated position under the seat. Secure it with the provided screws.



## MOTORE EFFICACE E BRUSHLESS

# 100000

x movimenti garantiti



*Image: The silent brushless motor, designed for smooth and quiet operation.*

5. **Connect Electrical Components:** Connect the power adapter to the motor and then to a power outlet. Connect the remote control cable to the motor.
6. **Final Tightening:** Once all parts are assembled and aligned, fully tighten all screws.

## 5. OPERATING INSTRUCTIONS

Your HOMCOM Electric Recliner Chair features a user-friendly remote control for easy adjustments.

### 5.1. Reclining the Chair

Use the remote control to smoothly recline the chair to your desired position. The chair offers a stepless recline up to 160 degrees, and the footrest extends automatically.

Your browser does not support the video tag.

*Video: Demonstration of the 160-degree electric reclining function of the chair.*

# RECLINAZIONE ELETTRICA

*Doppio funzione memory*



Posizione di memoria 1



Posizione di memoria 2

Passare facilmente da una posizione all'altra con i pulsanti di memoria sul telecomando



Impostatelo una volta, godetevelo ogni volta

*Image: The remote control with buttons for recline and memory functions, illustrating two memory positions.*

## 5.2. Memory Function

The dual memory function allows you to save two preferred reclining positions. To set a memory position:

1. Adjust the chair to your desired position using the recline buttons.
2. Press and hold one of the memory buttons (e.g., M1 or M2) until you hear a beep or see an indicator light, confirming the position is saved.
3. To recall a saved position, simply press the corresponding memory button.

## 6. MAINTENANCE

Proper care will extend the life of your recliner chair.

- **Cleaning:** The scratch-resistant velvet fabric is easy to clean. Use a soft, damp cloth with mild soap for



spills. Avoid harsh chemicals or abrasive cleaners.

- **Motor Care:** The brushless motor is designed for durability (up to 100,000 cycles) and requires minimal maintenance. Keep the area around the motor free from dust and debris.
- **Cable Inspection:** Regularly check all electrical cables for any signs of wear or damage. Replace immediately if any damage is found.
- **General Care:** Avoid jumping on the chair or applying excessive force to the reclining mechanism.

# TESSUTO

- Non attira e non trattiene i peli di animali domestici
- Nessuna preoccupazione per i graffi degli animali domestici



Image: Close-up of the velvet fabric, emphasizing its scratch-resistant and easy-to-clean properties.

## 7. TROUBLESHOOTING

### Common Issues and Solutions

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem                                     | Possible Cause  | Solution  |
|---|---|---|
| Chair does not recline.                     | Power cable disconnected; remote control not connected; power outage. | Check power cable and remote control connections. Ensure power outlet is working.   |
| Reclining mechanism is noisy.               | Debris in mechanism; loose connections.                               | Inspect for debris and remove. Check for loose screws and tighten if necessary.     |
| Footrest not extending/retracting properly. | Obstruction; mechanism issue.   | Ensure no objects are obstructing the footrest. If issue persists, contact support. |

## 8. SPECIFICATIONS

- **Brand:** HOMCOM
- **Model:** IT83B-327V90GY0631
- **Color:** Grey
- **Material:** Velvet Fabric (Polyester)
- **Overall Dimensions (Upright):** 80L x 83P x 104A cm (31.5" L x 32.7" W x 40.9" H)
- **Overall Dimensions (Reclined):** 80L x 162P x 67A cm (31.5" L x 63.8" W x 26.4" H)
- **Seat Width:** 58 cm (22.8")
- **Backrest Thickness:** 18 cm (7.1")
- **Weight Capacity:** 135 kg (297 lbs)
- **Motor Type:** Silent Brushless Motor (48 dB)
- **Recline Angle:** Up to 160°
- **Voltage:** 240 Volt
- **Special Features:** Dual Memory Function, Side Storage Pocket, Adjustable Footrest, Scratch-Resistant Fabric.



# SUPPORTO PER TUTTO IL CORPO

*Progettato per ridurre le tensioni, offre un comfort senza precedenti*



*Image: The recliner chair in a fully reclined position, demonstrating full body support.*

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your purchase or contact HOMCOM customer service directly. Keep your purchase receipt as proof of purchase. You can visit the [HOMCOM Store on Amazon](#) for more product information and contact details.