

[manuals.plus](#) /› [King Lucky](#) /› [King Lucky i121 Open Ear Clip-On Wireless Bluetooth Earbuds User Manual](#)

King Lucky i121

King Lucky i121 Open Ear Clip-On Wireless Bluetooth Earbuds User Manual

Model: i121

1. INTRODUCTION

Welcome to the King Lucky i121 Open Ear Clip-On Wireless Bluetooth Earbuds user manual. These earbuds are designed to provide a comfortable audio experience while maintaining awareness of your surroundings. This manual provides essential information for setting up, operating, and maintaining your new earbuds.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- King Lucky i121 Open Ear Earbuds (L/R)
- Charging Case
- USB-C Charging Cable
- User Manual
- Detachable Decorative Clips (optional, may vary by package)




Figure 2.1: Package Contents. This image displays the King Lucky i121 earbuds, their charging case, a USB-C charging cable, and a pair of decorative clips.

3. SETUP

3.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. Connect the provided USB-C cable to the charging

port on the case and a compatible USB power source. The indicator light on the case will show charging status.



Figure 3.1: Battery Life and Charging. The earbuds offer approximately 6 hours of playback on a single charge, with the charging case providing up to 50 hours of total battery life.

3.2. Bluetooth Pairing

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "King Lucky i121" from the list of devices to connect.
5. Once connected, a voice prompt will confirm successful pairing.

4. WEARING THE EARBUDS

The King Lucky i121 earbuds feature an open-ear clip-on design for comfort and situational awareness.

1. Identify the Left (L) and Right (R) earbuds.

2. Gently open the ear clip and position it over the top of your ear, allowing the speaker part to rest near your ear canal without entering it.
3. Adjust for a secure and comfortable fit.




Figure 4.1: Open-Ear Design. This diagram shows how the earbuds sit on the ear, providing audio without blocking ambient sounds.

4.1. Attaching Detachable Decorative Clips

If your package includes detachable decorative clips, follow these steps to attach them:

1. Remove the earbuds from the charging case.
2. Carefully clip the decorative element onto the ear hook of the earbud.
3. Ensure the clip is securely fastened.

Note: The charging case may not close properly with the decorative clips attached. It is recommended to remove them before placing the earbuds back into the case for charging or storage.

Portable Detachable Earrings

From installation to wear in just 5 seconds

1 Remove earbuds & random baubles



2 Clip any baubles onto earhooks



3 Perfect accessory pairings

Figure 4.2: Attaching Decorative Clips. This visual guide demonstrates the process of attaching the decorative clips to the earbuds for a customized look.



Wear your music like jewelry.

Fashion meets function in one brilliant design

Figure 4.3: Earbuds with Decorative Clips. A woman is shown wearing the King Lucky i121 earbuds with the detachable jewelry, illustrating their integration as a fashion accessory.

5. OPERATING CONTROLS

The King Lucky i121 earbuds feature touch controls for easy management of audio and calls.

Action	Function
Tap x1 (L/R)	Answer Call
Tap x2 (L/R)	End Call / Play/Pause Music
Tap x1 (L)	Volume Down
Tap x1 (R)	Volume Up
Tap x3 (L)	Activate Voice Assistant (Siri, Google Assistant)

Action	Function
Tap x3 (R)	Game Mode
Long Press 2" (L/R)	Reject Call
Long Press 2" (L)	Previous Track
Long Press 2" (R)	Next Track
Tap x5 (L/R)	Factory Reset

6. KEY FEATURES

- **Open-Ear Design:** Allows you to hear your audio content while remaining aware of your surroundings, ideal for outdoor activities or office environments.
- **Immersive Sound:** Equipped with 12mm dynamic drivers for clear audio and enhanced bass.
- **Clear Calls:** Features Environmental Noise Cancellation (ENC) microphones for clear voice transmission during calls.
- **Bluetooth 5.4:** Provides a stable and low-latency wireless connection.
- **IPX5 Water Resistance:** Protects against sweat and light rain, suitable for workouts and outdoor use.
- **Long Battery Life:** Up to 6 hours of listening time per charge, with the charging case extending total playtime to 50 hours.
- **Lightweight:** Each earbud weighs approximately 5.2g for comfortable extended wear.

12mm Driver for immersive sound!

Large Drivers Deliver Deep Bass and Crisp Highs
DNS ensures every word is transmitted precisely for vivid calls.



Figure 6.1: 12mm Dynamic Driver. An internal view of the earbud highlighting the 12mm dynamic driver, which contributes to the audio quality.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the earbuds in their charging case when not in use to protect them from dust and damage.
- **Water Exposure:** While IPX5 rated, avoid submerging the earbuds in water. Dry them thoroughly if exposed to sweat or rain before placing them back in the charging case.

8. TROUBLESHOOTING

Problem	Solution

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Perform a factory reset (Tap x5 on either earbud).
No sound	Check device volume and earbud volume. Ensure earbuds are properly connected to your device.
Poor sound quality	Ensure earbuds are clean and free of debris. Move closer to your connected device to avoid interference.
Charging issues	Verify the USB-C cable and power source are working. Ensure earbuds are correctly seated in the charging case.

9. SPECIFICATIONS

- **Model:** i121
- **Brand:** King Lucky
- **Connectivity:** Bluetooth 5.4
- **Water Resistance:** IPX5
- **Earbud Weight:** Approximately 5.2g per earbud
- **Driver Size:** 12mm Dynamic
- **Battery Life (Earbuds):** Up to 6 hours
- **Battery Life (with Case):** Up to 50 hours
- **Charging Port:** USB-C

10. OFFICIAL PRODUCT VIDEO

Video 10.1: King Lucky Jewelry Clip-on Earbuds with Detachable Aurora. This official video from King Lucky showcases the design and features of the earbuds, including the detachable decorative elements and their versatile use.

11. WARRANTY AND SUPPORT

King Lucky products come with a manufacturer's warranty. For detailed warranty information, product support, or service inquiries, please refer to the contact information provided in your product packaging or visit the official King Lucky website. The seller, KING LUCKY 100-Day Return Guarantee, offers a return policy as specified at the point of purchase.