

EBELLO B0F83W771C

EBELLO Manual Reclining Sectional Sofa Set - Instruction Manual

Model: B0F83W771C

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before assembling and using your EBELLO Manual Reclining Sectional Sofa Set. Keep this manual for future reference.

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the sofa on a soft, clean surface to prevent scratches.
- Do not allow children to play on or around the reclining mechanism. Keep hands and feet clear of moving parts.
- Do not stand on the sofa or footrest.
- Periodically check all connections and fasteners to ensure they remain tight.
- Maximum weight capacity for each seating section is 250 lbs (113 kg).

2. PRODUCT OVERVIEW & FEATURES

The EBELLO Manual Reclining Sectional Sofa Set is designed for comfort and functionality, featuring manual reclining seats, a center console with cup holders, and hidden storage.



Overall view of the EBELLO L-shaped Manual Reclining Sectional Sofa in black faux leather.

Key Features:

- **Manual Reclining Function:** Smooth mechanism for easy adjustment.
- **Overstuffed Design:** High-density foam padding for enhanced comfort.
- **Durable Faux Leather:** Easy-to-clean and wear-resistant upholstery.
- **Center Console:** Includes two cup holders and a hidden storage compartment.
- **Space-Saving L-Shaped Layout:** Maximizes seating efficiency.

Product Size



Detailed view highlighting the soft padded seat, overstuffed backrest, supportive footrest, metal footrest frame, and durable faux leather material.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts are accounted for. If any parts are missing or damaged, please contact customer support.

- Left Arm Recliner Section
- Right Arm Recliner Section
- Armless Chair Section(s) (Quantity may vary based on configuration)
- Corner Section (if applicable)
- Console Section (if applicable)
- Backrests for all sections
- Legs/Feet
- Hardware Pack (bolts, washers, nuts, Allen wrench)

4. ASSEMBLY INSTRUCTIONS

Assembly is required. It is recommended that two adults assemble this sofa. Approximate assembly time: 30-60 minutes.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a clean, soft surface to prevent damage.
2. **Attach Legs:** Locate the legs/feet and attach them to the bottom of each sofa section. Ensure they are securely

tightened.

3. **Connect Sections:** Align the metal connectors on the sides of each sofa section. Push the sections together firmly until they lock into place. Start with the corner piece (if applicable) and work outwards.
4. **Attach Backrests:** Slide the backrests onto the metal brackets located on the base of each sofa section. Ensure they click securely into place.
5. **Final Check:** Once all sections and backrests are attached, gently lift and shake each section to ensure stability. Confirm all connections are secure.



The metal footrest frame provides support for the reclining mechanism.

5. OPERATING INSTRUCTIONS

5.1. Manual Reclining Function

The end seats of the sectional sofa feature a manual reclining mechanism.

1. **To Recline:** Locate the lever on the side of the armrest. Pull the lever firmly to release the footrest. Lean back gently to recline the backrest to your desired position.
2. **To Return Upright:** Push your body forward and use your legs to push the footrest down until it locks into its original position. The backrest will return to an upright position.



The manual recliners offer multiple positions for reading, watching TV, or napping.



Manual Control

This sofa features a user-friendly manual control system. With simple operations, you can adjust the seat's reclining angle, allowing for personalized comfort and relaxation at your fingertips.

The manual control lever allows for easy adjustment of the reclining angle.

5.2. Center Console with Cup Holders and Storage

The center console provides convenient features for your comfort.

- **Cup Holders:** Use the two integrated cup holders to keep beverages secure and within reach.
- **Hidden Storage:** Lift the console lid to access the hidden storage compartment. This space is ideal for remotes, magazines, or other small items.

Hidden Storage



Additional hidden storage under the cover making sure sufficient storage space. Goods can be put things for easy storage and searching



Two Cupholders



This design allows users to relax comfortably while keeping their drinks close at hand. Whether it's a steaming cup of coffee or a refreshing beverage these cup holders prevent spills and eliminate the need to constantly search for a flat surface

The center console features convenient cup holders and a hidden storage area.

6. CARE AND MAINTENANCE

Proper care will extend the life and appearance of your sofa.

- **Cleaning Faux Leather:** For general cleaning, wipe the faux leather with a soft, damp cloth. For tougher stains, use a mild soap solution and wipe immediately with a clean, damp cloth, then dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the faux leather to fade or crack. Position your sofa away from direct sunlight.
- **Avoid Sharp Objects:** Keep sharp objects away from the upholstery to prevent punctures or tears.
- **Regular Inspection:** Periodically check all bolts and connections to ensure they are tight. Tighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your sofa, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Recliner not engaging/disengaging smoothly	Mechanism obstruction or loose connection.	Check for any objects obstructing the mechanism. Ensure all assembly bolts are tight. Apply a silicone-based lubricant to moving parts if squeaking occurs.
Sofa sections separating	Connectors not fully engaged or loose.	Ensure all metal connectors between sections are fully pushed down and locked. Re-engage if necessary.
Squeaking noises	Loose fasteners or friction in moving parts.	Tighten all visible bolts and screws. Apply a small amount of silicone lubricant to metal-on-metal contact points in the reclining mechanism.
Footrest not staying up	Mechanism not fully locked.	Ensure the footrest is fully extended and the reclining lever is released. If the issue persists, inspect the mechanism for damage.

If the problem persists after attempting these solutions, please contact EBELLO customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	EBELLO
Model Number	B0F83W771C
Color	Black
Style	Contemporary
Seating Capacity	6
Upholstery Material	Faux Leather
Frame Material	Metal (for footrest frame)
Assembly Required	Yes
Reclining Position Count	1 (fully reclined)
Item Firmness Description	Medium
Special Features	Armrest, Breathable, Easy To Install, Recliner, Storage

Dimensions:

While specific overall dimensions are not provided in the product data, the L-shaped configuration is designed to maximize seating in various living spaces. Please refer to the product listing for detailed measurements of individual components if available.

9. WARRANTY INFORMATION

This EBELLO product comes with a**Limited Warranty**. Details regarding the duration and coverage of this warranty are typically provided at the point of purchase or can be obtained by contacting EBELLO customer support. Please retain your proof of purchase for any warranty claims.

10. CUSTOMER SUPPORT

For further assistance, missing parts, or warranty inquiries, please contact EBELLO customer support through the retailer where the product was purchased or visit the official EBELLO brand store online.

Online Store: [EBELLO Brand Store](#)

© 2024 EBELLO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question