

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SACOSDING](#) /

› [SACOSDING Magnetic Bead Men's Watch \(Model FB0047Z-02\) - Instruction Manual](#)

SACOSDING FB0047Z-02

SACOSDING Magnetic Bead Men's Watch

Model: FB0047Z-02

INTRODUCTION

Thank you for choosing the SACOSDING Magnetic Bead Men's Watch. This timepiece features an innovative magnetic floating ball display, offering a unique way to tell time. This manual provides essential information for setup, operation, and maintenance to ensure optimal performance and longevity of your watch.

PRODUCT OVERVIEW

The SACOSDING Magnetic Bead Watch is designed with a 42mm dial featuring a strong magnetic track. Time is indicated by two suspended balls: the inner ball represents minutes, and the outer ball represents hours. These balls orbit the dial, providing a distinctive visual representation of time.

The watch utilizes a high-quality quartz movement for accurate timekeeping. The dial is constructed from a copper alloy with an insulating coating to enhance durability and resist deformation, rust, and aging. The watch is equipped with a 22mm wide black leather strap, combining innovation with a classic Roman numeral dial design.



Image: Front view of the SACOSDING Magnetic Bead Watch with a black leather strap.



Image: Diagram showing the magnetic field mechanism that guides the floating time-telling balls.

Your browser does not support the video tag.

Video: An introductory overview of the SACOSDING Magnetic Bead Watch, demonstrating its unique time display and design.

SETUP

To set up your SACOSDING Magnetic Bead Watch, follow these steps:

1. **Step 1: Remove the Watch Stopper**

Locate the small plastic stopper on the side of the watch crown. Gently pull it out to activate the watch movement.

2. Step 2: Set the Time

Pull the crown outwards. Turn the crown clockwise to adjust the magnetic balls to the desired time.

The inner ball indicates minutes, and the outer ball indicates hours.

3. Step 3: Secure the Crown

Once the time is set, push the crown back into its original position. The magnetic balls will align to display the correct time.

Note: It is normal to find the two magnetic beads non-aligned initially due to magnetic repulsion. They will settle into position once the crown is pushed in and the watch is worn.



Image: Visual guide for setting the watch, including removing the stopper and adjusting the crown.

OPERATING INSTRUCTIONS

Reading the time on your Magnetic Bead Watch is intuitive once you understand the display:

- The **inner magnetic ball** indicates the **minutes**.
- The **outer magnetic ball** indicates the **hours**.

The Roman numerals on the outer track represent hours (I to XII), and the minute markers are positioned around the inner track. The magnetic balls will move to their respective positions to show the current time.

Specification



Brand	FOXBOX	MODEL	FB0047
Movement type	Quartz movement	Waterproof	30 meters
Clasp	Pin buckle	Weight	65g
Strap Material	Leather strap	Case Material	Stainless steel

Image: Example of how to read the time on the magnetic watch, showing the hour and minute indicators.

MAINTENANCE

To keep your SACOSDING watch in excellent condition, please follow these maintenance guidelines:

- Water Resistance:** The watch is 30m (100 feet) water-resistant, suitable for washing hands, rain, or splashing water. It is **not** suitable for swimming, diving, or showering. Avoid exposure to warm or hot water.
- Cleaning:** Wipe the watch with a soft, dry cloth to remove dust and smudges. For the leather strap, avoid excessive moisture and harsh chemicals.
- Storage:** When not in use, store the watch in a cool, dry place away from direct sunlight and strong magnetic fields to prevent interference with the magnetic display.
- Battery:** The watch uses 1 nonstandard battery (included). If the watch stops functioning, the battery may need replacement by a qualified technician.



FOXBOX

Example when reading:

Viewing time in 12-hour format (not 24-hour format)




Image: Demonstration of the watch's 30M water resistance against splashes.

TROUBLESHOOTING

If you encounter any issues with your SACOSDING Magnetic Bead Watch, please consider the following:

- Incorrect Time Display:** Ensure the crown is fully pushed in after setting the time. If the magnetic balls are not aligning correctly, gently shake the watch to help them settle.
- Watch Not Running:** Check if the plastic stopper has been completely removed from the crown. If the watch still does not run, the battery may need to be replaced.
- Magnetic Interference:** Avoid placing the watch near strong magnets, as this can temporarily affect the magnetic ball display.

For persistent issues or concerns not addressed here, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	SACOSDING

Model Number	FB0047Z-02
Movement Type	Quartz Movement
Water Resistance	30 meters (100 feet)
Case Diameter	42mm
Case Thickness	12mm
Strap Material	Leather
Clasp Type	Tang Buckle
Weight	65g
Batteries	1 Nonstandard Battery (included)



Image: Visual representation of the watch's dimensions and key specifications.

WARRANTY AND SUPPORT

SACOSDING is committed to providing high-quality products and customer satisfaction. While specific warranty details are not provided in this manual, we offer 24/7 online customer service to assist you with any inquiries or issues you may have.

Please contact our customer service for assistance with:

- Product fit or sizing questions
- Quality concerns
- Time setting assistance
- Delivery issues

We value your experience and are here to help.



Image: Information regarding 24/7 online customer support for various product-related queries.