

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [INSOLKIDON](#) /

> [User Manual for INSOLKIDON Tablet Case Compatible with DOO-GEE Tab E3 Pro 13-INCH Tablet](#)

INSOLKIDON DOO-GEE Tab E3 Pro 13-INCH Tablet Case

User Manual

INSOLKIDON TABLET CASE

Model: DOO-GEE Tab E3 Pro 13-INCH Tablet Case

Introduction

This manual provides instructions for the INSOLKIDON Full Coverage Ultra Slim PU Leather Tablet Case, designed specifically for the DOO-GEE Tab E3 Pro 13-INCH Tablet. This protective case offers full coverage, a folding stand, and a hand strap for enhanced usability and protection.

Safety Information

- Ensure the tablet is securely seated within the case to prevent accidental dislodgement.
- Avoid exposing the case to extreme temperatures or direct sunlight for prolonged periods.
- Keep the case away from sharp objects to prevent damage to the PU leather material.
- Do not use harsh chemicals or abrasive cleaners on the case; use a soft, damp cloth for cleaning.

Package Contents

The package contains the following item:

- 1 x INSOLKIDON Tablet Case (Black)

Operating and Usage

Folding Stand Function

The case features a foldable cover that transforms into a stand, allowing for hands-free viewing in landscape orientation. This is ideal for watching videos, making video calls, or typing.



Image: The black tablet case with a tablet inside, positioned in the folding stand mode, showcasing its viewing angle.



Image: A close-up front view of the tablet securely placed in the INSOLKIDON case, utilizing the folding stand feature.



Image: A person comfortably using a tablet that is propped up by the INSOLKIDON case's stand function, demonstrating practical use.



Image: Two perspectives of the tablet case, one showing it folded into a stand and another with a tablet inserted, highlighting its versatile design.

Integrated Hand Strap

The case includes an integrated hand strap on the back, providing a secure and comfortable grip when holding the tablet, reducing the risk of accidental drops.



Image: The back of the black tablet case, clearly showing the integrated hand strap for secure holding.



Image: Two images side-by-side. One shows a person holding the tablet securely using the hand strap. The other shows the case in stand mode.

Maintenance

- **Cleaning:** Wipe the case regularly with a soft, slightly damp cloth to remove dust and fingerprints.
- **Stains:** For stubborn stains, use a mild soap solution on a cloth and gently wipe the affected area, then dry thoroughly.
- **Avoid:** Do not use alcohol, solvents, or abrasive cleaners, as these can damage the PU leather

material.

- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight.

Troubleshooting

Case Does Not Fit Properly

Cause: Incorrect tablet model or improper installation.

Solution: Verify that your tablet is the DOO-GEE Tab E3 Pro 13-INCH model. Re-install the tablet, ensuring it is fully seated and aligned within the case.

Tablet Slips from Stand

Cause: Improper positioning of the stand or unstable surface.

Solution: Ensure the folding stand is fully extended and locked into position. Place the tablet on a flat, stable surface.

Specifications

Feature	Description
Brand	INSOLKIDON
Compatible Devices	DOO-GEE Tab E3 Pro 13-INCH Tablet
Material	PU Leather, Fabric
Color	Black
Special Features	Adjustable Stand, Anti-Slip, Shockproof, Hand Strap
Form Factor	Cover
Protection	Dirt-Resistant, Shockproof, Scratch Resistant

Warranty and Support

For warranty information or product support, please contact your retailer or the manufacturer directly. Please refer to the packaging or purchase documentation for specific contact details.