



[Manuals.plus](#) /

› [Samsonite](#) /

› Samsonite Elevation Plus 30-Inch Large Checked Luggage Instruction Manual

Samsonite 148761-1549

Samsonite Elevation Plus 30-Inch Large Checked Luggage Instruction Manual

Model: 148761-1549

INTRODUCTION

This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your Samsonite Elevation Plus 30-Inch Large Checked Luggage. Please read these instructions carefully before using your luggage to ensure optimal performance and longevity.

The Samsonite Elevation Plus collection is designed for modern travelers, featuring durable materials and thoughtful organization. This large checked suitcase offers ample space and convenient features for extended journeys.



Image: Front view of the Samsonite Elevation Plus 30-Inch Large Checked Luggage in Midnight Blue.

SETUP

Before your first use, perform the following steps:

1. **Unpacking:** Remove all packaging materials, including plastic wraps and protective inserts. Inspect the luggage for any signs of damage during transit.
2. **Handle Adjustment:** Extend the RightHeight Handle System by pressing the release button and pulling the handle upwards. Adjust it to a comfortable height. Ensure it locks securely into place at your desired increment.
3. **Wheel Inspection:** Verify that all eight spinner wheels rotate freely and are securely attached.

OPERATING INSTRUCTIONS

RightHeight Handle System

The RightHeight Handle System allows for multiple 1-inch incremental height adjustments. To adjust, press the button located on the handle grip and extend or retract the handle to your preferred height. Release the button to lock the handle in position. This system is designed for ergonomic comfort and personalized fit.



Image: A hand demonstrating the adjustment of the RightHeight Handle System.

360° Dual Spinner Wheels

Your luggage is equipped with recessed 360° dual spinner wheels. These wheels provide stability and allow for smooth, multi-directional movement. To maneuver, simply push or pull the luggage in any direction. The recessed design helps protect the wheels from impact.



Image: Close-up view of the durable dual spinner wheels.

Expandable Packing Capacity

For additional packing space, your luggage features a 2-inch expansion zipper. Locate the secondary zipper around the perimeter of the main compartment. Unzip this section to expand the luggage, providing extra room for your belongings. Zip it back up to return to its standard size.



Image: Side view illustrating the luggage expansion zipper.

Internal Organization

The interior of your luggage is designed for efficient packing:

- **Modular Packing Panel:** Use this panel to compress clothes and keep them organized.
- **Clean Chroma Lining:** The interior lining helps protect your items.
- **PEVA-lined Wet Pouch:** Ideal for storing damp items or toiletries to prevent leaks.
- **Lined Bottom Pocket:** Provides additional storage for smaller items.
- **Compression Panel with "U" Pocket:** Helps secure contents and offers an extra pocket.
- **"X" Cross Straps:** Secure your packed items to minimize shifting during travel.
- **Expandable Zip & Expand Laundry Bag:** A dedicated bag for dirty laundry, which can be expanded for more capacity.



Image: Open luggage interior showing the modular packing panel, straps, and various pockets.

Smart Storage Features

- **Quick-Access Stash Pocket:** A soft-lined exterior pocket for items you need to reach quickly.
- **AirTag Holder:** A dedicated holder for an Apple AirTag (not included) to help track your luggage.
- **Retractable ID Tag:** For easy identification of your luggage.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your luggage.

- **Exterior Cleaning:** For general cleaning, wipe the polyester fabric with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners. For tougher stains, a specialized fabric cleaner suitable for polyester may be used, following the product instructions.
- **Interior Cleaning:** The Clean Chroma Lining can be wiped with a damp cloth. For spills in the PEVA-lined wet pouch, rinse and air dry thoroughly.
- **Wheel Care:** Periodically check the wheels for debris (hair, lint, etc.) and remove them. If wheels become stiff, a small amount of silicone-based lubricant can be applied to the axle.
- **Zipper Maintenance:** Keep zippers free of dirt and debris. If a zipper becomes stiff, apply a small amount of zipper lubricant or wax.
- **Handle Care:** Ensure the handle mechanism remains clean. Avoid forcing the handle if it feels stuck.
- **Storage:** Store your luggage in a clean, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

If you encounter issues with your luggage, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Handle is stuck or difficult to extend/retract.	Debris in the mechanism, bent handle tubes, or excessive weight.	Check for and remove any debris. Do not force the handle. If bent, contact Samsonite customer service.
Wheels are not rolling smoothly.	Debris caught in wheels, worn bearings, or lack of lubrication.	Clean wheels of any debris. Apply a silicone-based lubricant to the wheel axles. If still problematic, contact Samsonite customer service.
Zipper is jammed or difficult to move.	Fabric caught in zipper teeth, dirt/debris, or bent teeth.	Carefully pull any fabric away from the zipper teeth. Clean the zipper with a brush. Apply zipper lubricant or wax.
Luggage appears unbalanced when standing.	Uneven packing distribution.	Repack items to distribute weight evenly, especially heavier items towards the bottom.

SPECIFICATIONS

Feature	Detail
Model Number	148761-1549
UPC	043202975189
Size	Large (30-Inch)
Item Dimensions (L x W x H)	18.5"L x 9.5"W x 27"H
Item Weight	5.71 Kilograms

Feature	Detail
Color	Midnight Blue
Material Type	Polyester (Recyclex RPET fabric)
Shell Type	Softside
Wheel Type	Spinner
Number of Wheels	8
Expansion	2 inches

WARRANTY AND SUPPORT

Samsonite products are manufactured to stringent standards and undergo rigorous quality control. For information regarding the product warranty, please refer to the warranty card included with your purchase or visit the official Samsonite website.

If you require assistance, have questions, or need to report a defect, please contact Samsonite customer service directly. Contact details can typically be found on the Samsonite website or on your purchase documentation.