

SMEG SKC01

SMEG Collezione Sparkling Water Maker SKC01 Instruction Manual

Model: SKC01

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your SMEG Collezione Sparkling Water Maker. Please read these instructions carefully before first use and retain them for future reference. The SMEG Sparkling Water Maker allows you to transform plain tap water into sparkling water with adjustable carbonation levels, without the need for electricity or batteries.



Image 1: SMEG Collezione Sparkling Water Maker in Matte Black.

2. SAFETY INFORMATION

- Use only potable water for carbonation. Do not carbonate any liquid other than water.
- Ensure the carbonating bottle is securely attached before operating the machine.
- Do not remove the carbonating bottle during carbonation.
- Keep the appliance away from direct heat sources and out of reach of children.
- Only use SMEG-approved carbonating bottles and standard 60L CO₂ cylinders.
- Do not place the carbonating bottle in a dishwasher or expose it to extreme temperatures.
- If the appliance is damaged, do not attempt to repair it yourself. Contact customer support.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- SMEG Sparkling Water Maker Unit
- 1L Tritan Renew Bottle with Lid

- Drip Tray Grill
- Instruction Manual (this document)
- Warranty Information
- Quick Start Guide

Note: The CO₂ cylinder is sold separately and is not included in the package.

4. SETUP

4.1 Installing the CO₂ Cylinder

1. Place the sparkling water maker on a flat, stable surface.
2. Gently lay the unit on its side.
3. Unscrew the protective cap from the CO₂ cylinder.
4. Insert the CO₂ cylinder into the opening at the bottom of the unit. Screw it clockwise until it is firmly secured. Do not overtighten.
5. Return the unit to an upright position.



Image 2: CO₂ cylinder installation area on the base of the unit.

4.2 Preparing the Carbonating Bottle

1. Fill the 1L Tritan Renew bottle with cold potable water up to the MAX fill line. Do not overfill.
2. Ensure the bottle is clean and free from any foreign objects.



Image 3: Carbonating bottle with MAX fill line visible.

5. OPERATING INSTRUCTIONS

5.1 Attaching the Carbonating Bottle

1. Tilt the carbonating bottle slightly and insert it into the nozzle opening.
2. Push the bottle upwards and then rotate it clockwise until it locks into place. The bottle should feel secure.



Image 4: Carbonating bottle attached to the SMEG Soda Maker.

5.2 Carbonating the Water

1. Once the bottle is securely attached, press the carbonation button located on the top of the unit.
2. Press and hold the button for 1-2 seconds for light carbonation, 2-3 seconds for medium, or 3-4 seconds for strong carbonation. You will hear a buzzing sound as the water carbonates.
3. Release the button when you achieve your desired level of fizziness.

Your browser does not support the video tag.

Video 1: Official SMEG video demonstrating how to use the SKC01 Sparkling Water Maker.

5.3 Removing the Carbonating Bottle

1. After carbonation, wait a few seconds for the excess pressure to release.
2. Rotate the bottle counter-clockwise and gently pull it downwards to remove it from the unit.
3. Cap the bottle immediately to retain carbonation.



Image 5: SMEG Soda Maker with bottle removed.

5.4 Recipe Ideas

Your SMEG Sparkling Water Maker can be used to create a variety of refreshing drinks. Here are some examples:

Your browser does not support the video tag.

Video 2: SMEG Sparkling Water Grapefruit Recipe demonstration.

Your browser does not support the video tag.

Video 3: SMEG Sparkling Water Berry Recipe demonstration.

Your browser does not support the video tag.

Video 4: SMEG Sparkling Water Mojito Recipe demonstration.

6. MAINTENANCE

6.1 Cleaning the Sparkling Water Maker Unit

- Wipe the exterior of the unit with a soft, damp cloth.
- Do not immerse the unit in water or use abrasive cleaners.
- Clean the drip tray and grill regularly with mild soap and water.

6.2 Cleaning the Carbonating Bottle

- Wash the carbonating bottle with lukewarm water and mild dish soap.
- Use a bottle brush to clean the interior thoroughly.
- Rinse thoroughly and allow to air dry.
- Do not wash the bottle in a dishwasher or use hot water above 40°C (104°F).

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No carbonation or weak carbonation	CO ₂ cylinder is empty or not properly installed. Bottle not filled with cold water. Bottle not securely attached.	Replace CO ₂ cylinder. Ensure cylinder is tightly screwed in. Use cold water. Securely attach the bottle.
Water leaking during carbonation	Bottle not securely attached. Water filled above MAX line.	Ensure bottle is correctly locked into place. Do not fill water above the MAX line.
Difficulty removing bottle	Residual pressure in the bottle.	Wait a few seconds after carbonation for pressure to release before twisting and pulling.

8. SPECIFICATIONS

Brand: Smeg

Model Name: SMEG Sparkling Water Maker

Model Number: SKC01BLMUS (SKC01)

Color: Matte Black

Material: Aluminum, Plastic, Stainless Steel

Product Dimensions (D x W x H): 9.75" x 5.25" x 16.5"

Item Weight: 3.6 Pounds

Capacity: 1 Liter

Power Source: Manual

Operation Mode: Manual

Compatible CO₂ Cylinders: Standard 60L cylinders

UPC: 812895026511

9. WARRANTY AND SUPPORT

For detailed warranty information, product registration, and additional support, please scan the QR code on your unit to access the MY SMEG Assistant App. The app also provides video tutorials and sparkling drink recipes.



Image 6: QR code for MY SMEG Assistant App.

You can also visit the official SMEG website for customer service and support resources.