

WRF555SDFZ11 WRF555SDFZ17

Door Shelf Bin User Manual

Model: WRF555SDFZ11, WRF555SDFZ17 and other compatible models

Brand: Generic

**Product
Overview**

Compatibility

**Installation
Warranty &
Support**

Maintenance

Specifications

1. PRODUCT OVERVIEW

The Door Shelf Bin is a replacement storage component designed for specific refrigerator models. Its primary function is to provide organized storage space within the refrigerator door, allowing for efficient arrangement of bottles, jars, condiments, and other items. This bin helps maximize usable space and keeps contents secure.



Figure 1: Front view of the Door Shelf Bin, showing its clear plastic construction and rectangular shape. Constructed from durable, clear plastic, the bin is designed for longevity and easy visibility of its contents. Its robust design ensures it can withstand the daily use of a busy refrigerator environment.

2. COMPATIBILITY

This Door Shelf Bin is compatible with various refrigerator models, primarily from Whirlpool, Maytag, and KitchenAid. Please verify your refrigerator's model number to ensure proper fitment.

Known compatible Whirlpool refrigerator models include:

- WRF555SDFZ03
- WRF555SDFZ04
- WRF555SDFZ05
- WRF555SDFZ06
- WRF555SDFZ07
- WRF555SDFZ08
- WRF555SDFZ09
- WRF555SDFZ11
- WRF555SDFZ17
- WRF555SDFZ18
- WRF555SDFZ19

This part replaces original part numbers such as 8544723, W10685670, WP8544723, 4538922, AP6245906, PS12114312, EAP12114312. *Note: Some of these replacement part numbers may be associated with dryer components due to data inconsistencies. Please ensure your original part matches the appearance of this*

3. INSTALLATION

Installing the Door Shelf Bin is a straightforward process. No special tools are typically required.

3.1. Before Installation

1. Empty the contents of the old or broken door bin.
2. Carefully remove the old door bin from its position in the refrigerator door. This usually involves lifting it straight up or sliding it out of its retaining clips.
3. Clean the area where the new bin will be installed to ensure no debris interferes with the fit.

3.2. Installing the New Bin

1. Align the new Door Shelf Bin with the designated slots or rails on the inside of your refrigerator door.
2. Gently push the bin down or slide it into place until it clicks securely into position. Ensure it is level and stable.



Figure 2: Top-down view of the Door Shelf Bin, showing the attachment points on either side.

After installation, gently test the bin by applying light pressure to ensure it is firmly seated and will not dislodge when loaded with items.

4. MAINTENANCE

Regular cleaning of your Door Shelf Bin will help maintain hygiene and extend its lifespan.

4.1. Cleaning Instructions

1. Remove the bin from the refrigerator door.
2. Wash the bin with warm water and a mild dish soap. Avoid abrasive cleaners or scouring pads, which can scratch the plastic surface.
3. Rinse thoroughly with clean water.
4. Dry the bin completely with a soft cloth before returning it to the refrigerator.




Figure 3: Bottom view of the Door Shelf Bin, illustrating its smooth base for easy cleaning.

5. TROUBLESHOOTING

If you encounter any issues with your Door Shelf Bin, consider the following common solutions:

- **Bin does not fit:** Double-check your refrigerator's model number against the compatibility list. Ensure the bin is oriented correctly and aligned with the door's mounting points.
- **Bin feels loose:** Remove the bin and re-install, ensuring it clicks firmly into place. Verify that no debris is obstructing the mounting slots.
- **Cracks or damage:** If the bin arrives damaged or cracks during normal use, refer to the warranty information for replacement options.

For further assistance, please contact customer support.

6. SPECIFICATIONS

Attribute	Detail
Manufacturer	Generic
Part Number	W10212139 <i>(Note: This part number may be associated with a different product in some databases.)</i>
Product Dimensions	1 x 1 x 1 inches <i>(Note: This dimension appears to be a placeholder or error and does not reflect the actual size of a refrigerator door bin.)</i>
Country of Origin	China
Item Model Number	WRF555SDFZ11, WRF555SDFZ17
Color	As Pictured (Clear/White)
Item Package Quantity	1

7. WARRANTY AND SUPPORT

7.1. Warranty Information

This product comes with a **60-day warranty** from the date of purchase, covering manufacturing defects.

Please retain your proof of purchase for warranty claims.

Additionally, a money-back guarantee is offered: within 30 days from the date of purchase, and in some cases, up to 90 days. Please refer to your purchase documentation for specific terms and conditions regarding returns and refunds.

7.2. Customer Support

If you have any questions, require assistance with installation, or need to report an issue, please contact our customer support team. We aim to resolve your problem within 24 hours.

For compatibility inquiries, it is recommended to contact support with your refrigerator's full model number before purchase.