



Manuals.plus /

› AMZASA /

› AMZASA Antique Brass Gold Chandelier with Shades (Model AS9028-5AB) Instruction Manual

AMZASA AS9028-5AB

AMZASA Antique Brass Gold Chandelier with Shades (Model AS9028-5AB) Instruction Manual

Model: AS9028-5AB | Brand: AMZASA

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your AMZASA Antique Brass Gold Chandelier with White Fabric Shades. Please read all instructions carefully before beginning installation and retain this manual for future reference.

- **Electroplating Process:** The chandelier features an electroplated antique brass gold finish with white fabric shades and five lights. This process enhances its luxurious appearance, resists tarnishing and corrosion, and provides a warm, beautiful light.
- **Fixture Size:** The 5-light chandelier has a cage frame size of 25" (Diameter) x 19.3" (Height). The canopy is 4.72" and the adjustable chain is 69", allowing for various hanging heights and compatibility with sloping or parallel ceilings.
- **Versatile Use:** Suitable for dining rooms, breakfast areas, kitchens, islands, bars, living rooms, bathrooms, bedrooms, balconies, porches, corridors, lofts, stairwells, craft rooms, entryways, hallways, foyers, offices, and farmhouses.
- **Easy Assembly:** The golden metal robotic arms are pre-assembled. Simply twist and adjust to your preferred angle.
- **Quality Materials:** The white textile lampshades are made from new materials to prevent yellowing.

SAFETY INFORMATION

Always turn off the main power supply at the circuit breaker before installing, cleaning, or performing any maintenance on the light fixture. Consult a qualified electrician if you are unsure about any part of the installation process. Ensure all electrical connections comply with local codes and ordinances. Use only the specified bulb type and wattage to avoid fire hazards.

WHAT'S IN THE BOX

Carefully unpack all components and check against the list below:

- Chandelier frame with pre-wired sockets
- White Fabric Shades (5 pieces)
- Adjustable chain
- Mounting hardware (canopy, screws, wire nuts)
- Instruction manual

Note: Bulbs are not included. This fixture requires 5 E12 base bulbs, max 40 watts each (Incandescent or Halogen recommended).

SETUP AND INSTALLATION

Follow these steps for proper installation. It is recommended to have two people for installation.

Step 1: Unboxing and Component Check

Carefully open the packaging and remove all components. Verify that all parts listed in "What's in the Box" are present and undamaged.

Electroplated Finish Gold




Image: Chandelier dimensions (25" Dia x 19.3" H) and compatibility with flat, sloped, and vaulted ceilings. The adjustable chain is 69" long.

Step 2: Assembling the Chandelier Body

The main arms of the chandelier are pre-assembled. You will need to connect the central rod and feed the electrical wires through it. Secure the connections as shown in the video.

Your browser does not support the video tag.

Video: Detailed assembly and installation guide for the AMZASA chandelier, demonstrating how to connect the main body, attach the chain, and prepare for ceiling mounting.

After connecting the central rod, attach the chain to the top loop, ensuring the electrical wire is threaded through the chain and canopy.

Step 3: Attaching the Fabric Shades

Once the main structure is assembled, carefully place each white fabric shade onto its respective light socket. Secure them in place using the provided rings or fasteners.



Image: Close-up view highlighting the adjustable robotic arm design and the white fabric shades, demonstrating how they fit onto the light sockets.

Step 4: Electrical Connection and Mounting

Before connecting to the ceiling, ensure the power is OFF at the circuit breaker. Connect the fixture's wires to your household wiring (typically black to black, white to white, and ground to ground). Mount the canopy to the ceiling junction box using the provided hardware. Adjust the chain length to your desired hanging height.

OPERATING INSTRUCTIONS

After successful installation, insert 5 E12 base bulbs (max 40W each) into the sockets. Restore power at the circuit breaker. The chandelier can be operated via a standard wall switch. This fixture is compatible with dimmable bulbs and dimmer switches (sold separately) for adjustable brightness.

TURN ON



TURN OFF



Image: Comparison of the chandelier with lights turned ON, showing a warm glow through the fabric shades, and lights turned OFF, displaying the clean white shades.

MAINTENANCE

- **Cleaning:** Turn off power before cleaning. Use a soft, dry cloth to wipe the metal parts. For the fabric shades, gently dust with a soft brush or vacuum with a brush attachment. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure power is off and bulbs have cooled before replacing. Unscrew old bulbs and screw in new E12 base bulbs (max 40W).

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	Power is off; loose wiring; faulty bulb.	Check circuit breaker; verify wiring connections; replace bulb.
Flickering lights.	Loose bulb; incompatible dimmer; unstable power.	Tighten bulbs; ensure dimmer compatibility; consult electrician.
Chandelier hangs unevenly.	Improper mounting; uneven chain adjustment.	Re-adjust mounting hardware or chain links.

SPECIFICATIONS

Feature	Detail
Brand	AMZASA
Model Name	AS9028-5AB
Color	Electroplated Gold
Material	Fabric shade, Iron, Metal
Style	Farmhouse, Modern, Industrial
Light Fixture Form	Chandelier
Product Dimensions	25"L x 19.3"W x 79.7"H (max hanging height)
Indoor/Outdoor Usage	Indoor
Power Source	AC
Special Feature	Adjustable Height, Dimmable (with compatible bulbs/switch)
Light Source Type	Incandescent, Halogen (E12 base)
Number of Light Sources	5
Voltage	110 Volts
Wattage	40 watts (per bulb, max)
Bulb Base	E12
Assembly Required	Yes
Item Weight	5.94 pounds (approx. 2.7 kg)

WARRANTY AND SUPPORT

The AMZASA Chandelier comes with a **3-year warranty** as specified by the manufacturer. For any issues or support, please contact AMZASA customer service. Additionally, Amazon offers a **30-day return/replacement policy** for this product.

For further assistance, please visit the AMZASA Store on Amazon.

