Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEDIARY 20 Inch Low Profile

LEDIARY 20 Inch Low Profile Ceiling Fan with Lights and Remote Instruction Manual

Model: 20 Inch Low Profile | Brand: LEDIARY

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your LEDIARY 20 Inch Low Profile Ceiling Fan with Lights and Remote. This modern ceiling fan is designed to provide optimal airflow and versatile lighting for various indoor spaces, featuring a 7-blade design, 6 adjustable speeds, dimmable LED lighting with three color temperatures, and convenient control via remote or a dedicated mobile application.

2. Safety Information

- Always turn off power at the circuit breaker before installation or maintenance.
- Ensure all electrical connections comply with local codes and ordinances.
- Consult a qualified electrician if you are unsure about wiring procedures.
- Do not tug on wires forcefully during installation.
- Ensure the mounting bracket is securely fastened to a structural ceiling joist or a suitable outlet box rated for fan support.
- Keep hands clear of fan blades during operation.

3. Package Contents

Carefully unpack all components and inspect for any damage. If any parts are missing or damaged, contact customer support.

- Lamp Body
- Canopy Part
- Fan Blade
- Blade Cap
- Remote Control Kit (includes 2 AAA batteries)
- Frame Arm (x3)
- Screws and Wiring Connectors



Image: LEDIARY 20 Inch Low Profile Ceiling Fan with Lights and Remote, showcasing its sleek design and compact size.

4. Setup and Installation

Follow these steps for proper installation. A detailed installation video is provided below for visual guidance.

4.1. Assembly

1. Align and secure the three lamp body sections inward.
2. Install each frame arm downward into its respective lamp body slot.
3. Secure each arm with two frame arm screws.
4. Install the fan blade onto the motor shaft.
5. Install the blade cap by tightening it counter-clockwise.

4.2. Mounting to Ceiling

1. Press down the buckle on the hanger plate.
2. Attach the hanger plate to the ceiling junction box using appropriate J-box screws.

3. Connect the wiring: Black to live cable, White to neutral cable, Green to ground cable. Ensure all connections are secure.
4. Push the assembled lamp body into the canopy part on the ceiling until you hear a click, ensuring it is securely fastened.

4.3. Installation Video Guide

Your browser does not support the video tag.

Video: Step-by-step installation guide for the LEDIARY 20 Inch Ceiling Fan. This video demonstrates unboxing, assembly of components, wiring connections, and final mounting to the ceiling.

5. Operating Instructions

Your LEDIARY ceiling fan offers multiple control options and features for personalized comfort.

5.1. Remote Control and App Control

The fan can be controlled using the included remote control or a dedicated mobile application. The remote allows for easy adjustment of fan speeds, light settings, timer, and reverse modes. The app requires Bluetooth support for connectivity.



Image: The remote control for the LEDIARY ceiling fan, highlighting buttons for various functions including fan speed, light brightness, color temperature, and timer.




Image: A smartphone displaying the mobile application interface for controlling the LEDIARY ceiling fan, showing options for fan speed, light settings, and other features.

5.2. Fan Speed Settings

The fan features 6 adjustable wind speeds to suit your comfort needs, from a gentle breeze to robust circulation. The DC motor ensures

quiet operation, typically below 35dB.

- **Speeds 1-2:** Soft wind, ideal for sleeping.
- **Speeds 3-4:** Natural wind, suitable for working or general comfort.
- **Speeds 5-6:** Cool wind, for active environments or quick cooling.



Image: Visual representation of the LEDIARY ceiling fan's 6-speed settings, showing varying levels of airflow for different activities like sleeping, working, and

exercising.

5.3. Dimmable LED and Color Temperatures

Adjust the lighting to create the desired ambiance with 10%-100% stepless dimming and three color temperature options:

- **3000K:** Warm White for a cozy atmosphere.
- **4000K:** Neutral Light for general illumination.
- **6000K:** Cool White for bright task lighting.

The fan includes a memory function that retains the last used temperature and brightness settings when turned on again.




Image: The LEDIARY ceiling fan light demonstrating its three adjustable color temperatures: 3000K Warm White, 4500K Natural Light, and 6000K Cold White, along with stepless dimming.

5.4. Reversible Function

The fan features a reversible motor for year-round use:

- **Summer Mode (Downward Airflow):** Creates a cooling effect by pushing air down.
- **Winter Mode (Upward Airflow):** Recirculates warm air near the ceiling, distributing it throughout the room.



Image: Illustration of the LEDIARY ceiling fan's reversible function, depicting downward airflow for summer cooling and upward airflow for winter warmth circulation.

5.5. Timer Function

Set a 2-hour sleep timer for automatic fan and light shutdown, promoting energy efficiency and undisturbed rest.

6. Maintenance

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and light fixture. Do not use abrasive cleaners or solvents.
- **Inspection:** Periodically check all connections and screws to ensure they are tight and secure.
- **Light Source:** The LED light source is integrated and not user-replaceable. Contact customer support for any issues.

7. Troubleshooting

If you encounter issues with your fan, refer to the common problems and solutions below. For further assistance, consult the installation guide video or contact customer support.

7.1. Light Not On After Installation

If the light does not turn on after installation, check the following:

1. **Pin Alignment:** Ensure the pin connector on the lamp body is inserted level into the hanger plate. Downward or upward tilt will prevent operation.
2. **Correct if Needed:** Gently adjust any tilted pins back to the horizontal position.

7.2. General Troubleshooting Tips

- **No Power:** Check the circuit breaker and wall switch to ensure power is supplied to the fan.
- **Remote Not Responding:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fan.
- **Fan Not Spinning:** Verify all wiring connections are secure. Ensure the fan blades are not obstructed.

7.3. Troubleshooting Video Guide

Your browser does not support the video tag.

Video: The installation guide video also includes a section on troubleshooting common issues, particularly regarding the light not functioning after installation. Refer to the end of the video for this segment.

8. Specifications

Brand	LEDIARY
Model Name	20 Inch Low Profile
Product Dimensions	20"D x 20"W x 3"H
Item Weight	5.37 pounds
Power Source	DC
Wattage	45 watts
Number of Speeds	6
Control Method	App, Remote, Voice
Special Feature	Adjustable Color Temperature, Dimmable, Energy Efficient, Timer
Room Type	Living Room, Bedroom, Office, Nursery

Indoor/Outdoor Usage	Indoor
Batteries	2 AAA batteries required (included for remote)

9. Warranty and Support

Your LEDIARY 20 Inch Low Profile Ceiling Fan is backed by a dedicated 2-year after-sales service. For any quality concerns, shipping damage, or technical assistance, please contact LEDIARY customer support. Our team is committed to providing prompt solutions to your queries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F89XGJQ4

More documents and user manuals: **https://manuals.plus/**