

[Manuals.plus](#) /

> [GRUSIGN](#) /

> GRUSIGN 71" Kitchen Pantry Cabinet with Charging Station Instruction Manual

GRUSIGN BG-XC-GREY

GRUSIGN 71" Kitchen Pantry Cabinet with Charging Station Instruction Manual

Model: BG-XC-GREY

Brand: GRUSIGN

1. INTRODUCTION AND OVERVIEW

This versatile GRUSIGN 71" Kitchen Pantry Cabinet is designed to provide generous storage and functional utility for your kitchen, dining room, or coffee bar. Featuring a classic farmhouse design, it seamlessly blends with various home decors while offering practical solutions for organizing appliances, dishes, and groceries.

Key Features:

- **Ample Storage Space:** Includes four adjustable shelves and a large-capacity drawer for organizing various items.
- **Built-In Charging & Appliance Space:** Equipped with two AC outlets and two USB ports, ideal for coffee makers, microwaves, and toasters.
- **Classic Farmhouse Design:** Rustic barn doors and metal handles complement any decor.
- **Durable & Sturdy Construction:** Crafted from high-density wood with anti-tip hardware for stability.
- **Versatile Organizational Solution:** Adaptable for kitchen storage, coffee station, dining room buffet, or entryway organizer.



Figure 1: Key Features of the GRUSIGN Kitchen Pantry Cabinet

2. SETUP AND ASSEMBLY

Before beginning assembly, ensure all parts and hardware are present by comparing them with the included parts list. Follow the step-by-step instructions carefully. Two people are recommended for assembly.

Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Verify all numbered parts and hardware against the packing list.
2. **Assemble Base Structure:** Follow the diagrams in the provided manual to connect the base panels and side supports using the designated fasteners.
3. **Install Drawer Slides:** Secure the drawer slides to the cabinet side panels as indicated. Ensure they are level and aligned for smooth operation.
4. **Construct Drawers:** Assemble the drawer boxes and attach the corresponding drawer slides.

5. **Attach Back Panels:** Secure the back panels to the assembled sections of the cabinet.
6. **Mount Countertop:** Carefully place and secure the countertop onto the base cabinet.
7. **Assemble Upper Hutch:** Construct the upper hutch section, including shelves and side panels.
8. **Install Charging Station:** Insert the built-in charging station into its designated cutout on the countertop.
9. **Attach Doors:** Mount the barn-style doors to the cabinet using the provided hinges. Adjust hinges as needed for proper alignment.
10. **Install Handles:** Attach all black metal handles to the drawers and doors.
11. **Secure Anti-Tipping Device:** For safety, attach the anti-tipping hardware to the top of the cabinet and secure it to a wall stud.

Visual Guides:




Figure 2: Product Dimensions for Assembly Reference

Your browser does not support the video tag.

Video 1: Step-by-step installation guide for the GRUSIGN Kitchen Pantry Cabinet, provided by the seller.

Your browser does not support the video tag.

Video 2: Detailed installation video for the Kitchen Pantry Cabinet, demonstrating each step of the assembly process.

3. OPERATING INSTRUCTIONS

Using the Charging Station:

The integrated charging station features two AC outlets and two USB ports. To use, simply plug your appliances or devices into the available ports. Ensure the main power switch (if present) is in the 'ON' position. This feature is designed to keep your countertop appliances powered and your devices charged conveniently.



Figure 3: Built-in Charging Station

Adjustable Shelves:

The cabinet features four adjustable shelves. To adjust a shelf, remove any items, then carefully lift the shelf and reposition the support pegs to the desired height. Ensure all four pegs are securely inserted into the corresponding holes before placing items back on the shelf.

Smooth-Glide Drawers:

The large-capacity drawer operates on smooth-glide runners. To open, gently pull the handle. To close, push firmly until it is fully shut. Avoid forcing the drawer if it encounters resistance.



Figure 4: Organized Drawer Storage

4. MAINTENANCE AND CARE

To ensure the longevity and appearance of your GRUSIGN Kitchen Pantry Cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spill Management:** The cabinet features waterproof, oil-resistant, and stain-resistant surfaces. Promptly wipe up spills to prevent staining.
- **Scratch Prevention:** While the surfaces are scratch-resistant, use placemats or coasters under hot items or items that may scratch the surface.

- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Avoid Overloading:** Do not exceed the weight limit of 90 pounds for the shelves to prevent damage.



High load-bearing



Waterproof and anti-corrosion



Oil-resistant and stain-resistant



Scratch-proof

Figure 5: Durability Features

5. TROUBLESHOOTING

Common Issues and Solutions:

- **Wobbly Cabinet:** Ensure all cam locks and screws are fully tightened. Verify the cabinet is on a level surface. Adjust leg levelers if applicable.
- **Drawers Not Sliding Smoothly:** Check that the drawer slides are correctly installed and free of obstructions. Lubricate slides with a silicone-based spray if needed.
- **Doors Not Aligning:** Adjust the hinges on the doors. Most hinges allow for minor adjustments in height, depth, and side-to-side movement.
- **Charging Station Not Working:** Ensure the power cord is securely plugged into a wall outlet and the charging station itself. Check for any tripped circuit breakers.

6. SPECIFICATIONS

Feature	Detail
Brand	GRUSIGN
Color	Grey
Product Dimensions	15"D x 41.3"W x 70.9"H
Special Features	Adjustable Shelf, Anti-Tipping, Built-In Charging Station, Heavy Duty, Scratch Resistant
Mounting Type	Floor Mount
Room Type	Dining Room, Kitchen, Living Room
Weight Limit	90 Pounds
Number of Shelves	4
Item Weight	119 Pounds
Material	Engineered Wood, Metal
Assembly Required	Yes

7. WARRANTY AND SUPPORT

This GRUSIGN Kitchen Pantry Cabinet is backed by a 12-month warranty for worry-free use, covering manufacturing defects. For any questions, missing parts, or assistance with assembly or operation, please contact GRUSIGN customer support. Refer to your purchase documentation for specific contact details or visit the official GRUSIGN store on Amazon.

GRUSIGN Store: [Visit the GRUSIGN Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F8B4LHPN>

More documents and user manuals: <https://manuals.plus/>