

BIGASUO 159k

BIGASUO 15.6" Frameo Digital Picture Frame User Manual

Model: 159k

1. INTRODUCTION

The BIGASUO 15.6" Frameo Digital Picture Frame offers a modern way to display and share your favorite photos and videos. Featuring a 1920 x 1080 IPS Full HD touch screen and 64GB of internal storage, it allows for easy sharing from anywhere via the Frameo app. This manual will guide you through the setup and operation of your new digital picture frame.

2. SETUP

2.1 Package Contents

Before beginning, ensure all items are present in the package:

- 1 x 15.6" Frameo Digital Picture Frame
- 1 x AC Adapter
- 1 x Frame Stand
- 1 x User Manual

Easy Setup via **SD Card & USB Drive**

1. Download photos/videos to USB flash drive/SD card
2. Insert the U disk/SD card into the opened photo frame
3. Select the photo/video to directly play or copy it in the photo frame

Note: Please make sure the SD card and USB drive are in "FAT32" format before use.



Figure 2.1: Contents included in the product package.

2.2 Initial Power-On and Wi-Fi Connection

1. Connect the AC adapter to the frame and plug it into a power outlet. The frame will power on automatically.
2. Follow the on-screen prompts to select your preferred language and time zone.
3. Connect the frame to your Wi-Fi network. Ensure you are connecting to a 2.4GHz Wi-Fi network, as 5GHz networks are not supported.

2.3 Frameo App Setup for Photo/Video Sharing

The Frameo app allows you to send photos and videos directly to your digital frame from anywhere in the world.

- Download the free "Frameo" app from the App Store (iOS) or Google Play Store (Android) on your smartphone.
- Open the app and create your profile.
- On your digital frame, navigate to the 'Add Friend' section to get a unique code.
- Enter this code into the Frameo app on your phone to link your device to the frame.

Instant & Wireless Sharing

Send photos/videos from anywhere in the world via the "frameo" app




Figure 2.2: Instant and wireless sharing of photos and videos using the Frameo app.

2.4 Importing Media via SD Card or USB Drive

The frame supports direct import of photos and videos from SD cards and USB flash drives (FAT32 format required).

1. Insert the SD card or USB flash drive into the corresponding slot on the frame.
2. The frame will prompt you to import media. Select the photos/videos you wish to import.
3. You can choose to directly play media from the drive or copy it to the frame's internal 64GB storage.

Auto-Rotate & Wall Mounted

Place the frame horizontally and vertically as you like



Figure 2.3: Easy setup and media import using SD card and USB drive.

3. OPERATING THE DIGITAL PICTURE FRAME

3.1 Display and Touch Screen Features

The 15.6-inch IPS Full HD touch screen provides a clear and vibrant display for your media.

- **Resolution:** 1920 x 1080 for vivid and lifelike colors.
- **Viewing Angle:** 178° IPS panel ensures stunning visual effects from any angle.
- **Touch Interface:** User-friendly touchscreen for simple and convenient operation.

15.6 Inch FHD Touch Screen

Showcase photo details effortlessly, easy to operate



16:9
Aspect Ratio



High Sensitivity
Touch Screen



IPS Screen



1920*1080
FHD



178° Viewing
Angle



Vibrant Color
Fidelity



Figure 3.1: High-resolution IPS Full HD Touch Screen capabilities.

3.2 Managing Photos and Videos

The frame offers ample storage and flexible management options.

- **Internal Memory:** Built-in 64GB storage can hold up to 100,000 photos.
- **Expandable Storage:** Supports SD cards and USB flash drives for easy import, export, and backup.
- **Video Playback:** Play videos with sound by inserting an SD card or USB flash drive. The Frameo app supports videos up to 15 seconds.

64GB Large Internal Memory

Built-in 64GB storage and support SD card and USB drive extended, you can store/playback more precious memories

Note: Please make sure the SD card and USB drive are in "FAT32" format before use.



SD Card



USB Drive

64GB



Figure 3.2: Large internal memory and expandable storage options.

3.3 Advanced Features

- **"Reply" Function:** Send emojis to loved ones to express appreciation for shared photos.
- **Auto-Rotate:** Photos automatically adjust orientation for desktop or wall mounts. Switch between landscape and portrait modes.
- **Slideshow:** Plays your photos smoothly in a continuous loop.
- **Custom Settings:** Adjust weather/clock display, playback order, hide/publish pictures, brightness, and sleep mode.

15.6 Inch FHD 16:9 WiFi Digital Picture Frame




Figure 3.3: Auto-rotate and wall-mounted display options.

4. MAINTENANCE

To ensure the longevity and optimal performance of your digital picture frame, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the screen and frame. Avoid using abrasive cleaners or sprays directly on the screen.
- **Placement:** Place the frame on a stable, flat surface or mount it securely on a wall. Avoid direct sunlight, extreme temperatures, and high humidity.
- **Software Updates:** Periodically check for and install software updates via the Frameo app or the frame's settings menu to ensure the best performance and access to new features.
- **Power Management:** Utilize the sleep mode feature to automatically turn the screen off during specified times, conserving energy and extending screen life.

5. TROUBLESHOOTING

If you encounter any issues with your digital picture frame, refer to the following common troubleshooting steps:

- **Frame Not Turning On:** Ensure the AC adapter is securely connected to both the frame and a working power outlet. Try a different outlet if necessary.
- **Wi-Fi Connection Issues:** Verify that your Wi-Fi network is 2.4GHz. Restart your Wi-Fi router and the digital frame. Re-enter the Wi-Fi password carefully.
- **Photos/Videos Not Appearing:** Check your internet connection. Ensure the Frameo app is updated to the latest version. Confirm that the photos/videos were successfully sent from the app. For SD/USB, ensure the drive is in FAT32 format and the files are supported (JPG, JPEG, BMP, PNG, MP4).
- **Screen Unresponsive:** Try restarting the frame by unplugging it and plugging it back in. If the issue persists, contact customer support.
- **Auto-Rotate Not Working:** Ensure the frame is placed on a stable surface or mounted correctly. Check the frame's settings to confirm auto-rotate is enabled.

6. SPECIFICATIONS

Feature	Specification
Product Dimensions	15.75 x 7.87 x 0.99 inches
Item Weight	3.19 pounds
Item Model Number	159k
Brand	BIGASUO
Color	15.6 Inch Brown Wood
Resolution	1080p
Compatible Devices	Smartphone
Screen Size	15.6 Inches

7. WARRANTY AND SUPPORT

Your BIGASUO digital picture frame comes with a standard manufacturer’s warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty duration and coverage details.

For technical support, troubleshooting assistance beyond what is covered in this manual, or warranty claims, please contact BIGASUO customer service. Contact information is typically provided on the product packaging or on the official BIGASUO website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question