

SVHT SVHT

SVHT Cordless Vacuum Cleaner User Manual

Model: SVHT

1. SAFETY INSTRUCTIONS

Please read all instructions carefully before using the SVHT Cordless Vacuum Cleaner. Retain this manual for future reference.

- This appliance is for household use only. Do not use outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Do not pick up liquids, burning or smoking materials, or sharp objects.
- Ensure the power adapter is compatible with your local power supply.
- Use only the charger supplied by the manufacturer to recharge the battery.
- Do not use the vacuum cleaner if any part is damaged. Contact customer support for assistance.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Clean the filter regularly to maintain optimal suction performance.

2. PRODUCT OVERVIEW

The SVHT Cordless Vacuum Cleaner is a powerful and versatile cleaning tool designed for various surfaces in your home. It features advanced technology for efficient and convenient cleaning.

Included Components

- 40KPA Cordless Vacuum Main Body
- 2 Extra HEPA Filters
- Battery
- Power Adapter
- 2-in-1 Brush
- Long Crevice Nozzle
- Motorized Brush Head with Anti-tangle Roller

- Telescopic Metal Tube
- Wall Mount & Screws
- Cleaning Gadget
- User Manual



Image: All components included with the SVHT Cordless Vacuum Cleaner.



Image: A visual representation of all parts included in the package.

Key Features

- **Powerful Suction:** Up to 40KPa for deep cleaning carpets, rugs, and hard floors.
- **Long-Lasting Runtime:** Up to 45 minutes in ECO mode, 20 minutes in MAX mode.
- **Advanced Green Light Tech:** Illuminates hidden dust particles for thorough cleaning.
- **Anti-Tangle Floor Brush:** V-shaped roller with soft-hard bristles to minimize hair tangles.
- **8-Stage Advanced Filtration System:** Captures 99.9% of microdust as small as 0.01 microns.
- **Lightweight & Versatile:** Main body weighs only 3 lbs, easily converts to a handheld vacuum.
- **LED Touch Screen:** Intuitive display for battery indicator, ON/OFF switch, speed button, and tangle reminder.

3. SETUP

Assembly

1. Connect the telescopic metal tube to the main vacuum body until it clicks into place.
2. Attach the motorized brush head to the other end of the telescopic tube until it clicks.
3. Ensure the battery is securely inserted into the main body.



Image: The SVHT Cordless Vacuum Cleaner fully assembled.

Charging

The battery can be charged while attached to the vacuum or separately. A full charge takes approximately 4.5 hours.

- Connect the power adapter to the battery.
- Plug the adapter into a wall outlet.
- The LED display on the main body will indicate charging status.
- For convenient storage and charging, use the provided wall mount.

Wall-mounted Storage & Charging



Image: The vacuum cleaner mounted on the wall for storage and charging.

Your browser does not support the video tag.

Video: This video demonstrates the unboxing and assembly of the SVHT Cordless Vacuum Cleaner, including how to attach accessories, the dust cup, and the motorized brush. It also shows the charging process.

4. OPERATING

Powering On/Off and Suction Modes

- Press the ON/OFF switch on the LED touch screen to start or stop the vacuum.
- Use the speed button on the LED touch screen to switch between ECO mode (up to 45 mins runtime) and MAX mode (up to 20 mins runtime).



Image: Close-up of the vacuum's LED touch screen showing battery, power, and speed settings.

Cleaning Performance

- The motorized brush head is equipped with Advanced Green Light Tech to reveal hidden dust on floors.
- The anti-tangle V-shaped roller and soft-hard bristle combination effectively cleans various floor types including hardwood, low-mid-pile carpet, tile, and marble.

Powerful Suction for Deep Cleaning



Image: The vacuum cleaner in action, highlighting its powerful suction on various debris.



Latest Green Light Technology - Spot the Hidden Dust

Image: The green light technology on the brush head illuminating dust on a hard floor.




Image: The vacuum cleaner effectively cleaning various floor surfaces including tile, carpet, hardwood, and marble.

Versatile Cleaning

The lightweight design allows the vacuum to transform into a handheld unit for cleaning curtains, furniture, car interiors, and hard-to-reach areas.

- Use the 2-in-1 brush for upholstery and delicate surfaces.
- The long crevice nozzle is ideal for narrow gaps and corners.



Meet Your All Cleaning Needs

Image: Demonstrates the vacuum's versatility for cleaning high areas, car interiors, and furniture.

Your browser does not support the video tag.

Video: This video showcases the SVHT Powerful Lightweight Cordless Vacuum Cleaner for home use, demonstrating its ease of maneuverability and cleaning capabilities.

Your browser does not support the video tag.

Video: This video highlights the SVHT 45-minute rechargeable lightweight cordless vacuum cleaner, emphasizing its long battery life and portability.

5. MAINTENANCE

Emptying the Dust Cup

The 1.5-liter dust cup features a one-touch empty design for hygienic disposal of debris.

- Position the dust cup over a trash bin.
- Press the release button to open the bottom flap and empty the contents.



Image: A woman emptying the vacuum's dust cup into a trash bin.




Image: The dust cup and filter components being emptied and washed under running water.

Filter Cleaning and Replacement

The 8-stage filtration system includes washable and reusable HEPA filters. Regular cleaning is essential for maintaining suction power.

- Remove the filter from the dust cup.
- Wash the strainer and HEPA filter with cool water. Allow them to air dry completely before reinserting.
- Replace the HEPA filter if necessary. Two replacement filters are included.

Anti-Tangle Brush Maintenance

The upgraded anti-tangle floor brush minimizes hair clogs. Use the provided cleaning gadget to remove any tangled hair from the roller.

6. TROUBLESHOOTING

If you encounter any issues with your SVHT Cordless Vacuum Cleaner, please refer to the following common solutions:

- **Weak Suction:** Please empty the dustbin, wash the strainer and HEPA filter with cool water, and replace the HEPA filter if necessary.
- **Vacuum Stops Suddenly:** Please check if there is any blockage in the tube, or if the roller brush is tangled by hair.
- **Battery Not Charging:** Ensure the power adapter is correctly connected to both the battery and a working power outlet.

7. SPECIFICATIONS

Feature	Specification
Brand	SVHT
Model Name	SVHT Cordless Vacuum Cleaner
Wattage	450 watts

Suction Power	Up to 40KPA
Battery Life	45 minutes (ECO mode) / 20 minutes (MAX mode)
Charging Time	4.5 Hours
Dust Cup Capacity	1.5 Liters
Filter Type	8-Stage High-Efficiency Filtration System with Reusable & Washable HEPA Filter
Item Weight	3 pounds
Product Dimensions	17.3"L x 10.6"W x 7.48"H
Noise Level	65 Decibels

8. WARRANTY & SUPPORT

Your SVHT Cordless Vacuum Cleaner is backed by reliable customer support.

- **1-Year Warranty:** Covers manufacturing defects and malfunctions.
- **24/7 After-Sales Service:** For any questions or assistance, please contact our support team.



Image: Customer support information detailing warranty, technical support, and customer service availability.

For more information or to explore other SVHT products, visit the [SVHT Store](#).