

## WLIVE ASNG123QX

# WLIVE ASNG123QX 6 Drawer LED Dresser User Manual

Model: ASNG123QX

## 1. INTRODUCTION

---

Thank you for purchasing the WLIVE 6 Drawer LED Dresser. This manual provides important information regarding the assembly, operation, maintenance, and troubleshooting of your new dresser. Please read these instructions carefully before assembly and retain them for future reference.

## 2. SAFETY INSTRUCTIONS

---

**WARNING: Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:**

- Always install the anti-tip device provided with the dresser.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.
- Place heaviest items in the lowest drawers.
- Do not place heavy objects on top of the dresser unless specified.

Failure to follow these warnings can result in death or serious injury.

Other safety precautions:

- Ensure all screws and fasteners are securely tightened before use.
- Do not exceed the maximum weight capacity for each drawer or the top surface.
- Keep small parts away from children during assembly to prevent choking hazards.
- Assemble on a soft, clean surface to prevent scratching the product.

## 3. PACKAGE CONTENTS

---

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or

damaged, do not proceed with assembly. Contact customer support for assistance.

**Typical components include:**

- Dresser Panels (Top, Bottom, Sides, Back)
- Drawer Fronts, Sides, and Bottoms
- Drawer Slides/Runners
- Hardware (Screws, Dowels, Cam Locks, Handles)
- LED Light Strip with Power Adapter and Remote Control
- Anti-Tip Kit
- Assembly Tools (e.g., Hex Key - often included)

## 4. ASSEMBLY AND SETUP

---

Assembly typically requires two adults. Follow the step-by-step instructions provided in the separate assembly guide included in your package. The general steps are outlined below:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface. Verify all parts against the parts list in your assembly guide.
2. **Assemble the Main Frame:** Attach the side panels to the bottom panel, then secure the back panel. Ensure all connections are tight.
3. **Install Drawer Slides:** Attach the drawer slides to the inner sides of the dresser frame according to the markings.
4. **Assemble Drawers:** Construct each drawer by attaching the sides, front, and back to the drawer bottom. Install drawer handles.
5. **Insert Drawers:** Carefully slide the assembled drawers into the dresser frame, ensuring they operate smoothly.
6. **Install LED Lighting:**
  - Locate the designated area for the LED strip installation (usually along the top or back edge).
  - Clean the surface thoroughly before applying the adhesive backing of the LED strip.
  - Press the LED strip firmly into place.
  - Connect the LED strip to the power adapter and then plug the adapter into a standard electrical outlet.
7. **Install Anti-Tip Kit:** This is a critical safety step.
  - Secure one bracket to the back of the dresser near the top edge using the provided screws.
  - Position the dresser against the wall in its final location.
  - Mark the wall through the second bracket hole, ensuring the strap is taut.
  - Drill a pilot hole (if necessary for your wall type) and secure the second bracket to the wall using appropriate hardware.
  - Thread the strap through both brackets and secure it tightly.

## 5. OPERATING INSTRUCTIONS (LED LIGHTS)

---

Your WLIVE dresser features integrated LED lighting. Use the provided remote control to operate the lights.

- **Power On/Off:** Press the **ON** button to turn the lights on, and the **OFF** button to turn them off.

- **Brightness Adjustment:** Use the **Brightness Up** and **Brightness Down** buttons to adjust the intensity of the light.
- **Color Selection:** Press the color buttons (e.g., **Red**, **Green**, **Blue**, **White**) to change the light color.
- **Mode Selection:** The remote may include various dynamic modes (e.g., Flash, Strobe, Fade, Smooth). Press the corresponding buttons to cycle through these effects.

Ensure the remote control has fresh batteries and is pointed towards the LED receiver for optimal operation.

## 6. MAINTENANCE

- **Cleaning:** Wipe the dresser surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary.
- **LED Care:** Do not attempt to disassemble the LED strip. If the lights malfunction, refer to the troubleshooting section or contact customer support.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
LED lights do not turn on.	<ul style="list-style-type: none"> <li>◦ Power adapter not plugged in.</li> <li>◦ Remote control batteries are dead.</li> <li>◦ LED strip connection is loose.</li> </ul>	<ul style="list-style-type: none"> <li>◦ Ensure the power adapter is securely plugged into an outlet and the LED strip.</li> <li>◦ Replace remote control batteries.</li> <li>◦ Check all connections between the LED strip, controller, and power adapter.</li> </ul>
Drawers are difficult to open/close.	<ul style="list-style-type: none"> <li>◦ Drawer slides are misaligned.</li> <li>◦ Overloaded drawer.</li> <li>◦ Loose hardware.</li> </ul>	<ul style="list-style-type: none"> <li>◦ Recheck drawer slide installation and alignment.</li> <li>◦ Reduce the weight in the drawer.</li> <li>◦ Tighten all drawer and slide hardware.</li> </ul>
Dresser feels wobbly.	<ul style="list-style-type: none"> <li>◦ Loose assembly hardware.</li> <li>◦ Uneven floor.</li> </ul>	<ul style="list-style-type: none"> <li>◦ Tighten all assembly screws and bolts.</li> <li>◦ Place shims under the dresser legs to level it.</li> </ul>

## 8. SPECIFICATIONS

Feature	Detail
Brand	WLIVE
Model Number	ASNG123QX

Feature	Detail
Material	Wood
Finish Type	Wood
Product Dimensions (D x W x H)	17.72"D x 50.79"W x 31.89"H
Number of Drawers	6
Color	Light Oak
Mounting Type	Floor Mount
Additional Features	Safety Stop, Integrated LED Lighting
Required Assembly	Yes

## 9. WARRANTY AND CUSTOMER SUPPORT

---

WLIVE products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official WLIVE website.

If you encounter any issues during assembly or operation, or if you have questions about your product, please contact WLIVE customer support:

- **Website:** [Visit the WLIVE Store on Amazon](#) (for general inquiries and product information)
- **Email/Phone:** Refer to your product packaging or the WLIVE website for the most current contact information.

Please have your model number (ASNG123QX) and purchase date ready when contacting support.