

[manuals.plus](#) /› [boAt](#) /› **boAt Aavante 2.2 1400 Soundbar User Manual**

## boAt Aavante 2.2 1400

# boAt Aavante 2.2 1400 Soundbar User Manual

Model: Aavante 2.2 1400

## 1. INTRODUCTION

Thank you for choosing the boAt Aavante 2.2 1400 Soundbar. This manual provides essential information for setting up, operating, and maintaining your new soundbar. Please read it thoroughly before use to ensure optimal performance and safety.

### 1.1 Product Overview

The boAt Aavante 2.2 1400 is a 140W 2.2 channel soundbar designed to enhance your home audio experience. It features built-in subwoofers, multiple connectivity options including Bluetooth V5.3, AUX, USB, Coaxial, and HDMI(ARC), and various EQ modes for customized sound.

### 1.2 What's in the Box

- boAt Aavante 2.2 1400 Soundbar
- Remote Control (2 AA batteries included)
- Power Cable
- User Manual

## 2. SAFETY INFORMATION

Please observe the following safety guidelines to prevent damage to the device or personal injury:

- Do not expose the soundbar to rain, moisture, or extreme temperatures.
- Do not open the casing; refer all servicing to qualified personnel.
- Ensure proper ventilation around the unit.
- Use only the provided power cable.
- Keep out of reach of children.

## 3. PRODUCT COMPONENTS AND CONTROLS

### 3.1 Soundbar Overview

The soundbar features a sleek design with integrated controls and various input ports on the rear panel.



Image: Front view of the boAt Aavante 2.2 1400 Soundbar, showcasing its compact and elegant design.

### 3.2 Connectivity Ports

The soundbar offers multiple options for connecting to your audio sources:

# Multi-Compatibility



BLUETOOTH v5.3



AUX



USB



HDMI(ARC)



COAXIAL



Image: Close-up of the soundbar's rear panel, highlighting the Bluetooth V5.3, AUX, USB, HDMI(ARC), and Coaxial input ports.

- **Bluetooth V5.3:** For wireless connection to compatible devices.
- **AUX:** For analog audio input from devices with a 3.5mm jack.
- **USB:** For playing audio files directly from a USB drive.
- **HDMI(ARC):** For high-quality digital audio connection to ARC-enabled TVs.
- **Coaxial:** For digital audio input from compatible devices.

## 3.3 Remote Control

The included remote control provides full functionality for managing your soundbar.

## Entertainment EQ Modes:




Movies



Music



News



### Easy Access To Controls



### Master Remote Control



Image: Illustration showing the soundbar's easy access controls and the master remote control, along with icons for Music, Movies, and News EQ modes.

- Power On/Off
- Volume Up/Down
- Input Source Selection
- EQ Mode Selection (Music, Movies, News)
- Playback Controls (Play/Pause, Skip)

## 4. SETUP

### 4.1 Unpacking

Carefully remove all components from the packaging. Retain the packaging for future transport or storage.

### 4.2 Placement

Place the soundbar on a stable, flat surface directly in front of your television for the best audio experience. Ensure there is adequate space for air circulation.

# 2.2-Channel with Built-in Subwoofer



Image: The boAt Aavante 2.2 1400 Soundbar positioned below a television, illustrating its 2.2-channel audio with built-in subwoofer for an immersive experience.

## 4.3 Connecting to Power

1. Connect the power cable to the AC IN port on the soundbar.
2. Plug the other end of the power cable into a wall outlet.

## 4.4 Audio Connections

Choose one of the following methods to connect your audio source:

### 4.4.1 HDMI (ARC) Connection

For optimal digital audio quality and control, connect your TV's HDMI ARC port to the soundbar's HDMI(ARC) port using an HDMI cable (not included).

### 4.4.2 Bluetooth Connection

1. Press the 'Input' button on the remote or soundbar until 'BT' appears on the display.

2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Select 'boAt Aavante 1400' from the list of available devices.
4. A confirmation tone will sound upon successful pairing.

#### 4.4.3 AUX Connection

Connect an AUX cable (not included) from your audio device's 3.5mm output to the soundbar's AUX IN port.

#### 4.4.4 USB Connection

Insert a USB drive containing audio files into the USB port on the soundbar. The soundbar will automatically switch to USB mode and begin playback.

#### 4.4.5 Coaxial Connection

Connect a Coaxial cable (not included) from your audio device's Coaxial output to the soundbar's Coaxial IN port.

### 5. OPERATING INSTRUCTIONS

---

#### 5.1 Power On/Off

Press the power button on the soundbar or remote control to turn the unit on or off.

#### 5.2 Volume Control

Use the 'Volume +' or 'Volume -' buttons on the remote or soundbar to adjust the volume level.

#### 5.3 Input Source Selection

Press the 'Input' button on the remote or soundbar repeatedly to cycle through available input sources: Bluetooth, AUX, USB, Coaxial, HDMI(ARC).

#### 5.4 EQ Modes

The soundbar features multiple equalizer modes to optimize audio for different content types:

- **Music Mode:** Enhanced for musical playback.
- **Movies Mode:** Optimized for cinematic sound.
- **News Mode:** Clearer vocal reproduction for news and dialogue.

Press the corresponding EQ mode button on the remote control to select your desired mode.

### 6. MAINTENANCE

---

#### 6.1 Cleaning

Wipe the soundbar with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.

#### 6.2 Storage

If storing the soundbar for an extended period, disconnect it from power and store it in a cool, dry place, preferably in its original packaging.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; Wall outlet not active	Ensure power cable is securely connected; Test wall outlet with another device.
No sound	Incorrect input source; Volume too low; Mute activated; Cable connection issue	Select correct input source; Increase volume; Deactivate mute; Check audio cable connections.
Bluetooth not connecting	Soundbar not in pairing mode; Device not discoverable; Interference	Ensure soundbar is in BT mode; Make sure device Bluetooth is on; Move devices closer; Restart both devices.
Remote control not working	Batteries depleted; Obstruction; Remote out of range	Replace batteries (2 AA); Remove obstructions; Point remote directly at soundbar; Ensure within range.

## 8. SPECIFICATIONS

- **Model Name:** Avante 2.2 1400
- **Brand:** boAt
- **Speaker Type:** Soundbar
- **Connectivity Technology:** Bluetooth V5.3, AUX, USB, Coaxial, HDMI(ARC)
- **Power Output:** 140W
- **Channels:** 2.2 Channel with Built-in Subwoofer
- **Product Dimensions:** 97D x 14W x 9H Centimeters
- **Item Weight:** 4 kg
- **Control Method:** Remote
- **Power Source:** Wired Electric
- **Batteries for Remote:** 2 AA batteries (included)
- **Recommended Uses:** Home Theatre
- **Country of Origin:** India

## 9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or contact boAt customer service.

**Manufacturer:** Imagine Marketing Ltd

**Email:** [info@imaginemarketingindia.com](mailto:info@imaginemarketingindia.com)

