

[Manuals.plus](#) /

› [Fockety](#) /

› Fockety Impact Sprinkler on Tripod Base User Manual

Fockety Focketyvrts9e8fky

Fockety Impact Sprinkler on Tripod Base

Model: Focketyvrts9e8fky

INTRODUCTION

This manual provides instructions for the proper assembly, operation, and maintenance of your Fockety Impact Sprinkler on Tripod Base. This heavy-duty lawn sprinkler is designed for efficient and effective watering of lawns, gardens, and yards, featuring 360-degree large area irrigation and a 3/4 inch connector for easy setup.

PACKAGE CONTENTS

Please verify that all components are present before proceeding with assembly.

- 1 x Tripod
- 1 x Sprinkler Head
- 3 x Foot Support Stakes
- 1 x Quick Connector (3/4 inch female and male thread)






Image: All components included in the package, laid out for inspection.



Image: Detailed view of the sprinkler head, quick connector, and foot support stakes.

SETUP INSTRUCTIONS

1. **Assemble the Tripod:** Extend the tripod legs to a stable position.
2. **Attach Foot Support Stakes:** Insert the three foot support stakes into the designated slots at the ends of the tripod legs. These stakes enhance stability by allowing the tripod to be fixed into the ground.
3. **Mount the Sprinkler Head:** Securely screw the sprinkler head onto the top of the tripod pole.
4. **Connect to Water Source:** Attach the 3/4 inch quick connector to your garden hose. Then, firmly press the quick connector onto the sprinkler's inlet until you hear a distinct "click" sound. This indicates a secure connection. *Failure to ensure a firm connection may result in the quick connector detaching under water pressure.*
5. **Adjust Height:** The tripod's height is adjustable. Loosen the locking mechanism on the tripod pole, extend or retract to your desired height, and then tighten the mechanism to secure it.



Image: The tripod sprinkler fully assembled, ready for connection to a water source.

INLET FILTER MESH

The water effect is finer



Image: The inlet filter mesh, which helps ensure finer water distribution.

OPERATING INSTRUCTIONS

1. **Position the Sprinkler:** Place the assembled sprinkler in the desired area for irrigation. For maximum stability, press the foot support stakes firmly into the ground.
2. **Turn on Water Supply:** Slowly turn on the water supply to your garden hose.
3. **Observe Rotation:** The sprinkler head features a 360-degree rotation design, providing wide area coverage.
4. **Adjust Spray Range and Pattern:** The sprinkler's spray distance and span can be customized by adjusting the tripod's height and the water pressure. Higher water pressure generally results in a larger coverage area.
5. **Monitor Coverage:** Observe the water distribution to ensure all desired areas are being watered effectively. Adjust the sprinkler's position or settings as needed.



360° ROTATION FREE SWING IRRIGATION




Image: The sprinkler in operation, demonstrating its 360-degree rotation and wide spray pattern.



360 Degree Large Area Coverage



Image: The sprinkler effectively covering a large area with water.



Image: The sprinkler actively watering a lawn, showcasing its practical application.

MAINTENANCE

- **Clean Filter Mesh:** Periodically check and clean the inlet filter mesh to prevent clogging and ensure optimal water flow.
- **Inspect Connections:** Regularly inspect all connections for leaks or damage. Tighten connections as necessary.
- **Winter Storage:** Before freezing temperatures, disconnect the sprinkler, drain all water, and store it in a dry, protected area to prevent damage from ice expansion.
- **General Cleaning:** Wipe down the sprinkler and tripod with a damp cloth to remove dirt and debris.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Sprinkler not rotating or spraying unevenly.	Clogged nozzle or filter mesh. Insufficient water pressure.	Clean the sprinkler nozzle and inlet filter mesh. Ensure adequate water pressure from the source.
Water leaking from connections.	Loose connections. Damaged O-rings or washers.	Ensure all quick connectors are firmly clicked into place. Tighten threaded connections. Replace damaged washers or O-rings if necessary.
Tripod unstable.	Foot support stakes not fully inserted. Uneven ground.	Press the foot support stakes firmly into the ground. Reposition the tripod on a more level surface.

SPECIFICATIONS

- **Brand:** Fockety
- **Model Number:** Focketyvrts9e8fky
- **Material:** Aluminum Alloy (Tripod), Brass (Sprinkler components)
- **Connector Type:** 3/4 inch Female and Male Thread Quick Connectors
- **Irrigation Coverage:** 360 Degree Rotation, Large Area (dependent on water pressure)
- **Adjustable Height:** Yes
- **Item Dimensions (L x W x H):** 21.25 x 3.93 x 3.93 inches (collapsed/packaged)
- **Item Weight:** 500 Grams




Image: Dimensions of the adjustable tripod sprinkler at different heights.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the retailer from whom the product was purchased. Keep your purchase receipt for warranty claims.

© 2026 Fockety. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question