



[Manuals.plus](#) /

› [Enbrighten](#) /

› Enbrighten Vibe Modern Cafe Lights User Manual

## Enbrighten 84014

# Enbrighten Vibe Modern Cafe Lights User Manual

Model: 84014

[Contents](#)   [Setup](#)   [Operation](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

[Safety Information](#)   [Package](#)

## INTRODUCTION

The Enbrighten Vibe Modern Cafe Lights are smart, color-changing string lights designed for both indoor and outdoor use. Featuring durable acrylic bulbs and Wi-Fi connectivity, these lights offer extensive customization options through the Enbrighten app, as well as compatibility with Amazon Alexa and Google Home for voice control. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new cafe lights.



Figure 1: Enbrighten Vibe Modern Café Lights with app interface.

## IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before installing or operating this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Outdoor Use:** This product is rated for year-round outdoor installation. Ensure all connections are secure and protected from moisture.
- **Power Source:** Connect only to a 120V AC power source. Do not exceed the maximum wattage for the string lights.
- **Installation:** Install lights securely to prevent them from falling. Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
- **Damage:** Do not operate if the cord, bulbs, or housing are damaged. Contact customer support for replacement parts.
- **Children:** Keep out of reach of children. This is not a toy.
- **Linking:** Do not exceed 750 feet when linking multiple sets of Enbrighten smart cafe lights.

120V | LED | 1 WATT PER LIGHT | 2200K WARM WHITE



### Durable Acrylic Bulbs

Won't break if dropped or stepped on.



### All-Weather Rated

Built to last and certified for year-round installations.



Figure 2: Durable and weather-resistant design.

## PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x 24ft String of Enbrighten Vibe Modern Cafe Lights (with 12 acrylic bulbs)
- User Manual

*Note: Mounting hardware is not included.*

## SETUP AND INSTALLATION

### 1. Physical Installation

The Enbrighten Vibe Modern Cafe Lights offer flexible mounting options for various outdoor and indoor settings. Ensure the mounting surface is stable and can support the weight of the lights.

1. **Plan Your Layout:** Determine the desired path for your lights. Consider mounting on eaves, pergolas, fences, or other structures.
2. **Secure Mounting:** Use appropriate mounting hardware (e.g., screws, hooks, zip ties – not included) to secure the lights. Each bulb socket has a mounting tab for easy attachment.

**2.4GHz**  
Wi-Fi connection required\*  
Longer range, better coverage  
Dual- and tri-band router compatible

**ALL-WEATHER  
IP65 RATED**

**ETL**  
C LISTED US  
Intertek

**Easy Installation and Flexible Mounting Options**  
Mount on eaves, pergolas, patios and more.  
(Mounting hardware not included)

▶ **12 Lights, 24ft.**

**24.00in.**

**7.80in.**

**4.10in.**

**1.60in.**

**Connect Multiple Strings**  
Heavy-duty cord plugs into any standard outlet. Link multiple Café Lights up to 750 feet.

Figure 3: Flexible mounting options and dimensions.

3. **Linkable Strands:** If installing multiple sets, connect them end-to-end using the integrated heavy-duty cord plugs. Ensure the total length does not exceed 750 feet.



Figure 4: Cafe lights installed in an outdoor setting.

4. **Power Connection:** Once securely mounted, plug the lights into a standard 120V AC outdoor-rated electrical outlet.

## 2. App Installation and Pairing

The Enbrighten app is required for full control and customization of your cafe lights. A 2.4GHz Wi-Fi network is necessary for pairing.

1. **Download the App:** Download the free Enbrighten app from the Apple App Store (for iOS devices) or Google Play (for Android devices).
2. **Create an Account:** Open the app and follow the on-screen instructions to create a new account or log in to an existing one.
3. **Add Device:** In the app, tap the "+" icon or "Add Device" to begin the pairing process. Select "Lighting" and then "String Lights" or "Cafe Lights."
4. **Connect to Wi-Fi:** Follow the app's prompts to connect your cafe lights to your home's 2.4GHz Wi-Fi network. Ensure your mobile device is also connected to the same 2.4GHz network during pairing.
5. **Pairing Mode:** The lights will typically enter pairing mode automatically when first powered on. If not, refer to the

app for instructions on how to manually initiate pairing mode (e.g., by cycling power).

6. **Confirmation:** Once successfully paired, the app will confirm the connection, and you can begin controlling your lights.

## OPERATION

Control your Enbrighten Vibe Modern Cafe Lights using the Enbrighten app or through voice commands with compatible smart home assistants.

### 1. Enbrighten App Control

The Enbrighten app provides comprehensive control over your cafe lights:

- **Power On/Off:** Toggle the lights on or off directly from the app interface.
- **Color Changing:** Select from an extensive palette of colors to match any mood or occasion. You can choose solid colors or create personalized multicolor combinations.



Figure 5: App interface for color and mode selection.

- **White Light Options:** Adjust the white light from warm vintage tones (2200K) to cooler white shades (up to 6000K).
- **Dimming:** Adjust the brightness level from 0% to 100% to create the perfect ambiance.
- **Preset Modes:** Utilize pre-programmed lighting effects for holidays, seasons, or special events (e.g., Valentine's Day, July 4th, Spring).
- **Custom Modes:** Create and save your own unique lighting sequences and color patterns.
- **Scheduling:** Set schedules for your lights to turn on/off or change modes at specific times, enhancing convenience and energy efficiency.

## 2. Voice Control (Alexa & Google Home)

The Enbrighten Vibe Modern Cafe Lights are compatible with Amazon Alexa and Google Home for convenient voice control. Ensure your lights are successfully paired with the Enbrighten app before linking to your smart assistant.

### 1. Link Accounts:

- **For Amazon Alexa:** Open the Alexa app, go to "Skills & Games," search for "Enbrighten," enable the skill, and link your Enbrighten account.
- **For Google Home:** Open the Google Home app, tap "Add" (+), select "Set up device," then "Works with Google," search for "Enbrighten," and link your account.

### 2. Voice Commands: Once linked, you can use voice commands such as:

- "Alexa, turn on Cafe Lights."
- "Hey Google, set Cafe Lights to blue."
- "Alexa, dim Cafe Lights to 50%."
- "Hey Google, turn off Cafe Lights."



Figure 6: Wi-Fi control and smart home compatibility.

## MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Enbrighten Vibe Modern Cafe Lights.

- **Cleaning:** Disconnect power before cleaning. Wipe bulbs and cords with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Bulb Replacement:** The LED bulbs are designed for a lifetime of use and are not user-replaceable. If a bulb fails, contact customer support.
- **Storage:** If storing the lights for an extended period, clean them thoroughly, coil the string neatly, and store in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically inspect the cord and bulbs for any signs of damage, especially after severe weather conditions.

## TROUBLESHOOTING

If you experience issues with your Enbrighten Vibe Modern Cafe Lights, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lights do not turn on.	No power, loose connection, or faulty outlet.	Check if the lights are properly plugged in. Test the outlet with another device. Ensure the power switch (if any) is on.
Lights are not connecting to Wi-Fi.	Incorrect Wi-Fi band (not 2.4GHz), weak signal, or incorrect password.	Ensure your router is broadcasting a 2.4GHz network. Move the lights closer to the router. Double-check your Wi-Fi password. Try resetting the lights to pairing mode.
App control is unresponsive.	App glitch, network issue, or lights are offline.	Close and reopen the Enbrighten app. Check your internet connection. Verify the lights are powered on and connected to Wi-Fi.
Voice control is not working.	Smart assistant not linked, incorrect device name, or network issue.	Ensure your Enbrighten account is correctly linked to Alexa/Google Home. Use the exact device name configured in the Enbrighten app. Check your smart assistant's internet connection.
Lights are flickering or behaving erratically.	Unstable power supply or internal fault.	Try plugging the lights into a different outlet. If the issue persists, contact customer support.

If these solutions do not resolve the issue, please contact Enbrighten customer support for further assistance.

## SPECIFICATIONS

Feature	Detail
Model Number	84014
Length	24 feet
Number of Bulbs	12
Bulb Material	Acrylic
Light Source Type	LED
Power Source	Corded Electric
Voltage	120 Volts (AC)
Wattage	10 watts (total)
Color Temperature	2200 Kelvin (Warm White) - Tunable up to 6000K
Connectivity	Wi-Fi (2.4GHz)
Control Method	App Control, Voice Control (Amazon Alexa, Google Home)
Indoor/Outdoor Usage	Indoor, Outdoor (Weather Resistant)
Linkable Length	Up to 750 feet

Feature	Detail
Certifications	ETL Safety Certified
Item Weight	8.08 pounds
UPC	030878840149

## WARRANTY AND CUSTOMER SUPPORT

The Enbrighten Vibe Modern Cafe Lights come with a limited-lifetime warranty, ensuring peace of mind regarding product quality and durability.

- **Warranty Details:** For specific terms and conditions of the limited-lifetime warranty, please refer to the warranty documentation included with your product or visit the official Enbrighten website.
- **Customer Support:** If you have any questions, require technical assistance, or need to make a warranty claim, please contact Enbrighten customer support.

**Manufacturer:** Jasco Products Company, LLC

For the most up-to-date support information, please visit the [Enbrighten Store on Amazon](#) or the official Enbrighten website.

© 2025 Enbrighten. All rights reserved.

This manual is for informational purposes only and is subject to change without notice.