

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Lavazza](#) /

› [LAVAZZA LB1050 Classy Milk Coffee Machine User Manual](#)

## Lavazza LB1050

# LAVAZZA LB1050 Classy Milk Coffee Machine User Manual

Model: LB1050

## 1. INTRODUCTION

Welcome to the world of Italian coffee excellence with your new Lavazza LB1050 Classy Milk coffee machine. This manual provides essential information for the safe and efficient use, setup, operation, and maintenance of your machine. Please read it thoroughly before first use and keep it for future reference.

## 2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before operating the appliance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Unplug from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only Lavazza BLUE capsules with this machine.
- Be cautious of hot surfaces and hot liquids during operation.
- Do not use the appliance for anything other than its intended use.

## 3. PRODUCT OVERVIEW

The Lavazza LB1050 Classy Milk is a high-performance capsule coffee machine designed for ease of use and a variety of customizable beverages. It features a modern touch interface and an integrated milk frother.



**Figure 1:** Lavazza LB1050 Classy Milk machine with a cup of frothed milk coffee. This image shows the machine's sleek design and the integrated milk frother in action, preparing a layered coffee drink.



**Figure 2:** Lavazza LB1050 Classy Milk machine with an empty milk frothing cup. This view highlights the machine's control panel and the clear glass milk frothing jug, ready for use.

### Key Features:

- **Lavazza BLUE System:** Ensures rich aroma and professional-quality beverages.
- **Touch Interface:** Modern backlit touch panel for easy navigation.

- **8 Pre-programmed Beverages:** Including Espresso, Espresso Lungo, Caffè Lungo, Cappuccino, Grand Cappuccino, Latte Macchiato, Hot Milk.
- **2 Customizable Settings:** Personalize your favorite drinks.
- **15 Bar Pressure:** For optimal coffee extraction.
- **Integrated Milk Frother:** For creamy cappuccinos and lattes.
- **Smart Alert System:** Notifies for empty water tank (1.5 L) or full used capsule container (12 capsules).
- **Energy Saving:** Programmable standby mode after 10 or 30 minutes of inactivity.
- **Compact Design:** Dimensions of 16 x 30 x 41 cm.

## 4. SETUP

---

### 4.1 Unpacking

1. Carefully remove the machine from its packaging.
2. Remove all protective films and packaging materials.
3. Place the machine on a stable, flat surface, away from water sources and heat.

### 4.2 Initial Cleaning

1. Wash the water tank, drip tray, and milk frother components with warm water and mild detergent. Rinse thoroughly.
2. Wipe the exterior of the machine with a damp cloth.

### 4.3 Filling the Water Tank

1. Remove the water tank from the back of the machine.
2. Fill the tank with fresh, cold drinking water up to the MAX level (1.5 L capacity).
3. Replace the water tank securely.

### 4.4 First Use / Priming

1. Plug the machine into a grounded power outlet.
2. Press the power button to turn on the machine. It will heat up, indicated by flashing lights.
3. Once the lights are steady, place a large container under the coffee spout.
4. Run a cycle without a capsule (e.g., select Espresso) to prime the system and rinse internal components. Repeat this process 2-3 times.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Preparing a Coffee Beverage

1. Ensure the water tank is filled and the machine is powered on and heated.
2. Lift the lever to open the capsule compartment.
3. Insert a Lavazza BLUE capsule into the compartment. Close the lever firmly.
4. Place your cup under the coffee spout.
5. Select your desired beverage from the touch panel (e.g., Espresso (30 ml), Espresso Lungo (45 ml), Caffè Lungo (90 ml)).
6. The machine will automatically dispense the coffee and stop.
7. After brewing, lift the lever to eject the used capsule into the internal container.

## 5.2 Preparing a Milk-Based Beverage

1. Fill the milk frother jug with cold milk (dairy or non-dairy) up to the desired level indicated on the jug.
2. Place the jug on the machine's milk frother base.
3. Insert a Lavazza BLUE coffee capsule if making a coffee + milk drink (e.g., Cappuccino, Latte Macchiato).
4. Select your desired milk-based beverage from the touch panel (e.g., Cappuccino, Grand Cappuccino, Latte Macchiato, Hot Milk).
5. The machine will automatically froth the milk and/or dispense coffee, then stop.
6. Remove your cup and enjoy. Clean the milk frother immediately after use.

## 5.3 Customizing Beverages

The machine offers 2 customizable settings. To program a custom volume:

1. Insert a capsule and place a cup.
2. Press and hold the desired customizable beverage button until the desired volume is reached.
3. Release the button. The new volume is now saved for that button.

# 6. MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and extends the life of your machine.

## 6.1 Daily Cleaning

- **Used Capsule Container:** Empty the used capsule container when the alert light indicates it is full (capacity: 12 capsules). Rinse with water.
- **Drip Tray:** Empty and rinse the drip tray regularly.
- **Water Tank:** Rinse the water tank daily and refill with fresh water.
- **Milk Frother:** Immediately after each use, disassemble and wash all milk frother components with warm soapy water. Rinse thoroughly to prevent milk residue buildup.
- **Exterior:** Wipe the machine's exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.

## 6.2 Descaling

Over time, mineral deposits (limescale) can build up in the machine, affecting performance. Descaling your machine regularly, depending on water hardness and usage.

1. Refer to the descaling instructions provided with your descaling solution.
2. Use a descaling solution specifically designed for coffee machines.
3. Follow the manufacturer's instructions for the descaling agent carefully.
4. After descaling, run several rinse cycles with fresh water to remove any descaling solution residue.

# 7. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outlet faulty.	Check power cord connection; try a different outlet.
No coffee dispenses.	Water tank empty; capsule not inserted correctly; machine not primed.	Fill water tank; ensure capsule is properly seated; perform priming cycle.

Problem	Possible Cause	Solution
Coffee is cold or lukewarm.	Machine not fully heated; cups not pre-warmed.	Wait for machine to fully heat up; pre-warm cups with hot water.
Milk does not froth properly.	Milk frother dirty; milk not cold enough; incorrect milk type.	Clean milk frother thoroughly; use cold milk; try different milk types.
Water leaks from machine.	Water tank not seated correctly; drip tray full.	Ensure water tank is firmly in place; empty and re-seat drip tray.

If the problem persists after attempting these solutions, please contact Lavazza customer support.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Lavazza
Model Number	LB1050
Color	Black
Dimensions (L x W x H)	30 x 16 x 41 cm (11.8 x 6.3 x 16.1 inches)
Water Tank Capacity	1.5 Liters (1500 Milliliters)
Used Capsule Container Capacity	12 capsules
Pressure	15 Bar
Special Feature	Automatic Stop, Integrated Milk Frother, Energy Saving Mode
Coffee Maker Type	Espresso Machine (Capsule System)
Operation Mode	Semi-automatic

## 9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Lavazza website. Keep your proof of purchase for warranty claims.

For further assistance, you may contact Lavazza customer service through their official channels.