

[Manuals.plus](#) /

› [CrossBeats](#) /

› CrossBeats Everest 2.0 Smart Watch User Manual

CrossBeats CB-Everest-Black-2.0-2025

CrossBeats Everest 2.0 Smart Watch User Manual

Model: CB-Everest-Black-2.0-2025

INTRODUCTION

Welcome to the user manual for your new CrossBeats Everest 2.0 Smart Watch. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance and longevity. Please read this manual thoroughly before using your smartwatch.



Image: Front view of the CrossBeats Everest 2.0 Smart Watch, showcasing its rugged design and display.

WHAT'S IN THE BOX

- CrossBeats Everest 2.0 Smart Watch
- Charging Cable
- Warranty Card
- Instruction Manual (this document)

SETUP GUIDE

1. Initial Charging

Before first use, fully charge your CrossBeats Everest 2.0 Smart Watch. Connect the charging cable to the charging port on the back of the watch and plug the USB end into a compatible power adapter (not included) or a computer's USB port.

- Charging time: Approximately 2-3 hours for a full charge.
- The watch display will indicate charging status.

2. Powering On/Off

- **To Power On:** Press and hold the power button (usually the top right button) until the CrossBeats logo appears.
- **To Power Off:** Press and hold the power button, then select "Power Off" on the screen.

3. Pairing with Your Smartphone

To unlock the full features of your smartwatch, pair it with your smartphone via Bluetooth.

1. Download the official CrossBeats app from your smartphone's app store (iOS App Store or Google Play Store).
2. Ensure Bluetooth is enabled on your smartphone.
3. Open the CrossBeats app and follow the on-screen instructions to add a new device.
4. Select "Everest 2.0" from the list of available devices.
5. Confirm the pairing request on both your watch and smartphone.

Make Calls, on the Go
Latest single chip
5.3 Bluetooth



Upto
15 days*
of battery

Image: The smartwatch screen showing an incoming call, demonstrating its Bluetooth calling capability. Below, the watch is shown charging, indicating battery life.

OPERATING YOUR SMART WATCH

Display and Navigation

The Everest 2.0 features a 1.43" True AMOLED display with a resolution of 466x466 pixels, offering clear visuals even in bright conditions (up to 850 nits peak brightness). Navigate the watch using touch gestures and the physical buttons.

- **Swipe Up/Down:** Access quick settings or notifications.
- **Swipe Left/Right:** Cycle through widgets and health data.
- **Tap:** Select an item or open an application.
- **Physical Buttons:** Typically used for power, back, or quick access to specific functions (e.g., sport modes).



Image: A close-up view of the CrossBeats Everest 2.0 Smart Watch highlighting its vibrant 1.43-inch AMOLED display.

Key Features

- **Bluetooth Calling:** Make and receive calls directly from your wrist using the integrated Bluetooth 5.3 connectivity.



Image: A composite image illustrating key features including the AMOLED display, Bluetooth calling, extended battery life, built-in torch, and health sensors.

- **Sports Modes:** Track your workouts with over 100 built-in sports modes, covering a wide range of activities from indoor exercises to outdoor adventures.

Unleash Limitless Adventures

100+ Sports Modes



Image: The smartwatch displaying a snowboarder, symbolizing its extensive range of over 100 sports modes for various activities.

- **Health Monitoring:** Utilize advanced bio-sensors for real-time tracking of vital health metrics such as heart rate, steps, and sleep patterns.
- **Flash Light/Torch:** The rugged build includes a convenient flash light feature for outdoor use.
- **Customizable Dials:** Personalize your watch face with over 200 dial options available through the companion app.

200+

Dials Options



Image: The smartwatch displaying multiple watch face options, highlighting the availability of over 200 customizable dials.

- **Notifications:** Receive alerts for calls, messages, and app notifications directly on your wrist.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the watch and strap regularly with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** The Everest 2.0 is designed to be water and dust proof. However, avoid prolonged submersion in water or exposure to high-pressure water jets. Do not operate buttons underwater.
- **Charging:** Use only the provided charging cable. Ensure the charging contacts are clean and dry before charging.
- **Storage:** When not in use for extended periods, store the watch in a cool, dry place. Charge it periodically to maintain battery health.

Rugged. Sturdy. Dependable.

Water and dust proof



Image: The smartwatch positioned in a snowy, rugged landscape, illustrating its durable, water-resistant, and dust-proof construction.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not turning on	Low battery; device frozen.	Charge the watch for at least 30 minutes. Perform a force restart by holding the power button for 10-15 seconds.
Cannot pair with phone	Bluetooth off; app issue; watch not discoverable.	Ensure Bluetooth is on for both devices. Restart both the watch and phone. Reinstall the CrossBeats app. Ensure the watch is in pairing mode.
Inaccurate health data	Improper fit; sensor obstruction.	Ensure the watch is snug on your wrist, not too tight or too loose. Clean the sensor on the back of the watch.

Problem	Possible Cause	Solution
Short battery life	Frequent use of power-intensive features; high brightness.	Reduce screen brightness. Limit continuous heart rate monitoring. Turn off unnecessary notifications.

SPECIFICATIONS

Brand: CrossBeats
Model: CB-Everest-Black-2.0-2025
Display: 1.43 Inches True AMOLED, 466x466 pixels, 850 nits peak brightness
Wireless Type: Bluetooth 5.3
Operating System: Android (compatible)
Battery Life: Up to 15 Days (Average), 30 Days (Standby)
Special Features: Sleep Monitor, Lightweight, Multisport Tracker (100+ modes), Alarm Clock, Activity Tracker, Flash Light
Water Resistance: Water and Dust Proof (Rugged Build)
Item Weight: 200 g
Included Components: Smart Watch, Charger, Warranty Card, Instruction Manual
Country of Origin: China

WARRANTY AND SUPPORT

Your CrossBeats Everest 2.0 Smart Watch comes with a standard manufacturer's warranty. Please refer to the included Warranty Card for detailed terms and conditions.

Customer Support

For technical assistance, warranty claims, or any other inquiries, please contact CrossBeats customer support:
Phone: +91 8050056565
Email: support@crossbeats.com
Address: SELLBRITE DIGITAL LLP, Ground Floor Brigade Towers 135 Brigade Road Bangalore India - 560025

IMPORTANT SAFETY INFORMATION

- Do not attempt to disassemble or modify the device.
- Keep the device away from extreme temperatures and direct sunlight.
- Consult a medical professional before starting any new exercise regimen, especially if you have pre-existing health conditions.
- Dispose of the device and its battery responsibly according to local regulations.

OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were found in the provided data that meet the embedding criteria (m3u8 format and "Seller" creator type).

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question