

## HWR T25T

# HWR T25T Karaoke Machine Instruction Manual

Model: T25T

## INTRODUCTION

Thank you for choosing the HWR T25T Portable Bluetooth Karaoke Speaker. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

The HWR T25T is designed to deliver a powerful and immersive audio experience with its dual 5.25-inch full-range drivers and 360-degree sound projection. It includes two wireless microphones for enhanced vocal performance and dynamic lighting effects to complement your audio.

## PACKAGE CONTENTS

Please verify that all items listed below are present in your package:

- 1 x HWR T25T Karaoke Machine
- 2 x Wireless Microphones
- 1 x USB Charging Cable
- 1 x AUX Cable



Image: The HWWR T25T Karaoke Machine with its two accompanying wireless microphones, USB charging cable, and AUX cable.

## PRODUCT OVERVIEW

### Main Unit

The main unit features a control panel on the top for easy access to functions, a speaker grille on the front, and dynamic RGB lighting. It includes various input ports for versatile connectivity.

# Multiple Connection Methods

Bluetooth / TF Card / USB / AUX In,  
choose your play mode




Image: A detailed view of the HWWR T25T's control panel and various connection methods including Bluetooth, USB, TF Card, and AUX In.

## Wireless Microphones

The two included wireless microphones utilize 2.4G Bluetooth technology with APTX HD decoders for clear, low-latency sound transmission. They are designed for comfortable handling and reliable performance.

### Support Service for You



757-943-7037  
service@hwwr.net

Any question or problem on our product,  
please don't hesitate to contact us.  
We will be delighted to assist you!

### One-Year Warranty

HWWR Provides 12-month warranty for  
any quality-related problem.

Image: A close-up of one of the wireless microphones, highlighting its design and controls.



## SETUP

### 1. Charging the Main Unit

- Connect the provided USB charging cable to the USB Type-C port on the karaoke machine and to a compatible USB power adapter (not included).
- The charging indicator will illuminate. A full charge takes approximately 2 hours.
- The unit provides over 12 hours of playback time on a full charge.



Image: Illustration of the 4500mAh large capacity battery, showing 2 hours for full charging and 12+ hours of playback time.

### 2. Installing Microphone Batteries

- The wireless microphones do not come with batteries installed. Open the battery compartment on each microphone.
- Insert two AA batteries (not included) into each microphone, ensuring correct polarity.
- Close the battery compartment securely.

### 3. Powering On

- Press and hold the Power button on the main unit to turn it on.

- Press the power button on each wireless microphone to turn them on. They will automatically pair with the main unit.

## OPERATING INSTRUCTIONS

---

### Bluetooth Connection

1. Ensure the karaoke machine is powered on and in Bluetooth mode (indicated by 'BLUE' on the display). If not, press the 'MODE' button to switch modes.
2. Enable Bluetooth on your smartphone, tablet, or computer.
3. Search for 'HWR T25T' in the list of available devices and select it to pair.
4. Once connected, you can play audio from your device through the karaoke machine.

### USB/TF Card Playback

1. Insert a USB drive or TF card containing audio files into the respective port on the main unit.
2. The machine will automatically switch to USB or TF card mode and begin playing audio. If not, press the 'MODE' button to select the correct input.
3. Use the control panel buttons to play, pause, skip tracks, and adjust volume.

### AUX Input

1. Connect one end of the provided AUX cable to the AUX In port on the karaoke machine.
2. Connect the other end to the audio output jack of your external device (e.g., TV, MP3 player).
3. Press the 'MODE' button to select AUX input. Audio from your external device will now play through the speaker.

### Microphone Usage

- Ensure microphones are powered on and paired with the main unit.
- Adjust microphone volume using the dedicated controls on the main unit.
- The microphones feature intelligent noise reduction for clear vocal pickup.

## Intelligent Noise Reduction / Powerful Speaker



Image: A visual representation of the intelligent noise reduction feature, illustrating sound before and after processing by the microphone.

### Dynamic Lighting Effects

- The karaoke machine features open passive light and a vibrant gradient light ring that syncs with your music.
- Press the 'LED' button on the control panel to cycle through different light modes or turn the lights off.

# Multicolor Light Shows for Party

RGB lights will beat follow the rhythm of the music



Image: Several HWWR T25T units showcasing different multicolor light patterns, demonstrating the dynamic lighting feature.

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the karaoke machine and microphones. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, fully charge the unit before long-term storage and recharge it every 3 months. Remove batteries from microphones if not used for a long time.
- **Avoid Water:** Keep the device away from water and moisture to prevent damage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery drained; Power button not pressed	Charge the unit; Press and hold the Power button



Problem	Possible Cause	Solution
No sound from speaker	Volume too low; Incorrect input mode; Device not connected	Increase volume; Select correct input mode (Bluetooth, USB, TF, AUX); Reconnect device
Microphones not working	Microphone batteries low/dead; Microphones not powered on; Not paired	Replace microphone batteries; Power on microphones; Ensure microphones are within range and paired
Bluetooth connection unstable	Device too far; Interference	Move device closer to speaker; Avoid obstacles; Turn off other Bluetooth devices

## SPECIFICATIONS

- **Model:** T25T
- **Item Weight:** 5.29 pounds
- **Product Dimensions:** 8.5 x 8 x 16 inches
- **Power Output:** 80W
- **Connectivity:** Bluetooth, USB, TF Card, AUX In
- **Microphone Type:** 2.4G Wireless
- **Battery Capacity:** 4500mAh
- **Charging Time:** Approximately 2 hours
- **Playback Time:** Over 12 hours
- **Compatible Devices:** Smartphones, Tablets, Computers, Bluetooth-enabled devices, Musical instruments with a 6.35 mm cable
- **Included Components:** Karaoke machine, 2 Wireless microphones, USB Cable, AUX Cable

## WARRANTY AND SUPPORT

### Warranty Information

HWWR provides a 12-month warranty for any quality-related problems from the date of purchase. Please retain your proof of purchase for warranty claims.

### Customer Support

Should you encounter any questions or problems with your HWWR T25T Karaoke Machine, please do not hesitate to contact our support team. We are dedicated to assisting you.



**Phone:** 757-943-7037

**Email:** [service@hwwr.net](mailto:service@hwwr.net)





## Related Documents - T25T

	<p><a href="#">HWWR D28-T Bluetooth Karaoke Machine User Manual</a></p> <p>Comprehensive user manual for the HWWR D28-T portable Bluetooth karaoke machine. Learn about product specifications, features, button operations, and usage instructions for this kid-friendly karaoke device.</p>
	<p><a href="#">HWWR D10-T Portable Bluetooth Speaker User Manual</a></p> <p>User manual for the HWWR D10-T portable Bluetooth speaker, detailing product features, connection instructions, troubleshooting, and specifications.</p>
	<p><a href="#">HWWR Wireless Lavalier Microphone K38 User Manual</a></p> <p>User manual for the HWWR Wireless Lavalier Microphone K38, detailing product introduction, operating methods, indicator light descriptions, and package contents for professional recording, live streaming, and vlogging.</p>
	<p><a href="#">JYX TX05 Bluetooth Karaoke Machine User Manual</a></p> <p>Comprehensive user manual for the JYX TX05 Bluetooth Karaoke Machine, detailing setup, operation, features, and troubleshooting for this portable audio system with two microphones.</p>
	<p><a href="#">JYX T19-T Karaoke Machine User Manual - Setup, Operation, and Features</a></p> <p>This user manual provides comprehensive instructions for the JYX T19-T Karaoke Machine. Learn how to set up, connect, operate, and troubleshoot your device, including features like wireless microphones and DJ lighting effects. Optimized for ease of use and accessibility.</p>
	<p><a href="#">HWWR D28-T Bluetooth Karaoke Machine User Manual</a></p> <p>Comprehensive user manual for the HWWR D28-T portable Bluetooth karaoke machine. Learn about product specifications, features, button operations, and usage instructions for this kid-friendly karaoke device.</p>