

- Manuals.plus /
- › Keygarzone /
- › Keygarzone Wireless Cat Water Fountain Model ZCW001SL Instruction Manual

Keygarzone ZCW001SL

Keygarzone Wireless Cat Water Fountain (Model ZCW001SL) Instruction Manual

Brand: Keygarzone | Model: ZCW001SL

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Keygarzone Wireless Cat Water Fountain. Designed for cats, dogs, and multi-pet households, this 5L stainless steel pet water fountain ensures your pets stay hydrated with clean, filtered water.



Image: The Keygarzone Wireless Cat Water Fountain, showcasing its sleek stainless steel design and illuminated water level indicator.

PRODUCT FEATURES

- **5L Large Capacity:** This fountain holds up to 5 liters of water, making it suitable for cats, dogs, and multi-pet households. A visible water window allows for easy monitoring of water levels.
- **Wireless & Long Battery Life:** The cordless, battery-operated design provides up to 40 days of use on a single 4-hour charge, offering flexible placement without tangled cords.
- **3 Drinking Modes:** Choose from Sensor, Timed, or Continuous flow modes to encourage your pets to drink more water, promoting their health.
- **6-Stage Filtration:** Equipped with a comprehensive 6-layer filtration system, including activated carbon and ion resin, to remove hair, odors, and impurities, ensuring clean and fresh water.
- **Stainless Steel Construction:** Made from rust-proof, food-grade stainless steel, the fountain is durable, easy to clean, and ideal for pets with plastic allergies.

PACKAGE CONTENTS

The package includes the following components:

- Stainless Steel Water Tank
- Stainless Steel Water Tray
- Main Control Module (with integrated pump)
- Circular Filter Cotton
- Blue Filter
- Pump Filter Cotton (black, square)
- Cleaning Brush
- Type-C Charging Cable
- User Manual



Image: All components included in the Keygarzone Wireless Cat Water Fountain package.

SETUP INSTRUCTIONS

Follow these steps to set up your Keygarzone Wireless Cat Water Fountain:

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Fill Water Tank:** Fill the stainless steel water tank with clean water. Ensure the water level does not exceed the 'MAX' indicator.



Image: Filling the water tank to the maximum level.

3. **Prepare and Place Filters:** Rinse the circular filter cotton and the blue filter under running water for 30 seconds to activate the filter material. Place them into the designated filter tray area.



Image: Placing the filter into the water tray.

4. **Install Water Tray:** Carefully place the stainless steel water tray onto the water tank, ensuring it sits securely.
5. **Insert Control Module:** Insert the main control module into its designated slot on the water tray.

6. **Power On:** Long press the power button on the main control module to turn the fountain on.

Your browser does not support the video tag.

Video: A step-by-step guide on how to install the Keygarzone Stainless Steel Pet Drinking Fountain.

OPERATING INSTRUCTIONS

The fountain offers three operating modes to suit your pet's drinking habits:

- **Sensor Mode:** Water flows automatically when a pet approaches within approximately 1.5 meters (5 feet).
- **Timed Mode:** Water runs for 20 seconds every 20 minutes.
- **Continuous Flow Mode:** Water flows continuously. If operating on battery power, it will run for 30 minutes and then switch to sensor mode to conserve energy.

To cycle through the modes, double-click the power button on the main control module. The indicator lights will show the currently active mode. The blue light in the water window indicates the water level. A low water level will trigger a dehydration alert.

Cordless Design + Custom Flow Modes

3 Flow Modes. Any Spot. Happier Cats.





Image: Visual representation of the three custom flow modes: Motion-Activated, Continuous Flow, and Timed.



No More Dreaded Cleaning Days

Easy to take apart, so you can finally say goodbye to those frustrating scrubbing sessions.

Image: Detailed view of the main control module with its various buttons and indicators.

MAINTENANCE

Cleaning

Regular cleaning is essential for maintaining hygiene and prolonging the life of your fountain. The stainless steel components are dishwasher safe. For manual cleaning:

1. **Disassemble:** Remove the main control module, water tray, and filters from the water tank.
2. **Clean Components:** Wash the water tank and water tray with mild soap and water. Rinse all parts thoroughly to remove any soap residue.
3. **Clean Pump:** Use the provided brush to clean the pump and any narrow passages to prevent blockages.
4. **Dry and Reassemble:** Ensure all components are completely dry before reassembling the fountain.

Separate Design for Water & Battery

Double-click the power button to easily switch modes

Full Charge in 4H / 4000mAh Battery / Up to 45Days Use



Image: The fountain disassembled for easy cleaning.

Filter Replacement

The 6-stage filter and filter cotton should be replaced regularly to ensure optimal water quality. The replacement frequency typically ranges from every 2 to 4 weeks, depending on usage and water hardness. The fountain may feature a

filter replacement indicator to alert you when a change is needed.



No More Spills or Chewing

Deep, snug lid stays firmly in place—keeps water inside and pets out.

Image: Breakdown of the 6-layer filtration system.

TROUBLESHOOTING

If you encounter any issues with your Keygarzone Wireless Cat Water Fountain, refer to the following common problems and solutions:

- **Fountain not dispensing water:**

- Check the battery level and recharge if necessary.
- Ensure the main control module is correctly inserted and seated.
- Verify that the water level in the tank is sufficient.
- Clean the pump and filters for any potential blockages.

- **Fountain is noisy:**

- Ensure the water level is adequate; low water can cause pump noise.
- Check for proper assembly of all components; ensure they are securely in place.
- Clean the pump to remove any debris that might be causing vibration or obstruction.

- **Water quality issues (e.g., odor, visible debris):**

- Replace the filter and filter cotton as per maintenance guidelines.
- Thoroughly clean all fountain components, including the tank, tray, and pump.
- Always use fresh, clean water.

- **Motion sensor not activating:**

- Confirm that the fountain is set to Sensor Mode.
- Check for any obstructions blocking the sensor's field of view.
- Ensure the sensor area is clean and free from dust or debris.

If these steps do not resolve the issue, please refer to the contact information in the Warranty & Support section for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	ZCW001SL
Capacity	5 Liters (169 oz)
Material	Stainless Steel
Power Source	Battery Operated (rechargeable via Type-C)
Battery Life	Up to 40 days (on 4-hour charge)
Noise Level	Ultra-Quiet (<30dB)
Dimensions	11.73 x 8.62 x 6.26 inches
Item Weight	3.45 pounds (1.57 Kilograms)
Manufacturer	KeygarZone

304 Food-grade Stainless Steel

Dishwasher Safe; Rustproof; Durable



Image: Product dimensions for the Keygarzone Wireless Cat Water Fountain.

WARRANTY & SUPPORT

For warranty information, technical support, or to purchase replacement parts (such as filters), please contact Keygarzone customer service. Refer to the contact details provided with your product packaging or visit the official Keygarzone website.

You can also visit the Keygarzone Store on Amazon for more information and products:

[Visit the Keygarzone Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can the filter for the Keygarzone ZCW001SL Wireless Cat Water Fountain be cleaned, or does it need to be replaced?

Based on the manual for the Keygarzone ZCW001SL Wireless Cat Water Fountain, the filters require both initial rinsing and regular replacement rather than deep cleaning for reuse: Initial Cleaning: Before first use, you should...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0F8HB1T1Y>

More documents and user manuals: <https://manuals.plus/>