

Granarbol TC-SC-005

Granarbol TC-SC-005 Pressurized Handheld Steam Cleaner User Manual

Model: TC-SC-005

1. INTRODUCTION

Thank you for choosing the Granarbol TC-SC-005 Pressurized Handheld Steam Cleaner. This powerful 2500W steam cleaner is designed for effective multi-surface cleaning, delivering 3 BAR pressure and 221°F (105°C) steam in just 15 seconds. It features a 47.3oz (1400ML) refillable water tank for up to 60 minutes of continuous use, allowing for chemical-free cleaning throughout your home.

2. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Hot Steam Hazard:** The steam produced is extremely hot (221°F/105°C). Always direct steam away from yourself, other people, pets, and plants. Avoid direct contact with steam.
- **Electrical Safety:** Ensure the power cord is not damaged. Do not operate the appliance with a damaged cord or plug. Keep the power cord away from heated surfaces.
- **Water Tank:** Only fill the water tank with clean tap water. Do not add cleaning solutions, perfumes, or other chemicals to the water tank, as this can damage the appliance and create hazardous fumes.
- **Children and Pets:** Keep the steam cleaner out of reach of children and pets. Do not allow children to operate the appliance.
- **Surface Compatibility:** Test the steam cleaner on an inconspicuous area of the surface to be cleaned before full application, especially on delicate materials.
- **Unplug When Not in Use:** Always unplug the appliance from the power outlet before filling, emptying, or cleaning, and when not in use.
- **Proper Ventilation:** Use the steam cleaner in a well-ventilated area.
- **Wear Protective Gear:** Always wear insulated gloves when handling hot parts or changing accessories.

3. PACKAGE CONTENTS

Verify that all items are included in your package:

- Granarbol TC-SC-005 Steam Cleaner Unit
- Handheld Steam Gun with Hose
- 4 x Nylon Brushes
- 2 x Brass Brushes
- 1 x Extension Rod
- 1 x Window Scraper
- 2 x Surface Scrapers
- 1 x Elbow Nozzle
- 1 x Insulated Gloves
- 1 x Cleaning Towel
- 2 x Microfiber Pads
- 1 x Storage Case
- 1 x Folding Funnel
- 1 x Anti-Clogging Needle
- 2 x Gaskets
- 1 x Battery Cover
- 1 x Waterproof Plug



Figure 3.1: Overview of the Granarbol TC-SC-005 steam cleaner and its comprehensive set of 21 accessories, including various brushes, scrapers, and cloths.

4. SETUP

1. **Insert Batteries:** Open the battery cover on the handheld steam gun and insert 2xAAA batteries (not included).
2. **Fill Water Tank:** Unscrew the water tank cap. Use the provided folding funnel to fill the 47.3oz (1400ML) tank with cold tap water. Do not overfill. Securely close the cap.



Figure 4.1: Illustration of filling the water tank with cold water using the funnel.

3. **Attach Accessories:** Select the desired nozzle or brush head for your cleaning task. Attach it firmly to the handheld steam gun. For extended reach, connect the extension rod between the gun and the attachment.



Figure 4.2: Visual guide for attaching different brush heads and the extension rod.

4. **Connect Power:** Plug the steam cleaner into a standard power outlet. The LED display on the unit will show '0'.

5. OPERATING INSTRUCTIONS

1. **Power On:** Long press the power button on the handheld steam gun to activate the unit. The steam cleaner will begin heating up, which takes approximately 15 seconds. The display on the unit will show '1' when ready for steam output.



Figure 5.1: The steam cleaner in operation, demonstrating steam output and the handheld control.

2. **Adjust Steam Level:** Short press the button on the handheld steam gun to cycle through 3 adjustable steam intensity levels (Low, Medium, High).

- **Mode 1 (Low):** Approximately 30g/min, suitable for delicate fabrics and surfaces.
- **Mode 2 (Medium):** Approximately 40g/min, ideal for everyday cleaning.
- **Mode 3 (High):** Approximately 50g/min, for tough grime and deep sanitization.

2-in-1 Smart Cleaning Tool

Instantly switch between glass & fabric cleaning modes



Figure 5.2: Visual representation of the three steam output levels and their applications.

3. **Begin Cleaning:** Direct the steam towards the surface to be cleaned. Move the attachment slowly over the area. For stubborn stains, hold the steam over the area for a few seconds.

1400ML Large Capacity Water Tank



Figure 5.3: Demonstrating the use of the steam cleaner on upholstery.

One-Switch Remote Handle Control

Operate instantly, stay comfortably in place



Figure 5.4: Demonstrating the use of the steam cleaner on a kitchen stovetop.

4. **Refilling Water:** The 1400ML tank allows for up to 60 minutes of continuous use. If the water level is low, you can add water mid-cleaning without waiting for the unit to cool down.
5. **Power Off:** Long press the power button on the handheld steam gun to turn off the unit. Unplug the power cord from the outlet.

Your browser does not support the video tag.

Video 5.1: Official Granarbol video demonstrating the handheld steam cleaner in use for various cleaning tasks.

6. MAINTENANCE

- **Draining Water:** After each use, ensure the unit is unplugged and cooled. Carefully drain any remaining water from the tank.
- **Cleaning Attachments:** Clean all used attachments with water and mild soap. Allow them to dry completely before storing.
- **Descaling:** If you notice reduced steam output or mineral buildup, descale the unit using a descaling solution suitable for

steam cleaners, following the product's instructions.

- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, preferably in the provided storage case.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam output.	Unit not powered on. Water tank empty. Unit not heated sufficiently. Nozzle clogged.	Long press power button on handheld gun. Refill water tank. Wait approximately 15 seconds for heating. Use anti-clogging needle to clear nozzle.
Weak steam output.	Low steam level selected. Mineral buildup.	Short press button to increase steam level. Descale the unit.
Water leaking from nozzle.	Attachment not securely fastened. Gasket worn or missing.	Ensure attachment is tightly secured. Replace gasket with a new one from the accessory kit.

8. SPECIFICATIONS

- **Model Name:** Steam Cleaner (TC-SC-005)
- **Brand:** Granarbol
- **Wattage:** 2500 watts
- **Tank Volume:** 1400 Milliliters (47.3 oz)
- **Heat Time:** 15 seconds (0.25 Minutes)
- **Maximum Temperature:** 221°F (105°C)
- **Form Factor:** Handheld
- **Power Source:** Corded Electric
- **Item Weight:** 5.37 pounds
- **Package Dimensions:** 11.42 x 9.33 x 6.73 inches
- **Special Features:** High Pressure, Large Capacity Tank, Portable, Rapid Heat Up, Steam Control
- **Surface Recommendation:** Car, Floor, Furniture, Couch, Upholstery

9. WARRANTY AND SUPPORT

Granarbol offers a 12-month worry-free warranty for this product. For any questions, technical support, or warranty claims, please contact Granarbol customer service. You can also register your product to extend the warranty and receive replacement accessories.

Customer Service Email: granarbolaftersales@gmail.com



Figure 9.1: Granarbol customer service details, including warranty and support information.

© 2025 Granarbol. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question