

[Manuals.plus](#) /

› [Fastrack](#) /

› Fastrack Automatic 2.0 Watch 3318SM01 User Manual

Fastrack 3318SM01

Fastrack Automatic 2.0 Watch Model 3318SM01 User Manual

Your guide to understanding and maintaining your Fastrack Automatic 2.0 timepiece.

1. INTRODUCTION

Thank you for choosing the Fastrack Automatic 2.0 Watch, Model 3318SM01. This timepiece features an automatic movement, meaning it is powered by the motion of your wrist and does not require a battery. Its skeleton dial design showcases the intricate internal mechanics, blending classic watchmaking with modern aesthetics. This manual provides essential information for the proper setup, operation, and care of your watch to ensure its longevity and performance.

2. PRODUCT OVERVIEW

Familiarize yourself with the key components of your Fastrack Automatic 2.0 watch.



Figure 2.1: Front view of the Fastrack Automatic 2.0 Watch, Model 3318SM01. This image displays the watch face with its distinctive green skeleton dial, silver hour markers, and gold-toned hands, all encased in a silver stainless steel case and bracelet.



Figure 2.2: Angled side view of the watch, highlighting the curvature of the stainless steel case and the integrated metal strap. The crown is visible on the right side of the watch case.



Figure 2.3: Close-up side view of the watch, focusing on the crown. The crown is used for manual winding and setting the time.



Figure 2.4: Rear view of the watch, showcasing the transparent case back that allows visibility of the automatic movement's oscillating weight and intricate gears. Engravings such as "50M WR" (Water Resistant) and "AUTOMATIC" are also visible.



Figure 2.5: A visual representation of the watch's dimensions, showing its 44 mm case size in comparison to a standard credit card (55 mm). This helps in understanding the watch's physical presence.

3. SETUP

3.1 Initial Winding

As an automatic watch, your Fastrack timepiece is powered by the natural motion of your wrist. However, for initial setup or if the watch has stopped due to inactivity, manual winding is required.

1. Ensure the crown is in its fully pushed-in position (Position 0).
2. Rotate the crown clockwise approximately 20-30 times. This will build up enough power reserve to start the watch.
3. The second hand should begin to move.

3.2 Setting the Time

1. Gently pull the crown out to Position 1 (the first click).

2. Rotate the crown either clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original fully pushed-in position (Position 0).

Note: Avoid setting the time between 9 PM and 3 AM if your watch had a date function (this model does not), as it could interfere with the date change mechanism. For this model, you can set the time at any point.

4. OPERATING THE WATCH

4.1 Automatic Movement

Your Fastrack Automatic 2.0 watch is equipped with an automatic mechanical movement. This movement is self-winding, meaning it harnesses energy from the natural motion of your arm and wrist. When worn regularly (typically 8-10 hours a day), the watch will remain wound and keep accurate time.

4.2 Power Reserve

If the watch is not worn for an extended period, the power reserve will deplete, and the watch will stop. To restart it, follow the "Initial Winding" steps in Section 3.1. The typical power reserve for a fully wound automatic watch is approximately 36-40 hours, though this can vary by movement.

5. MAINTENANCE

5.1 Cleaning

- Wipe the watch case and metal strap regularly with a soft, dry cloth to remove dust and fingerprints.
- For stubborn dirt, a slightly damp cloth can be used, followed immediately by a dry cloth.
- Avoid using harsh chemicals, solvents, or abrasive cleaning materials, as these can damage the watch's finish or seals.

5.2 Water Resistance

Your Fastrack Automatic 2.0 watch has a water resistance rating of 5 ATM (50 meters). This means it is suitable for everyday use, including splashes, rain, and brief immersion in water. However, it is **not** suitable for swimming, diving, or showering with hot water, as steam and temperature changes can compromise the seals.

- Do not operate the crown or pushers (if any) when the watch is wet or submerged in water.
- Ensure the crown is always fully pushed in to maintain water resistance.

5.3 Storage

When not wearing your watch for an extended period, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. A watch box or pouch is recommended to protect it from scratches and dust.

5.4 Servicing

Mechanical watches benefit from periodic servicing, typically every 3-5 years, to ensure optimal performance and lubrication of the movement. Contact an authorized Fastrack service center for professional maintenance.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Watch has stopped or is running slow.	Insufficient power reserve.	Manually wind the watch by rotating the crown clockwise 20-30 times (Section 3.1). Wear the watch regularly to keep it wound.
Time is incorrect.	Time was not set correctly or watch stopped.	Set the time according to Section 3.2. If the watch stopped, wind it first.
Condensation under the crystal.	Exposure to extreme temperature changes or compromised water resistance.	Avoid extreme temperature changes. If condensation persists, seek professional servicing immediately to prevent internal damage.
Watch is running too fast or too slow consistently.	Magnetization or need for regulation.	Keep the watch away from strong magnetic fields. If the issue persists, the movement may require demagnetization or regulation by a professional watchmaker.

7. SPECIFICATIONS

Brand	Fastrack
Model Number	3318SM01
Display Type	Analog
Movement Type	Automatic
Case Material	Brass (Case), Stainless Steel (Back Cover)
Case Diameter	44.3 mm
Case Thickness	11.7 mm
Crystal Material	Glass
Strap Material	Stainless Steel (Metal Strap)
Clasp Type	Push Button Deployment Clasp
Water Resistance	5 ATM (50 meters)
Item Weight	200 Grams
Dial Colour	Green
Band Colour	Silver

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your Fastrack Automatic 2.0 Watch, Model 3318SM01, comes with **a2-year limited warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, service requests, or warranty claims, please contact Fastrack customer support or visit an authorized service center. Contact details can typically be found on the official Fastrack website or your purchase documentation.

Manufacturer: Titan Company Limited, Sipcot Industrial Complex, Hosur, Tamil Nadu - 635129, India.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question