

[Manuals.plus](#) /

› [FOHERE](#) /

› FOHERE 1.1 Cu.Ft Mini Freezer Countertop User Manual

FOHERE BD-40-E

FOHERE 1.1 Cu.Ft Mini Freezer Countertop

MODEL: BD-40-E USER MANUAL

Important Safety Instructions

Please read all instructions carefully before using your new FOHERE mini freezer. Keep this manual for future reference. Failure to follow these instructions may result in electric shock, fire, or other injuries.

- **Electrical Safety:** Ensure the freezer is connected to a grounded 110V outlet. Do not use extension cords or ungrounded adapters.
- **Placement:** Place the freezer on a firm, level surface away from direct sunlight, heat sources, and moisture. Allow adequate space (at least 4 inches) around the unit for proper ventilation.
- **Flammable Materials:** Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- **Cleaning:** Always unplug the freezer before cleaning or performing any maintenance.
- **Children:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Product Overview

The FOHERE 1.1 Cu.Ft Mini Freezer is a compact and efficient upright freezer designed for various small spaces such as homes, dorms, apartments, and offices. Its thoughtful design includes features for convenience and quiet operation.



Image: The FOHERE 1.1 Cu.Ft Mini Freezer, showcasing its compact size and interior capacity for various items like fruits and canned drinks.

Key Features:

- **Compact Dimensions:** Approximately 17.44"D x 19.5"W x 17.87"H, ideal for countertop or under-desk placement.
- **1.1 Cubic Feet Capacity:** Sufficient space for frozen goods, beverages, or snacks.
- **7-Level Temperature Control:** Adjustable knob on the back allows temperature settings from -7.6°F to 14°F (-22°C to -10°C).
- **Quiet Operation:** Operates at a low noise level of 43dB, suitable for bedrooms and quiet environments.
- **Reversible Door:** The door can be configured to open from either the left or right side to suit your space.
- **Removable Shelf:** Includes one removable shelf for flexible storage and easy cleaning.
- **Adjustable Leveling Legs:** Ensures stability on uneven surfaces.

COMPACT & STYLISH

Keep food fresh and drinks cool anytime, anywhere.



1.1Cu.ft



43dB



7Level
Thermostats



Energy-Saving



Image: A visual representation of the freezer's key features, including its 1.1 cubic feet capacity, 43dB low noise level, 7-level thermostat, and energy-saving design.

Setup

Proper setup ensures optimal performance and longevity of your mini freezer.


1. **Unpacking:** Carefully remove all packaging materials, including tape and foam. Inspect the freezer for any shipping damage.
2. **Placement:** Choose a location with a solid, level floor that can support the weight of the freezer when fully loaded. Ensure there is at least 4 inches of space on all sides and the back for adequate air circulation. Avoid placing it near heat sources or in direct sunlight.
3. **Leveling:** Use the adjustable leveling legs at the bottom of the freezer to ensure it is perfectly level. A level freezer operates more efficiently and quietly.

4-ADVANTAGE OF UPRIGHT FREEZERS

Built-in
Handle



2 layers
insulation



Adjustable Legs



Removable
with Shelf



Image: Detail showing the adjustable leveling legs at the bottom of the freezer and the removable internal shelf, highlighting ease of adjustment and interior customization.

4. **Door Reversal (Optional):** The door is reversible. If you wish to change the door swing direction, refer to the detailed instructions provided in a separate diagram or video (if available) or consult the manufacturer's website. This process typically involves removing hinges and reattaching them on the opposite side.
5. **Initial Cleaning:** Before first use, wipe the interior and exterior of the freezer with a damp cloth and a mild detergent. Rinse with clean water and dry thoroughly.
6. **Power Connection:** After placement and cleaning, wait at least 2-4 hours before plugging the freezer into a grounded 110V electrical outlet. This allows the refrigerant to settle, preventing potential damage to the cooling system.

Operating Instructions

Operating your FOHERE mini freezer is straightforward. Follow these steps for optimal performance.

1. **Temperature Control:** The temperature is controlled by a knob located on the back of the freezer. It offers 7 variable settings, ranging from '1' (warmest, 14°F) to '7' (coldest, -7.6°F). Turn the knob to your desired setting. For initial use, it is recommended to set it to a mid-range setting (e.g., '4') and adjust as needed.

Adjustable 7-Level Thermostats

The knob on the back adjusts the temperature



Image: A detailed view of the temperature control knob located on the back of the freezer, illustrating the 7 adjustable settings and their corresponding temperature range.

- Loading the Freezer:** Allow the freezer to cool down for several hours before loading it with food. Do not overload the freezer, as this can restrict airflow and reduce cooling efficiency. Leave some space between items for proper circulation.
- Energy Saving Tips:**
 - Avoid opening the door too frequently or for extended periods.
 - Ensure the door seal is clean and intact to prevent cold air from escaping.

- Place the freezer in the coolest part of the room, away from direct sunlight or heat-producing appliances.

Maintenance and Cleaning

Regular maintenance and cleaning will help keep your FOHERE mini freezer in excellent condition and ensure efficient operation.

1. **Defrosting:** Over time, frost will accumulate on the interior walls. When the frost layer is about 0.2 inches (5mm) thick, it's time to defrost. To defrost:
 - Unplug the freezer from the power outlet.
 - Remove all food items and place them in another freezer or cooler.
 - Leave the door open to allow the frost to melt naturally. You can place towels at the bottom to absorb water. Do not use sharp objects or heating devices to speed up defrosting, as this can damage the freezer.
 - Once defrosted, wipe the interior dry with a clean cloth.
2. **Interior Cleaning:** After defrosting, or as needed, clean the interior with a solution of mild detergent and warm water. Wipe down the removable shelf. Rinse thoroughly with clean water and dry completely before plugging the freezer back in.
3. **Exterior Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. For stubborn stains, use a mild, non-abrasive cleaner.
4. **Door Seal Maintenance:** Regularly check the door gasket for cracks or tears. Clean the gasket with a damp cloth to ensure a tight seal, which is crucial for energy efficiency.

Troubleshooting

If you encounter issues with your FOHERE mini freezer, consult the following common problems and solutions before contacting support.

Problem	Possible Cause	Solution
Freezer does not operate.	No power supply.	Check if the freezer is plugged in securely. Verify the outlet has power by plugging in another appliance. Check circuit breaker.
Freezer is not cold enough.	Temperature setting is too high (warm). Door is not closed properly. Excessive door openings. Too much food loaded. Poor ventilation.	Adjust temperature control to a colder setting. Ensure door is fully closed and seal is intact. Reduce frequency and duration of door openings. Remove some items to allow air circulation. Ensure adequate space around the freezer for airflow.

Problem	Possible Cause	Solution
Freezer is noisy.	Freezer is not level. Items inside are vibrating. Normal compressor operation.	Adjust leveling legs to ensure the freezer is stable and level. Rearrange items to prevent contact with walls or other items. A slight humming sound from the compressor is normal.
Water on floor/inside.	Defrost water. Door not sealed properly.	This is normal during defrosting. Ensure water is collected and wiped. Check door seal for damage or obstructions.

Specifications

Detailed technical specifications for the FOHERE 1.1 Cu.Ft Mini Freezer, Model BD-40-E.

Feature	Specification
Brand Name	FOHERE
Model Info	BD-40-E
Item Weight	27.6 pounds
Product Dimensions	17.44 x 19.5 x 17.87 inches
Capacity	1.1 Cubic Feet
Installation Type	Countertop
Color	Black
Voltage	110 Volts
Wattage	67 watts
Door Hinges	Reversible
Door Material Type	Plastic
Shelves	1
Included Components	1* shelve, mini freezer

Warranty and Support

FOHERE is committed to providing high-quality products. For specific warranty details regarding your 1.1 Cu.Ft Mini Freezer (Model BD-40-E), please refer to the warranty card included with your purchase or visit the official FOHERE website. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

If you require technical assistance, have questions about operation, or need to report an issue, please contact

FOHERE customer support. Contact information can usually be found on the product packaging, the official FOHERE website, or through your retailer's support channels.

When contacting support, please have your model number (BD-40-E) and purchase date readily available to expedite the process.