

PeacefulHues y6XrJuNCgv3ndq0YtFtyqAPPFb9

PeacefulHues 14,000 BTU Portable Air Conditioner User Manual

Model: y6XrJuNCgv3ndq0YtFtyqAPPFb9

1. SAFETY INFORMATION

Please read all instructions carefully before using this appliance and retain for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury.

- Ensure the power supply matches the voltage specified on the rating label.
- Do not operate the unit with a damaged cord or plug.
- Do not insert fingers or objects into the air inlet or outlet.
- Keep the unit on a stable, level surface to prevent tipping.
- Do not block the air outlets or inlets. Maintain at least 20 cm (8 inches) clearance around the unit.
- Unplug the unit before cleaning or servicing.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. PRODUCT OVERVIEW

The PeacefulHues Portable Air Conditioner is a versatile 3-in-1 unit designed to provide cooling, fan, and dehumidification functions for spaces up to 750 sq. ft. It features a 14,000 BTU cooling capacity, a user-friendly control panel, remote control, and a 24-hour timer for convenient operation.

Included Components

- Portable Air Conditioner Unit
- Remote Control
- Exhaust Hose
- Window Sealing Kit (Window Slider Kit, Adapter)
- User Manual




Figure 2.1: Included Components

3. SETUP AND INSTALLATION

Proper installation is crucial for optimal performance. Ensure the unit is placed on a flat, stable surface and has adequate clearance for airflow.

3.1 Unit Placement

- Place the air conditioner on a firm, level floor.
- Maintain a minimum distance of 20 cm (8 inches) from walls or other objects to ensure proper air circulation.
- Avoid placing the unit in direct sunlight or near heat sources.

3.2 Window Kit Installation

The window kit is designed for installation in double-hung or sliding windows.

1. Adjust the window slider kit to fit your window opening. The kit is suitable for window widths between 20.47 inches and 39.9 inches.
2. Secure the window slider kit in the window frame.
3. Attach the exhaust hose adapter to the window kit.
4. Connect one end of the exhaust hose to the unit's exhaust outlet and the other end to the adapter on the window kit. Ensure connections are secure to prevent hot air from re-entering the room.



Figure 3.1: Window Kit Setup for Double-Hung and Sliding Windows

Self-Evaporation, Water-Draining Free

No need for repeated drainage, it can effectively reduce the drainage operation of air conditioners.



Figure 3.2: Exhaust Hose Connection

4. OPERATING INSTRUCTIONS

The unit can be operated using the control panel on the top of the unit or the included remote control.

4.1 Control Panel and Remote Control

The control panel features an LED digital display and various buttons for function selection. The remote control provides convenient access to all functions from a distance.

2 In 1 Operation Design

Intelligent touch panel & remote control



Figure 4.1: Control Panel and Remote Control

4.2 Operating Modes

Press the 'MODE' button to cycle through the available operating modes:

- **Cooling Mode:** Provides powerful cooling. Set desired temperature between 64°F (18°C) and 90°F (32°C) using the 'UP' and 'DOWN' buttons.
- **Fan Mode:** Circulates air without cooling. Select fan speed (High, Low, Auto) using the 'SPEED' button.
- **Dehumidify Mode:** Removes excess moisture from the air, with a capacity of up to 90 pints per day.



Figure 4.2: Operating Modes

4.3 Timer Function

The 24-hour timer allows you to schedule the unit to turn on or off automatically. Press the 'TIMER' button and use 'UP'/'DOWN' to set the desired time in hours.

4.4 Sleep Mode

Activate Sleep Mode for quiet operation during rest periods. The unit will operate at a lower fan speed and gradually adjust the temperature for comfort. Press the 'SLEEP' button to activate.



Figure 4.3: Sleep Mode Features

4.5 Auto Swing

Press the 'SWING' button to activate the automatic louver swing, which helps distribute air evenly throughout the room.

5. MAINTENANCE

Regular maintenance ensures efficient operation and extends the lifespan of your air conditioner.

5.1 Air Filter Cleaning

The air filter should be cleaned every two weeks or more frequently depending on usage and air quality.

1. Unplug the air conditioner from the power outlet.
2. Remove the filter cover and slide out the air filter.
3. Wash the filter with warm water and a mild detergent. Rinse thoroughly.
4. Allow the filter to air dry completely before reinserting it into the unit.



Figure 5.1: Air Filter Cleaning Process

5.2 Water Drainage

This unit features a self-evaporation system, which typically eliminates the need for manual drainage in cooling mode. However, in high humidity conditions or when using dehumidify mode, the internal water tank may fill up. The unit will indicate when drainage is required.

1. Turn off the unit and unplug it.
2. Place a shallow pan or tray under the drainage port located at the bottom rear of the unit.
3. Remove the drain plug to allow water to flow out.
4. Once drained, replace the drain plug securely.



Figure 5.2: Self-Evaporation System

5.3 Storage

Before storing the unit for an extended period:

- Drain all accumulated water.
- Clean the air filter.
- Store the unit in a cool, dry place, covered to protect from dust.

6. TROUBLESHOOTING

Before contacting customer support, please refer to the following troubleshooting guide for common issues.

Problem	Possible Cause	Solution
Unit does not turn on	No power supply Power cord not plugged in Circuit breaker tripped	Check power outlet Ensure cord is securely plugged in Reset circuit breaker
Unit does not cool effectively	Air filter dirty Room size too large Windows/doors open Exhaust hose not properly installed Temperature setting too high	Clean air filter Ensure unit is suitable for room size Close all windows and doors Check exhaust hose for proper sealing Lower the temperature setting
Water leakage	Drain plug loose Unit tilted Drainage pan full (if applicable)	Ensure drain plug is secure Place unit on a level surface Drain water from the unit
Noisy operation	Unit not on a level surface Air filter dirty Obstruction in fan	Place unit on a level surface Clean air filter Check for and remove any obstructions

7. SPECIFICATIONS

Feature	Specification
Model Number	y6XrJuNCgv3ndq0YtFtyqAPPFb9
Cooling Power	14,000 BTU
Coverage Area	Up to 750 sq. ft.
Operating Modes	Cooling, Fan, Dehumidify
Dehumidification Capacity	90 pints/day
Noise Level	48 Decibels
Temperature Range	64°F - 90°F (18°C - 32°C)
Voltage	115V
Wattage	1150W
Product Dimensions (D x W x H)	20.47" x 18.31" x 34.06"
Item Weight	80.5 Pounds
Control Method	Remote Control, Digital Display
Timer	1-24 Hour
Special Features	Sleep Mode, Auto Swing, Dust Filter

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This PeacefulHues Portable Air Conditioner comes with a **2-Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accident, alteration, or unauthorized repair.

8.2 Customer Support

If you have any questions, require assistance, or need to claim warranty service, please contact PeacefulHues customer support. Please have your model number and purchase date available when contacting support. Contact information can typically be found on the product packaging or the official PeacefulHues website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question