

Gezoon D1520

Gezoon D1520 15.6 inch Laptop User Manual

Model: D1520 | Brand: Gezoon

INTRODUCTION

This manual provides comprehensive instructions for setting up, operating, and maintaining your Gezoon D1520 15.6 inch Laptop. This device features an Intel 12th Generation Celeron N100 processor, 16GB LPDDR4 RAM, a 1TB SSD, and a 2K FHD IPS display, designed for efficient multitasking and a clear visual experience. Please read this manual thoroughly to ensure proper usage and to maximize the lifespan of your device.

WHAT'S IN THE BOX

- Gezoon D1520 Laptop
- Power Adapter
- User Manual
- Keyboard Cover
- Warranty Card

PRODUCT OVERVIEW



The Gezoon D1520 laptop features a sleek grey finish. The screen displays key specifications including 1080P Full HD resolution, Windows 11 Pro operating system, Intel N100 processor, 12GB DDR4 RAM, and 512GB SSD storage. The full-size keyboard and large trackpad are visible.

Exterior Features

The laptop features a brushed-look plastic composite casing in grey, offering a modern and durable design.

Left Side Ports

On the left side, the laptop includes a memory card reader slot, a USB 3.2 Gen1 Type-A port, a headphone/microphone combo jack, and a security cable lock slot.

Right Side Ports

The right side of the laptop features a DC power input jack, a Mini HDMI port, a USB 3.2 Gen1 Type-A port, and a Full-Featured Type-C port.

Bottom View

The bottom of the laptop includes ventilation grilles for cooling and rubber feet for stability. It also displays the "HaloBook Plus" model name and "Intel Inside" branding.

Keyboard and Trackpad

The laptop is equipped with a full-size keyboard including a numeric keypad. The large trackpad supports multi-touch gestures and includes integrated click functionality.

Webcam

A built-in HD front camera is located at the top center of the display, featuring a physical privacy slider for enhanced security.

SETUP INSTRUCTIONS

- 1. Initial Charge:** Connect the provided power adapter to the laptop's DC power input jack and then to a functional power

outlet. Allow the battery to charge fully before the first use to optimize battery health.

- 2. **Power On:** Open the laptop lid and press the power button located on the keyboard. The laptop will begin its boot sequence.
- 3. **Operating System Setup:** Follow the on-screen prompts to complete the Windows 11 Pro setup process. This typically includes selecting your language, connecting to a Wi-Fi network, accepting terms and conditions, and creating a user account.

OPERATING INSTRUCTIONS

Processor and Performance

The laptop is powered by an Intel 12th Generation Celeron N100 processor with 4 cores and 4 threads, capable of clocking up to 3.40GHz. This processor is designed for efficient handling of everyday computing tasks, from office applications to web browsing and media consumption.

Memory and Storage

Equipped with 16GB of LPDDR4 RAM, the system ensures smooth multitasking. The 1TB M.2 2280 SATA Solid State Drive (SSD) provides fast boot times and quick application loading. The SSD storage is expandable for future needs.

Display

The 15.6-inch 1920x1080 Full HD IPS display offers vibrant colors and wide viewing angles, suitable for both work and entertainment. The thin bezel design enhances the visual experience.

Connectivity

The laptop supports 2.4G/5G Wi-Fi for reliable internet access and Bluetooth 4.2 for connecting wireless peripherals such as headphones or mice.

Audio

Integrated dual stereo speakers provide clear audio output, while dual array microphones ensure clear voice capture for video calls and recordings.

Webcam Usage

To use the built-in HD webcam, slide the physical privacy cover to the open position. To ensure privacy when the webcam is not in use, slide the cover back to the closed position.

SPECIFICATIONS

Feature	Specification
Brand	Gezoon
Model Name	D1520
Screen Size	15.6 Inches
Screen Resolution	1920 x 1080 pixels (Full HD)
Max Screen Resolution	1920x1080 Pixels
Processor	Intel Processor N100 (Up to 3.4 GHz)

Feature	Specification
Number of Processors	4
RAM	16 GB LPDDR4
Hard Drive	1 TB SSD (M.2 2280 SATA)
Graphics Coprocessor	Intel UHD Graphics 730
Wireless Type	2.4 GHz Radio Frequency, 5.8 GHz Radio Frequency, Bluetooth
Number of USB 3.0 Ports	2
Operating System	Windows 11 Pro
Item Weight	4.21 pounds
Product Dimensions	12.6 x 8.2 x 0.7 inches
Color	Grey
Special Feature	High-definition screen, Lightweight, Memory Card Slot, Numeric Keypad, Ultra-thin

MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth for cleaning the screen and chassis. Avoid harsh chemicals or abrasive materials that could damage the surfaces.
- **Battery Care:** To prolong battery life, avoid exposing the laptop to extreme temperatures. It is recommended to fully discharge and recharge the battery periodically.
- **Software Updates:** Regularly update Windows 11 Pro and all device drivers to ensure optimal performance, security, and compatibility.
- **Storage Management:** Periodically clear unnecessary files and applications to maintain sufficient free storage space for smooth operation.

TROUBLESHOOTING

- **No Power:** Ensure the power adapter is securely connected to both the laptop and a working power outlet. Check if the power outlet is functional by plugging in another device.
- **Display Issues:** If the screen is blank or flickering, try restarting the laptop. If an external monitor is connected, ensure it is properly connected and the correct input source is selected.
- **Connectivity Problems:** Verify that Wi-Fi and Bluetooth are enabled in the operating system settings. If issues persist, try restarting your router or updating wireless drivers.
- **Slow Performance:** Close any unnecessary applications running in the background. Check for system updates and ensure there is sufficient free storage space on the SSD. Running a malware scan may also help.
- **Audio Not Working:** Check the volume settings and ensure headphones are not accidentally plugged in. Verify audio drivers are installed and up to date.

WARRANTY AND SUPPORT

For detailed warranty information, terms, and conditions, please refer to the warranty card included with your Gezoon D1520 laptop. For technical support, product inquiries, or service requests, please visit the official Gezoon website or contact their customer service as indicated in your product documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question