

## Kinglucky A8

# Kinglucky A8 Upgraded Clip-On Open-Ear Earbuds User Manual

Model: A8

## INTRODUCTION

This manual provides detailed instructions for the Kinglucky A8 Upgraded Clip-On Open-Ear Earbuds. Please read this manual thoroughly before using the product to ensure proper operation and to maintain optimal performance.



Image: Kinglucky A8 Clip-On Open-Ear Earbuds and their charging case. The earbuds are shown both inside and outside the case, highlighting their rose gold pink color and unique clip-on design.

## WHAT'S IN THE BOX

Verify that all items are present in the package:

- Kinglucky A8 ClipFree Earbuds
- Charging Case
- USB-C Charging Cable

- User Manual (this document)




Image: A visual representation of the package contents, showing the gift wrapping box, the charging case, the ClipFree A8 earbuds, and a USB-C charging cable.

## SETUP

---

### 1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB-C charging cable to the charging port on the case and plug the other end into a USB power source. The indicator light on the case will show charging status.

- A full charge provides up to 6 hours of playtime for the earbuds.
- The charging case extends total playtime to approximately 50 hours.

### 2. Wearing the Earbuds

The Kinglucky A8 earbuds feature a flexible C-shaped clip design for comfortable and secure placement. Each earbud weighs approximately 4.0g.

1. Gently clip the earbud onto the top edge of your ear.
2. Adjust the earbud slightly up or down to find your most comfortable and secure fit. The open-ear design allows you to remain aware of your surroundings.




Image: A two-panel diagram illustrating the correct way to wear the clip-on earbuds. The first panel shows gently clipping the earbud onto the ear, and the second shows adjusting it for a perfect fit.

### 3. Bluetooth Pairing

The earbuds utilize Bluetooth 5.4 for stable and efficient connection.

- 1. Open the charging case. The earbuds will automatically enter pairing mode.
- 2. On your device (smartphone, tablet, etc.), go to Bluetooth settings.
- 3. Select "Kinglucky A8" from the list of available devices.
- 4. Once connected, you will hear an audio confirmation, and the indicator light on the earbuds will change.

## OPERATING INSTRUCTIONS

### Touch Controls

The Kinglucky A8 earbuds feature intuitive touch controls on each earbud for managing audio playback and calls.




Image: A visual guide to the touch controls. It shows icons for music and calls, detailing single taps for volume/answer, double taps for play/pause, and press-and-hold for rejecting calls.


### Touch Control Functions

Action	Function
--------	----------

Action	Function
Single Tap	Volume Up / Volume Down (depending on earbud) or Answer Call
Double Tap	Play / Pause Music
Press and Hold (2 seconds)	Reject Call / Activate Voice Assistant

MultiPoint Pairing

The Kinglucky A8 earbuds support MultiPoint Pairing, allowing simultaneous connection to two devices. This enables seamless switching between your phone, tablet, smartwatch, or computer without needing to manually disconnect and reconnect.



MAINTENANCE

Cleaning

To maintain optimal performance and hygiene, regularly clean your earbuds and charging case. Use a soft, dry, lint-free cloth. Avoid using abrasive materials, alcohol, or chemical cleaners.

Water Resistance (IP56)

The Kinglucky A8 earbuds are rated IP56 for water resistance. This means they are protected against dust ingress and high-pressure water jets from any direction. They are suitable for use during workouts, light rain, and daily activities where sweat or splashes may occur. They are not designed for submersion in water.



Image: A graphic depicting the Kinglucky A8 earbuds with water droplets, emphasizing their IP56 water-resistant rating and suitability for active use.

TROUBLESHOOTING

If you encounter issues with your Kinglucky A8 earbuds, refer to the following common solutions:

- Earbuds not pairing:



- Ensure both earbuds are charged.
  - Place earbuds back in the case, close it, then open it again to re-enter pairing mode.
  - Turn off and on your device's Bluetooth.
  - Forget "Kinglucky A8" from your device's Bluetooth list and try pairing again.
- **No sound or low volume:**
    - Check the volume levels on both your device's and the earbuds.
    - Ensure earbuds are properly connected to your device.
    - Clean any debris from the earbud speakers.
- **Charging issues:**
    - Verify the charging cable and adapter are working correctly.
    - Ensure the charging contacts on the earbuds and inside the case are clean and free of obstruction.
- **Intermittent connection:**
    - Ensure your device is within the effective Bluetooth range (typically 10 meters/33 feet) without significant obstacles.
    - Avoid strong electromagnetic interference.

If problems persist, please contact Kinglucky customer support for further assistance.

## SPECIFICATIONS







Feature	Detail
Model Name	A8
Connectivity Technology	Wireless (Bluetooth 5.4)
Ear Placement	Open Ear (Clip-On)
Form Factor	True Wireless
Playtime (Earbuds)	Up to 6 hours per charge
Total Playtime (with Charging Case)	Up to 50 hours
Earbud Weight	Approximately 4.0g each
Water Resistance Rating	IP56
Microphones	Dual beamforming with ENC noise cancelling
Material	Plastic
Impedance	32 Ohm
Compatible Devices	Cellphones and other Bluetooth-enabled devices

## WARRANTY AND SUPPORT

Kinglucky products are designed for reliability and performance. For warranty information or technical support,

please refer to the official Kinglucky website or contact their customer service directly.  
You can visit the Kinglucky store for more information:[Kinglucky Official Store](#)

Related Documents - A8

	<p><a href="#">Kinglucky K12 Karaoke System User Manual</a></p> <p>Comprehensive user manual for the Kinglucky K12 Karaoke System, detailing product specifications, speaker and microphone functions, connectivity, and troubleshooting.</p>
	<p><a href="#">Kinglucky K12 Karaoke Machine User Manual</a></p> <p>This manual provides instructions for operating the Kinglucky K12 Karaoke Machine, covering its functions, specifications, and troubleshooting.</p>
	<p><a href="#">A8 Wireless Earbuds - User Manual and Support Information</a></p> <p>Official user manual and customer support details for A8 Wireless Earbuds, featuring Bluetooth 5.3, noise cancellation, 42-hour playtime, and IP7 waterproofing. Contact support for assistance.</p>
	<p><a href="#">Kinglucky X7 Bone Conduction Headphones User Manual</a></p> <p>User manual for the Kinglucky X7 Bone Conduction Headphones, detailing features, operation, specifications, and troubleshooting. Includes FCC statement.</p>
	<p><a href="#">Kinglucky i12 User Manual and FCC Compliance Information</a></p> <p>This document provides FCC compliance information and user guidance for the Kinglucky i12 device, model number i12. It details FCC rules, potential interference, and user corrective measures.</p>
	<p><a href="#">Kinglucky K12 Karaoke System User Manual</a></p> <p>Comprehensive user manual for the Kinglucky K12 Karaoke System, detailing product specifications, speaker and microphone functions, connectivity, and troubleshooting.</p>