

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [TECKNET](#) /

› [TECKNET TK-FB001 1000W Bullet Blender Instruction Manual](#)

TECKNET TK-FB001

TECKNET TK-FB001 1000W Bullet Blender Instruction Manual

Model: TK-FB001 | Brand: TECKNET

INTRODUCTION

Thank you for choosing the TECKNET TK-FB001 1000W Bullet Blender. This powerful and versatile appliance is designed for efficient blending and grinding, perfect for smoothies, protein shakes, vegetable juices, and coffee beans. Please read this manual thoroughly before first use to ensure safe operation and optimal performance.

INCLUDED COMPONENTS

Your TECKNET TK-FB001 Bullet Blender package includes the following items:

- 1000W Motor Base
- Cross Blade Assembly
- 17oz (500ml) Food-Grade Cup
- 10oz (150ml) Food-Grade Cup
- Food-Grade Sealing Lid
- Funnel
- Cleaning Brush

1000W EXTREME POWER

Easy Production



Image: All components of the TECKNET Bullet Blender laid out, showing the motor base, two different sized cups, blade assembly, and lids.


SAFETY INSTRUCTIONS

To prevent injury or damage, always follow these safety precautions:

- **Read All Instructions:** Familiarize yourself with the appliance before use.
- **Electrical Safety:** Ensure the voltage matches your power supply. Do not immerse the motor base in water or other liquids.
- **Blade Safety:** Blades are sharp. Handle with extreme care. Avoid contact with moving parts.
- **Secure Assembly:** Always ensure the cup and blade assembly are securely locked onto the motor base before operating. The triple-point lock system prevents accidental starts.
- **Overheat Protection:** The blender features built-in overheating protection. If the motor stops during extended use or when processing hard ingredients, allow it to cool down before resuming operation.
- **Stability:** The motor base is equipped with 4 non-slip silicone pads to ensure stable operation on countertops.
- **Children:** Keep the appliance out of reach of children. Close supervision is necessary when used near children.
- **Maintenance:** Do not attempt to repair the appliance yourself. Contact customer service for assistance.


Bottom Cooling Fan

Prevents overheating and extends service life



4 Non-slip Silicone Pads

Reduces vibration and improves stability



Three-point Mechanical Trigger

Prevents accidental activation and ensures safety

Image: Detailed view of the blender's safety features, including the bottom cooling fan, four non-slip silicone pads, and the three-point mechanical trigger for secure cup placement.

SETUP

Before first use, wash all removable parts (cups, lids, blade assembly) with warm, soapy water. Rinse thoroughly and dry. Ensure the motor base is unplugged and placed on a stable, flat surface.

OPERATING INSTRUCTIONS

General Blending (Smoothies, Shakes, Juices)

1. **Prepare Ingredients:** Add your desired ingredients to the blending cup. Ensure ingredients do not exceed the 'MAX' fill line. For best results, add liquids first, then soft ingredients, followed by harder ingredients (frozen fruit, ice).
2. **Attach Blade:** Screw the cross blade assembly onto the open end of the blending cup until it is securely tightened.
3. **Place on Base:** Invert the cup and blade assembly and place it onto the motor base. Align the tabs on the cup with the slots on the base.

4. **Activate Blending:** Press down firmly on the top of the cup. The blender will start operating. Blend until desired consistency is achieved. For optimal blending and to prevent overheating, use short pulses rather than continuous operation.
5. **Remove Cup:** Release pressure from the cup to stop blending. Lift the cup and blade assembly from the motor base.
6. **Serve:** Unscrew the blade assembly from the cup. Attach a sealing lid or shaker lid if taking on the go, or pour directly into a glass.



Image: A visual guide demonstrating the simple four-step process of filling the cup, attaching the blade, placing it on the motor base, and twisting to activate blending.

Grinding (Coffee Beans, Nuts, Spices)

Use the smaller 10oz cup for grinding dry ingredients. Follow the same steps as general blending, but ensure ingredients are dry and do not overfill the cup. Use short pulses for precise grinding.

CYCLONIC BLADE

Blend anything effortlessly



Image: The TECKNET Bullet Blender with its cyclonic blade system, shown with various ingredients like fruits and vegetables, illustrating its versatility for smoothies, oatmeal, vegetable juices, and baby food.

Official Product Video

Your browser does not support the video tag.

Video: An official product video from TECKNET demonstrating the 1000W High Speed Countertop Blender in action, showcasing its blending capabilities with various ingredients.

MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygiene of your blender. The TECKNET Bullet Blender offers effortless cleaning options:

- **Rinse Under Water:** After each use, rinse the cups and blade assembly under running water.
- **Dishwasher Safe:** The cups and lids are dishwasher safe for convenient cleaning.
- **Self-Cleaning Mode:** For quick cleaning, add water and a drop of dish soap to the blending cup, attach the blade, and pulse on the motor base for a few seconds. Rinse thoroughly.
- **Cleaning Brush:** Use the included cleaning brush to remove any stubborn residue from the blades or hard-to-reach areas.
- **Motor Base:** Wipe the motor base with a damp cloth. Never immerse it in water.



Image: A visual representation of the three easy cleaning methods for the blender: rinsing the blade under clean water, using the self-cleaning function with the cup on the base, and placing cups and lids in a dishwasher.

TROUBLESHOOTING

- **Blender Not Starting:** Ensure the cup and blade assembly are correctly aligned and securely locked onto the motor base. The blender will not operate if not properly assembled.
- **Motor Stops During Use:** This indicates the overheat protection has activated. Unplug the blender and allow it to cool down for at least 15-20 minutes before attempting to use it again. Reduce the load or add more liquid if ingredients are too thick.
- **Ingredients Not Blending Smoothly:** Add more liquid to the mixture. Ensure ingredients are cut into smaller pieces. Use the pulse function to break down larger chunks.
- **Leaking:** Check that the blade assembly is tightly screwed onto the cup and that the sealing ring is properly seated. Do not overfill the cup beyond the 'MAX' line.

SPECIFICATIONS

Brand	TECKNET
Model Number	TK-FB001
Power	1000W
Voltage	120 Volts
Capacity	17oz (500ml) & 10oz (150ml) Cups
Blade Material	Stainless Steel
Control Type	Manual (Press-down activation)
Product Dimensions	9.5"D x 5"W x 11"H
Item Weight	3.4 pounds

WARRANTY AND SUPPORT

TECKNET offers a **36-month warranty** (with registration) for your TK-FB001 Bullet Blender. This warranty covers manufacturing defects and ensures peace of mind. For technical support, usage tips, or any warranty-related inquiries, please contact our dedicated customer service team. Refer to the contact information provided in your product packaging or visit the official TECKNET website.