

[Manuals.plus](#) /

> [VINGLI](#) /

> VINGLI Padded Zero Gravity Chair Instruction Manual - Model VLB1393

VINGLI VLB1393

VINGLI Padded Zero Gravity Chair Instruction Manual

Model: VLB1393 | Brand: VINGLI

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before using your VINGLI Padded Zero Gravity Chair. Retain this manual for future reference.

- **Maximum Weight Limit:** The chair is designed to support a maximum weight of 440 lbs (200 kg). Do not exceed this limit to prevent injury or damage to the chair.
- **Stability:** Ensure the chair is placed on a flat, stable surface before use. Avoid uneven terrain.
- **Mechanism Operation:** Be cautious when operating the folding and reclining mechanisms. Keep hands and fingers clear of moving parts to avoid pinching.
- **Children and Pets:** Keep children and pets away from the chair during setup and adjustment.
- **Cleaning:** Use only mild soap and water for cleaning. Avoid harsh chemicals that may damage the fabric or frame.
- **Storage:** When not in use, fold the chair and store it in a dry, protected area to prolong its lifespan.

2. PRODUCT OVERVIEW

The VINGLI Padded Zero Gravity Chair is designed for ultimate comfort and relaxation, suitable for both indoor and outdoor environments. Key features include:

- **Premium Cotton Padding:** Features an ultra-soft, thick cotton padding for enhanced support and comfort.
- **Adjustable Reclining Mechanism:** Allows for multiple reclining positions, from upright to a full zero-gravity recline.
- **Durable Construction:** Built with a reinforced steel tube frame for strength and stability, supporting up to 440 lbs.
- **Portable Folding Design:** Folds flat for convenient storage and easy transport.
- **Convenient Side Tray:** Includes a detachable side tray with cup holders and slots for a tablet or phone.
- **Removable Head Pillow:** An adjustable headrest pillow provides additional comfort.
- **Breathable Fabric:** The underlying fabric ensures air circulation, keeping you cool.



Figure 2.1: VINGLI Padded Zero Gravity Chair with cushion and side tray.

SEASONAL COMFORT CUSTOMIZED

Without Cushion
Breathable & waterproof

With Cushion
Soft & Warm



Figure 2.2: Detailed view of the headrest cushion, cup holder, and sturdy framework.

UPGRADED CUSHION

VINGLI



OTHER

VS

OUR



PP Cotton



Durable



Thick



Breathable

Figure 2.3: Illustration of the upgraded thick cushion, providing 1.5 times more fill than other models.

VINGLI | Product Size



Max Load



Weight



26"

36"



20"

44"

30"

24"

Figure 2.4: The chair offers seasonal comfort, usable with or without the padded cushion.

3. PACKAGE CONTENTS

Verify that all components are present before assembly or use:

- 1 x VINGLI Zero Gravity Chair Frame
- 1 x Padded Cushion (pre-attached)
- 1 x Adjustable Head Pillow
- 1 x Detachable Side Tray with Cup Holders

4. SETUP INSTRUCTIONS

The VINGLI Padded Zero Gravity Chair requires no assembly. It arrives pre-assembled and ready for use. Follow these steps to unfold and prepare your chair:

1. Remove the chair from its packaging.

2. Gently pull the chair's armrests outwards to begin unfolding it.
3. Continue unfolding until the chair is fully extended and stable on all four legs. Ensure all locking mechanisms are disengaged during unfolding.
4. Attach the side tray by sliding it onto the designated slots on the armrest.
5. Adjust the head pillow to your desired height for optimal neck support.



Figure 4.1: The chair unfolded and ready for use.

5. OPERATING INSTRUCTIONS

5.1 Adjusting the Recline Position

The chair features an adjustable reclining mechanism to find your preferred comfort angle. Follow these steps:

1. Sit comfortably in the chair.
2. Locate the locking rings/levers on both armrests.
3. To unlock, pull the locking rings **inward** towards your body.
4. Lean back slowly, using your body weight to adjust the chair to your desired recline angle. Simultaneously, gently push your feet forward on the chair legs to extend the footrest.
5. Once the desired position is reached, push the locking rings **outward** to secure the chair in place. Ensure both locks are fully engaged before relaxing.

Your browser does not support the video tag.

Video 5.1: Demonstration of backrest adjustment and locking operation. This video illustrates how to recline the chair and secure it in position using the armrest locks.



Figure 5.1: User demonstrating a comfortable reclined position.

5.2 Using the Side Tray

The detachable side tray provides convenient storage for your items:

- The tray features two cup holders suitable for various beverage sizes.
- Additional slots are available for holding a tablet, smartphone, or other small personal items.
- Ensure items placed on the tray do not exceed its weight capacity or cause instability.

5.3 Adjusting the Head Pillow

The head pillow can be moved up or down along the backrest to provide personalized neck and head support.

6. MAINTENANCE

6.1 Cleaning

- **Cushion:** The padded cushion is removable. Spot clean with a damp cloth and mild detergent. Allow to air dry completely before reattaching or storing.
- **Frame:** Wipe the steel frame with a damp cloth. For stubborn dirt, use mild soap and water. Dry thoroughly to prevent rust.
- **Side Tray:** Wipe clean with a damp cloth.

6.2 Storage

To store the chair:

1. Ensure the chair is in an upright, unlocked position.
2. Remove the side tray and head pillow if desired.
3. Gently push the armrests inwards to fold the chair flat.
4. Secure the folded chair with the integrated buckle and strap for compact storage and easy transport.
5. Store in a cool, dry place, away from direct sunlight and extreme weather conditions.



Figure 6.1: The chair can be folded flat for convenient storage and transport.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not recline smoothly or locks do not hold.	Locking mechanism is not fully disengaged/engaged; debris in mechanism; worn parts.	Ensure locking rings are pulled fully inward to unlock and pushed fully outward to lock. Clean any debris from the mechanism. If issues persist, contact customer support.

Problem	Possible Cause	Solution
Chair feels unstable.	Uneven surface; chair not fully unfolded; weight limit exceeded.	Place chair on a flat, level surface. Ensure the chair is fully unfolded and all legs are stable. Verify user weight is within the 440 lbs limit.
Cushion appears flattened or uncomfortable.	Prolonged compression; need for fluffing.	Fluff the cushion regularly. If the cushion is significantly worn, consider replacement.

8. SPECIFICATIONS

Feature	Detail
Brand	VINGLI
Model Name	VLB1393
Color	Black (as per current product)
Product Dimensions (Unfolded)	33"D x 26"W x 43"H
Seat Depth	26 inches
Maximum Weight Recommendation	440 Pounds
Item Weight	40.5 pounds
Fill Material	Cotton
Reclining Position Count	5
Included Components	Cup Holder, Cushion
Indoor/Outdoor Usage	Outdoor (suitable for indoor as well)

9. WARRANTY AND CUSTOMER SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact VINGLI customer service through the retailer where the product was purchased or visit the official VINGLI brand store online.

Online Store: [VINGLI Official Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F8J4YWBX>

More documents and user manuals: <https://manuals.plus/>