

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Cecotec](#) /

› [Cecotec Fast&Furious 6050 X-Treme Steam Iron User Manual](#)

Cecotec Fast&Furious 6050 X-Treme

Cecotec Fast&Furious 6050 X-Treme Steam Iron User Manual

Model: Fast&Furious 6050 X-Treme

1. INTRODUCTION AND SAFETY INFORMATION

Thank you for choosing the Cecotec Fast&Furious 6050 X-Treme Steam Iron. This manual provides essential information for the safe and efficient use of your appliance. Please read it thoroughly before first use and keep it for future reference.

Important Safety Instructions:

- Always ensure the voltage indicated on the rating plate matches your mains voltage.
- Do not immerse the iron, power cord, or plug in water or any other liquid.
- Never leave the iron unattended while it is switched on or connected to the power supply.
- Keep the iron and its cord out of reach of children and pets when it is switched on or cooling down.
- The soleplate of the iron becomes extremely hot during use. Avoid direct contact with hot surfaces.
- Unplug the iron from the power outlet before filling or emptying the water tank, and when not in use.
- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged.
- Use the iron only for its intended household purpose of ironing garments.

2. PRODUCT OVERVIEW

The Cecotec Fast&Furious 6050 X-Treme is a powerful steam iron designed for efficient garment care. It features a high wattage for quick heating, an integrated water pump for consistent steam, and a tactile sensor for steam control.

Note: Product images and diagrams would typically be included here to illustrate components such as the soleplate, water tank, spray nozzle, steam button, temperature dial, and power cord. No images were provided in the input data.

3. SETUP AND FIRST USE

Unpacking:

- Carefully remove the iron and all accessories from the packaging.

- Remove any protective films, stickers, or labels from the soleplate or body of the iron.
- Retain the packaging for future storage or disposal.

Filling the Water Tank:

1. Ensure the iron is unplugged from the power outlet.
2. Open the water tank inlet cover.
3. Fill the water tank with clean tap water up to the 'MAX' fill line. For areas with hard water, it is recommended to use a mixture of 50% tap water and 50% distilled water, or solely distilled water to prevent limescale buildup.
4. Close the water tank inlet cover securely.

Initial Heating:

For the first use, or after prolonged storage, it is advisable to iron an old piece of fabric to remove any manufacturing residues from the soleplate. Some light smoke or odor may occur during the first few minutes of operation; this is normal and will dissipate.

4. OPERATING INSTRUCTIONS

Temperature Selection:

- Plug the iron into a suitable power outlet.
- Turn the temperature dial to the desired setting based on the fabric type. Start with lower temperatures for delicate fabrics and increase for heavier materials.
- The indicator light will illuminate while the iron is heating and turn off when the set temperature is reached.

Steam Ironing:

- Ensure the water tank is filled.
- Set the temperature dial to a steam-compatible setting (usually indicated by steam symbols on the dial). Steam will only be produced at higher temperatures.
- The Fast&Furious 6050 X-Treme features a tactile sensor for steam control. Simply hold the iron handle to activate continuous steam. Release to stop.
- Move the iron smoothly over the fabric.

Steam Shot / Vertical Steaming:

- For stubborn creases, press the steam shot button (if available, typically located on the handle). A powerful burst of steam will be emitted. Wait a few seconds between shots to allow the iron to reheat.
- For vertical steaming of hanging garments or curtains, hold the iron vertically a few centimeters away from the fabric and press the steam shot button.

Dry Ironing:

- If you wish to iron without steam, ensure the water tank is empty or the steam control is set to the 'dry' position (if applicable).
- Select the desired temperature for your fabric.

Automatic Shut-off:

For safety and energy saving, the iron is equipped with an automatic shut-off feature. If the iron is left motionless on its heel rest for approximately 8 minutes, or on its soleplate for approximately 30 seconds, it will automatically switch off. The indicator light will flash to indicate this. To reactivate, simply move the iron.

5. MAINTENANCE AND STORAGE

Cleaning the Soleplate:

- Always unplug the iron and allow it to cool completely before cleaning.
- Wipe the soleplate with a damp cloth and a non-abrasive cleaner if necessary. Do not use abrasive scouring pads or metal cleaners.
- For stubborn starch or residue, a specialized iron soleplate cleaner can be used following its instructions.

Descaling (Anti-Calc System):

The Fast&Furious 6050 X-Treme has an integrated water pump, which helps manage limescale. However, regular descaling is still recommended, especially in hard water areas. Refer to the specific descaling instructions in your full product manual if provided, or use a commercial descaling solution designed for irons, following its instructions.

Emptying and Storage:

- After each use, unplug the iron and allow it to cool down.
- Empty any remaining water from the tank to prevent limescale buildup and leakage.
- Store the iron upright on its heel rest in a dry, safe place, away from direct sunlight and moisture.

6. TROUBLESHOOTING

Before contacting customer support, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Iron not heating.	Not plugged in; power outlet fault; automatic shut-off activated.	Check plug and outlet; move iron to reactivate.
No steam or insufficient steam.	Water tank empty; temperature too low; steam holes blocked; limescale buildup.	Fill water tank; set higher temperature; clean soleplate holes; descale iron.
Water leaking from soleplate.	Temperature too low for steam; overfilled water tank; iron tilted too much.	Increase temperature; do not overfill; keep iron level during use.
Iron sticking to fabric.	Soleplate dirty; temperature too high for fabric.	Clean soleplate; adjust temperature according to fabric type.

7. SPECIFICATIONS

Feature	Specification
---------	---------------

Feature	Specification
Model	Fast&Furious 6050 X-Treme
Power	3100 W
Continuous Steam Output	75 g/min
Steam Shot	Up to 200 g/min (approx.)
Water Tank Capacity	350 ml (approx.)
Voltage / Frequency	220-240V ~ 50/60Hz
Key Features	Integrated water pump, Automatic shut-off, Tactile sensor steam control

8. WARRANTY AND SUPPORT

Information regarding the specific warranty period and terms for your Cecotec Fast&Furious 6050 X-Treme Steam Iron was not available in the provided data. Please refer to the warranty card included with your product or visit the official Cecotec website for detailed warranty information and customer support contact details.

For technical assistance, spare parts, or repairs, please contact the authorized Cecotec service center in your region.

© 2023 Cecotec. All rights reserved.

Related Documents - Fast&Furious 6050 X-Treme

	<p><u>Cecotec Fast&Furious 9040 Absolute / 9050 X-Treme Steam Station User Manual</u></p> <p>Comprehensive user manual for the Cecotec Fast&Furious 9040 Absolute and 9050 X-Treme steam stations, covering safety instructions, parts and components, operation, cleaning, maintenance, technical specifications, and warranty information.</p>
	<p><u>Cecotec Fast&Furious 5055 Pro Steam Iron User Manual</u></p> <p>Comprehensive user manual for the Cecotec Fast&Furious 5055 Pro steam iron, covering safety instructions, parts and components, operation, cleaning, maintenance, technical specifications, and warranty information.</p>
	<p><u>Cecotec FAST&FURIOUS 5050 X-TREME Steam Iron User Manual</u></p> <p>Comprehensive user manual for the Cecotec FAST&FURIOUS 5050 X-TREME steam iron, covering safety instructions, parts and components, operation, cleaning and maintenance, technical specifications, disposal guidelines, and technical support information.</p>

	<p><u>Cecotec Fast&Furious 8060 Ultra Steam Generator Iron Manual</u></p> <p>Comprehensive user manual for the Cecotec Fast&Furious 8060 Ultra steam generator iron, covering safety instructions, operation, cleaning, maintenance, and technical specifications.</p>
	<p><u>Cecotec Fast & Furious 9040 Absolute / 9050 X-Treme Steam Station User Manual</u></p> <p>Comprehensive user manual for the Cecotec Fast & Furious 9040 Absolute and 9050 X-Treme steam stations, covering safety instructions, operation, cleaning, maintenance, and technical specifications.</p>
	<p><u>Cecotec IronHero 1800 Force Vertical Steamer User Manual</u></p> <p>User manual for the Cecotec IronHero 1800 Force vertical garment steamer, including safety instructions, operation, cleaning, maintenance, troubleshooting, and technical specifications.</p>

Documents - Cecotec – Fast&Furious 6050 X-Treme




[\[pdf\] Catalog](#)

Catalogue Steam irons with water pump 2023 CECOTEC EN cdn cecotec cloud s3 amazonaws media IFA2023 |||

FAST FURIOUS, 3D FORCEANODIZED AND IRONHERO Steam irons with water pump Faster ironing with better results Discover Cecotec s steam irons with water pump and quickly remove wrinkles from your clothes while taking care of every garment. Iron with maximum efficiency thanks to its advanced technologi...

lang:en score:33 filesize: 11.44 M page_count: 15 document date: 2023-08-22



[\[pdf\]](#)

C T ES Agosto 23 CECOTEC cdn cecotec cloud s3 amazonaws media IFA2023 |||

CATALOGO GENERAL IFA 2023 Introduccin de la compaa CECOTEC es una compaa joven y disruptiva que, en tan solo 10 aos, lidera el mercado espaol del pequeo electrodomstico gracias a su revolucionaria filosofa de democratizacin de la tecnologa del hogar. Su frmula secreta Lograr en cada referencia, se...

lang:es score:8 filesize: 88.75 M page_count: 2028 document date: 2023-09-01