

BTS-M01

User Manual: Portable Bluetooth Mini Speaker

Model: BTS-M01

INTRODUCTION

Thank you for purchasing the Portable Bluetooth Mini Speaker. This compact and powerful speaker is designed to provide high-quality audio on the go. With its IPX4 waterproof rating and wireless connectivity, it is perfect for various indoor and outdoor activities. Please read this manual carefully to ensure proper use and maintenance of your speaker.

WHAT'S IN THE BOX

- Portable Bluetooth Mini Speaker
- USB Charging Cable
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your new speaker.



Figure 1: Front view of the Portable Bluetooth Mini Speaker, showing the speaker grille with "T&G" logo, control buttons on top, and a carrying strap.

Controls and Ports:

- **Power Button:** Press and hold to turn the speaker on or off.
- **Play/Pause Button:** Press to play or pause audio.
- **Volume Up (+) Button:** Press to increase volume. Press and hold for next track.
- **Volume Down (-) Button:** Press to decrease volume. Press and hold for previous track.
- **Charging Port:** USB port for charging the speaker.
- **LED Indicator:** Shows power status, charging status, and Bluetooth pairing status.

SETUP

1. Charging the Speaker:

1. Connect the small end of the included USB charging cable to the charging port on the speaker.
2. Connect the large end of the USB cable to a USB power adapter (not included) or a computer's USB

port.

3. The LED indicator will illuminate during charging and turn off once fully charged. A full charge takes approximately 1 hour.

2. Bluetooth Pairing:

1. Ensure the speaker is fully charged.
2. Press and hold the Power button to turn on the speaker. The LED indicator will flash, indicating it is in pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings.
4. Search for available devices and select "Mini Bt Speaker" (or similar name) from the list.
5. Once paired, the LED indicator will stop flashing and remain solid, and you may hear a confirmation tone.
6. The speaker will automatically connect to the last paired device when turned on, if the device is within range and Bluetooth is enabled.

OPERATING INSTRUCTIONS

Power On/Off:

- To turn on: Press and hold the Power button until the LED indicator lights up.
- To turn off: Press and hold the Power button until the LED indicator turns off.

Audio Playback:

- **Play/Pause:** Press the Play/Pause button.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.

Hands-Free Calling:

- **Answer Call:** Press the Play/Pause button once when a call comes in.
- **End Call:** Press the Play/Pause button once during a call.
- **Reject Call:** Press and hold the Play/Pause button for 2 seconds.

MAINTENANCE

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the speaker to extreme temperatures, direct sunlight, or high humidity.
- While the speaker is IPX4 waterproof, it is resistant to splashes and light rain, not submersion. Do not immerse the speaker in water.
- Store the speaker in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode; Device Bluetooth is off; Speaker is too far from device.	Ensure speaker is in pairing mode (flashing LED). Turn on Bluetooth on your device. Move speaker closer to device (within 33 feet).
No sound or low volume.	Volume on speaker or device is too low; Speaker is not connected.	Increase volume on both the speaker and your connected device. Re-pair the speaker with your device.
Short battery life.	Battery not fully charged; Battery degradation over time.	Ensure speaker is fully charged (approx. 1 hour). If issue persists after full charge, battery may be degrading.

SPECIFICATIONS

Model Name:	Mini Bt Speaker
Model Number:	BTS-M01
Output Power:	5W
Connectivity:	Bluetooth 5.0
Wireless Range:	Up to 33 feet (10 meters)
Water Resistance:	IPX4 (Splash-proof)
Charging Time:	Approximately 1 hour
Product Dimensions:	2.5"D x 2.5"W x 2.8"H
Item Weight:	1 pound
Material:	Plastic, Metal
Included Components:	Speaker, USB Charging Cable, User Manual

WARRANTY AND SUPPORT

This product comes with a Limited Manufacturer Warranty. For warranty claims or technical support, please refer to the contact information provided on the product packaging or your purchase receipt. Keep your proof of purchase for warranty purposes.

For further assistance, please contact your retailer or the manufacturer directly.