

## Brookstone UB-BRAAV/RI

# Brookstone Audio Aviators Wireless Speaker Sunglasses User Manual

Model: UB-BRAAV/RI

## INTRODUCTION

The Brookstone Audio Aviators are wireless speaker sunglasses designed to provide audio entertainment and UV protection. These aviator-style frames integrate Bluetooth speakers for hands-free listening and calls. They feature polycarbonate lenses that block 100% UVA and UVB rays. The sunglasses are lightweight, rechargeable via micro-USB, and offer up to 2.5 hours of playtime.

## WHAT'S IN THE BOX

- Brookstone Audio Aviators Wireless Speaker Sunglasses
- Micro-USB Charging Cable
- User Manual (this document)



Image: Brookstone Audio Aviators sunglasses shown with the included micro-USB charging cable.

## PRODUCT OVERVIEW

---

Familiarize yourself with the components of your Audio Aviators.



Image: Side view of the sunglasses, highlighting the integrated speaker arm.

1. **Speaker Arms:** Located on both temples, housing the Bluetooth speakers and controls.
2. **Lenses:** Polycarbonate, offering 100% UVA and UVB protection.
3. **Micro-USB Port:** For charging the internal battery (typically located on one of the speaker arms).
4. **Control Buttons:** For power, volume, and playback control.

## SETUP

---

### 1. Charging the Device

1. Locate the micro-USB charging port on one of the speaker arms.
2. Connect the provided micro-USB cable to the sunglasses and the other end to a USB power source (e.g., computer USB port, wall adapter).
3. Allow approximately 1-2 hours for a full charge. The indicator light (if present) will change color or turn off when fully charged.
4. A full charge provides up to 2.5 hours of playtime.

### 2. Bluetooth Pairing

1. Ensure the sunglasses are charged.
2. Press and hold the Power button (refer to product for exact button location) until the indicator light flashes, indicating pairing mode.
3. On your smartphone or Bluetooth-enabled device, go to the Bluetooth settings.
4. Search for available devices and select "Brookstone Audio Aviators" (or similar name).
5. Once connected, the indicator light will typically stop flashing or show a solid color.
6. The sunglasses will automatically attempt to reconnect to the last paired device when powered on.

## OPERATING INSTRUCTIONS

## Power On/Off

- To power on: Press and hold the Power button for approximately 3 seconds.
- To power off: Press and hold the Power button for approximately 5 seconds.

## Music Playback

- **Play/Pause:** Press the Play/Pause button once.
- **Next Track:** Press and hold the Volume Up button (or specific Next Track button).
- **Previous Track:** Press and hold the Volume Down button (or specific Previous Track button).
- **Volume Up:** Short press the Volume Up button.
- **Volume Down:** Short press the Volume Down button.

*Note: Specific button functions may vary slightly. Refer to the physical product for exact button layout and corresponding actions.*

## Phone Calls

- **Answer Call:** Press the Multi-function button (often the Play/Pause button) once when a call comes in.
- **End Call:** Press the Multi-function button once during a call.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds when a call comes in.
- **Redial Last Number:** Double-press the Multi-function button.

## MAINTENANCE

- **Cleaning Lenses:** Use a soft, clean microfiber cloth to wipe the lenses. Avoid abrasive materials or harsh chemical cleaners.
- **Cleaning Frame:** Wipe the frame with a damp cloth and mild soap if necessary. Dry thoroughly.
- **Storage:** Store the sunglasses in a protective case when not in use to prevent scratches and damage. Avoid exposing them to extreme temperatures or direct sunlight for prolonged periods.
- **Water Resistance:** These sunglasses are not waterproof. Avoid submerging them in water or exposing them to heavy rain.

## TROUBLESHOOTING

Problem	Solution
Device does not power on.	Ensure the battery is charged. Connect to a power source using the micro-USB cable.
Cannot pair with Bluetooth device.	Ensure the sunglasses are in pairing mode (indicator light flashing). Make sure Bluetooth is enabled on your device. Move the sunglasses closer to your device. Forget the device from your phone's Bluetooth list and try pairing again.
No audio or low volume.	Increase the volume on both the sunglasses and your connected device. Ensure the sunglasses are properly paired and connected. Check if the audio is playing from another output source on your device.

Problem	Solution
Short battery life.	Ensure the device is fully charged before use. Battery life can be affected by high volume levels.

## SPECIFICATIONS

- **Model Number:** UB-BRAAV/RI
- **Product Dimensions:** 0.5 x 5.8 x 2 inches
- **Item Weight:** 8 ounces
- **Connectivity:** Bluetooth
- **Battery Life:** Up to 2.5 hours playtime
- **Charging:** Micro-USB
- **Lens Material:** Polycarbonate
- **UV Protection:** 100% UVA and UVB
- **Manufacturer:** Rhode Island Novelty

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the manufacturer's official website. Keep your proof of purchase for warranty claims.  
Manufacturer: Rhode Island Novelty