

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Coleman](#) /

› [Coleman Oasis Shelter Wall Accessory \(10x10ft\) Instruction Manual](#)

Coleman 2208030

Coleman Oasis Shelter Wall Accessory (10x10ft) Instruction Manual

Model: 2208030

1. PRODUCT OVERVIEW

The Coleman Oasis Shelter Wall Accessory is designed to provide additional protection from sun, wind, and rain for your 10x10ft canopy. This waterproof wall attaches to any side of compatible canopies, creating a more sheltered outdoor space.

Key Features:

- **Protection:** Offers shade and blocks wind and driving rain.
- **Compatibility:** Designed for Coleman Oasis and Oasis Lite 10 x 10 ft canopies, and compatible with most standard 10x10 pop-up canopies.
- **Attachment:** Simple and secure clip and buckle attachment system.
- **Material:** Constructed from durable, waterproof, PFAS-free polyester fabric.
- **Versatility:** Ideal for beaches, campsites, festivals, tailgates, and backyard gatherings.



Image 1.1: The Coleman Oasis Shelter Wall Accessory providing side protection for a canopy.

2. SETUP INSTRUCTIONS

Follow these steps to properly attach the shelter wall accessory to your canopy.

1. **Unfold the Wall:** Carefully unfold the Coleman Oasis Shelter Wall Accessory.
2. **Position the Wall:** Determine which side of your canopy requires additional protection. The wall can be attached to any side.
3. **Attach Top Clips:** Locate the clips along the top edge of the shelter wall. Attach these clips to the canopy frame or fabric loops at the top of your canopy. Ensure they are securely fastened.
4. **Secure Side Straps/Buckles:** Wrap the side straps or buckles around the canopy legs. Fasten them tightly to ensure a snug and stable fit. The wall also features hooks to go around rounded legs for added stability.
5. **Ground Stakes (Optional but Recommended):** For increased stability, especially in breezy conditions, utilize the provided stakes. Secure any guy lines or loops at the bottom of the wall to the ground using the stakes.

Installation typically takes only a few minutes and does not require special tools.



Pinch-Free Setup

Comfort Grip™ locks canopy in place when extending poles.

Image 2.1: Illustrative image of securing a canopy component, similar to how the wall attaches.

3. OPERATING INSTRUCTIONS

The shelter wall accessory enhances your outdoor experience by providing versatile protection.

Using the Wall for Protection:

- **Sun Protection:** Position the wall on the side where the sun is most intense to block harmful UV rays and create a shaded area.
- **Wind Block:** Attach the wall on the side facing the prevailing wind to reduce wind exposure within your canopy.
- **Rain Protection:** While the wall is waterproof, it is designed to block driving rain from entering the canopy from the side. It is not intended for heavy rain conditions as a primary shelter.
- **Privacy:** Use the wall to create a private space within your canopy, useful at crowded events or campsites.



Sun Protection

Canopies are rated UPF 50+, blocking UV rays. Sun wall clips easily to side of canopy for added shade.

Image 3.1: Canopy with side wall providing sun protection for users.

4. MAINTENANCE

Proper care and maintenance will extend the life of your Coleman Oasis Shelter Wall Accessory.

Cleaning:

- **Spot Cleaning:** For minor dirt or stains, use a soft cloth or sponge with mild soap and lukewarm water. Gently wipe the affected area.
- **Rinsing:** Rinse thoroughly with clean water to remove all soap residue.
- **Drying:** Allow the wall to air dry completely before folding and storing. Do not machine wash or tumble dry. Ensure it is fully dry to prevent mildew.

Storage:

- Store the wall in a cool, dry place, away from direct sunlight and extreme temperatures.
- Ensure the wall is clean and completely dry before storing to prevent mildew and material degradation.
- The lightweight design allows for easy folding and storage in its original bag.

5. TROUBLESHOOTING

Addressing common concerns regarding the shelter wall accessory.

- **Wall does not fit my canopy:** This accessory is designed for 10x10ft Coleman Oasis and Oasis Lite canopies, and generally fits most standard 10x10 pop-up canopies. Verify your canopy's dimensions. Some canopies may have slightly different frame designs.
- **Wall feels loose or unstable:** Ensure all clips and buckles are securely fastened to the canopy frame and legs. If available, use the ground stakes and guy lines to anchor the bottom of the wall for added stability.
- **Water pooling on the wall:** The wall is waterproof and designed to shed water. If water is pooling, check that the wall is taut and properly angled to allow water runoff. Ensure the canopy itself is correctly set up to prevent pooling on the roof.
- **Damage from wind:** The wall is designed to block wind, but it is **not suitable for use in strong winds**. Always take down the canopy and wall accessory in high wind conditions to prevent damage to the product and potential injury.

6. SPECIFICATIONS

Brand	Coleman
Model Number	2208030
UPC	076501172928
Material	Polyester (PFAS-Free)
Color	Gray
Item Weight	2 Pounds (approx. 0.91 kg)
Dimensions (L x W x H)	120"L x 120"W x 132"H (Canopy dimensions, wall fits 10x10ft side)
Water Resistance Level	Water Resistant
UV Protection	Some UV Protection (Canopy typically UPF 50+)

Closure Type	Hook & Loop, Clips, Buckles
--------------	-----------------------------

7. WARRANTY INFORMATION

The Coleman Oasis Shelter Wall Accessory is backed by a **1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For specific details regarding warranty claims or to understand the full terms and conditions, please refer to the warranty documentation included with your purchase or contact Coleman customer support.

8. CUSTOMER SUPPORT

If you have any questions, require assistance with setup, or need to troubleshoot an issue not covered in this manual, please contact Coleman customer support.

Visit the official Coleman website for contact information, FAQs, and additional product resources:

www.coleman.com

9. IMPORTANT SAFETY INFORMATION

- **Wind Conditions:** Do not use the shelter wall or canopy in strong winds. High winds can cause damage to the product and pose a safety risk.
- **Heavy Rain:** The wall provides water resistance but is not designed for heavy rain. Seek alternative shelter during severe weather.
- **Securing the Canopy:** Always secure the main canopy structure to the ground using stakes and guy lines to prevent it from tipping over, especially when the wall accessory is attached.
- **Fire Safety:** Keep all flame and heat sources away from the canopy fabric. The fabric is not fireproof.

10. VIDEO RESOURCES

No official product videos from the seller were found that meet the specified criteria for inclusion in this manual.

© 2023 Coleman. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.